Turning a Shaft with an Emergency Lathe

By Thomas Fowler

While stationed on the United States tender "Ivy," when it was anchored on the Florida reefs a hundred miles from port, the writer was called upon to turn a 6-inch shaft 30 feet long. There was no lathe on board, and it was necessary to improvise one. A tool was made out of a half-inch round file, a tool-holder out of a two-inch hexagonal nut, and a screw feed out of a 2-inch bolt 12 inches long. By this means the shaft was turned a quarter inch off for a length of 4 feet.

A diagram of the apparatus used is published herewith. Several pieces of iron plate $\frac{1}{2}$ by 3 inches were bent to the radius of the shaft, and within each three-tube expander rollers were caged, forming roller bearings for the shaft. These were placed in 10 by 10-inch timbers, and braced to the deck. They served as the bottom bearings, and the caps were made of 10 by 10-inch timbers, cut to the radius of the shaft, lined with yellow metal, and held in place by means of rope tightened with wooden wedges. The shaft was so long that it extended several feet over the starboard side. An L-piece was made fast to the deck, and used as a butting block. A piece of 1-inch round steel was pointed and secured in a timber brace, to

Improved lathe for turning a shaft

serve as a lathe center on the port side of the shaft. On the shaft a pulley 20 inches in diameter was rigged up. It was made of two disks of 2-inch plank mounted on the shaft and connected with 1-inch strips 2 inches wide. To fasten this pulley to the shaft so that it would cause the shaft to turn with it, a rope was passed several times around the shaft at each side and then secured to the pulley. The rope was wrapped in such direction as to bind when the pulley was revolved.

There was no belting at hand, and so a rope belt had to be used. This was wound around the pulley twice, and from there was passed about the nigger-head of the winch, where two turns were made; thence it passed up through a pulley on the end of the boom, and back again to the pulley on the shaft. By raising the boom, it was possible to tighten the rope as it stretched. The shaft was turned by running the winch.

The details of the tool holder and carriage are shown in the illustration. The 2-inch bolt was suitably supported in a pair of brackets, and the hexagonal nut was mounted between them. Two metal strips were fastened with screws to two sides of the nut, so that they came together in the form of a V, with the apex arranged to slide between two rails, as shown to the best advantage in the cross-sectional view. The tool was fitted into a hole drilled parallel with the upper side of the hexagonal nut. It was held in place by means of a setscrew. The tool was fed along the shaft by turning the bolt at each revolution of the shaft, so as to advance the nut. The entire task was completed in two days' time, and the work proved very satisfactory.

To Bend Metal Edgewise

By B. F. Albert

Like many other problems, that of bending metal edgewise is simple enough "if you know how." Take a block of metal, and round it to the form you wish the metal strip to assume. Get a grooved roller with the groove deep enough to receive the metal strip to

Bending a metal strip edgewise

about three-quarters of its width. Bolt or rivet this roller to a lever fulcrumed to the form block at the center from which the curved portion is struck. Hold one end of the strip to the form with a lug, as shown, and then, with the device held firmly in the bench vise, the lever may be operated to bend the strip about the form.

Signs of Cement

By George Rice

While cement block letters have been made and used successfully since the introduction of cement articles in the commercial world, it has been only recently that there has been a practical application of the same. There is always something substantial and convincing in the rock or cement sign which has been made as a part of the structure. Stability is added to the effect by the fact that the sign is a part of the original edifice. While the cement signs can be molded as a part of the building, it is an easy matter to make the base separate and fasten it securely in place with clamping bolts.

Of course, there are well-made signs and poorly-made ones. You need not look far among the signs of this class to find evidences of poor workmanship. You will discover that the weather has had its effect prematurely on some of the signs, and that the corners are worn off and there are cracks. Sometimes the slab is broken, due to excessive pressure of the securing bolts when the slab is based on an uneven level. Sometimes the slab is fractured, due to weakness of the stock. Then there are corners broken or worn off on some of the sign slabs. You can find slabs bearing block raised letters with the edges of the letters badly worn as a result of the rains striking on them. This is due to defective work in the construction of the sign.

If the cement is poorly proportioned, with an excess of "mud," you are going to get a shabby sign.

Cement sign made of block letters

If the molding is done with the stock so soft that the mass is going to cling more or less to the sides of the mold, then you are going to get imperfect letters at the start, the edges will fail to define sharply. The stuff will lag and be sloppy. You may patch and work with the trowel, but without avail. Sometimes the mix is too dry, and a lettered slab is made that may crack and become worthless in a short time.

Much depends upon the character of the letter to be made. The accompanying drawing shows a popular type of letter of the adjustable or portable class. These letters are cast separately. They can be arranged to spell any desired word. The letters are often cemented to the base. But the users of these letters prefer to have fastening devices with which the letters may be removed at will. Sometimes common bolts are used for this purpose, and the letters can be fastened to a base with nuts. The securing devices are more attractive if bronze capped bolts, polished heads, brass tips, nicked covers, etc., are used. The letters may be ground down with an emery wheel to produce a smooth finish. The block cement letters can be provided with electric lamp sockets, as indicated in the drawing, if an illuminated sign is desired. The light shining on the cement background produces a very striking effect.

Cutter for Strawboard

By J. W. Bergstrom

The accompanying illustrations show how a very efficient cutter can be made for strawboard and other pulpy substances. Fig. 1 shows the cutter head mounted on the arbor of a circular saw ready for operation, and Fig. 2 shows a face view of the cutter.

The cutter consists of a head or flange made from cast iron, mounted on an arbor, supported in suitable bearings, like a circular saw. In the face of the flange are drilled a number of holes, say about $\frac{1}{4}$ -inch diameter, into which are driven pieces of tool steel, projecting about $\frac{1}{2}$ inch.

On the feed table a suitable guide is fastened in front of the cutter head, into which moves a guide board, placed at an angle thereto, capable of being moved transversely to the shaft or arbor. The guide board can be made adjustable, so that a different angle

Cutter for beveling strawboard

may be obtained. As the cutter head is running at full speed the strawboard to be beveled is either held or clamped to the guide board, and moved in a transverse direction thereto. The teeth of the cutter head will then cut a very smooth bevel on the soft strawboard. The ends of the teeth need not necessarily be of even length at the start, but will soon wear even.

Hints for the Handy Man

Here is a handy little kink for quick repairing of an umbrella, or for one who would like to change one umbrella handle for another and fasten it on solid. Clean out the hole in the handle, and fill it with powdered sulphur. Place the handle in a fixed upright position, and after heating the umbrella rod red hot, push the rod down into the hole containing the sulphur. The hot rod fuses the sulphur, and this when cold will hold the rod securely. This method may be applied to fastening rods into stone, iron, or wood.

When a die is to be hardened, the threads will get too hot because they are not as thick as the rest of the die. Hence they are liable to burn before the body of the die will get hot enough to harden. A bushing should be threaded to fit the die, and the hole in the bushing should be bored to such a size that the walls will be about 0.02 of an inch thick to the bore. The bush is then screwed in the die ready for hardening. When the die is then heated, it will be a uniform heat, and the threads will not burn before the die becomes hot. The die is then hardened, and it will be found that the threads will not get too hard from dipping in oil, as the bush prevents a sudden chill from the oil. A die treated in this way will be found