(Paper No. 3652.)

“Bond in Brickwork.”

By ERNEST ALFRED WILLIAM PHILLIPS, Assoc. M. Inst. C.E.

It is with diffidence that the Author ventures to reopen a question by common judgment so fixed and settled in theory and practice as correct bonding in brickwork. The Author's practical experience of brickwork dates from 1870, when he received lessons in the art, lasting with intervals about 12 years, from an English master mason and foreman bricklayer and plasterer of over 30 years' experience. The results of the experience thus gained and since extended are submitted in this Paper, and the Author hopes that before criticizing them, the reader will first work out each bond illustrated and described with actual dry bricks or with wooden models of bricks. In no other way does it seem possible to arrive at correct conclusions.

The main object in brickwork is to put the bricks together with good mortar in such bond and manner that, when the work is set, the full strength of both bricks and mortar are utilized.

Modern or so-called English bond is illustrated for walls from 1 to $2\frac{1}{2}$ bricks in thickness in *Figs. 1*. True or old English bond is illustrated in like manner in *Figs. 2*. The two bonds are compared, in general plan, in elevation, and in cross and longitudinal sections, in *Figs. 3*. It may surprise many to learn that the modern form of bonding is a bastard bond; being weak, often ill-jointed, and possessing at the best of times no greater strength longitudinally than the despised Flemish bond, while in thick walls it may become actually dangerous.

Definition of true English Bond.—It is first necessary to lay down a complete definition of true English bond¹:—

(a) The courses are to be composed entirely of headers or of stretchers.

(b) Every brick in a header course must therefore be a header, and every brick in a stretcher course must be a stretcher. A mixture of headers and stretchers in any one course is not English bond.

¹ J. Gwilt, “An Encyclopædia of Architecture.” New ed. London, 1891.

(c) Every brick must break joint in its two longitudinal planes, vertical and horizontal, with all nearest bricks lying in the same parallel direction, and this whether a course of bricks (lying across at right angles) intervenes or not.

(d) The bricks must break joint by half their length. In *Figs. 2*, Course I, stretcher A breaks joint by half its length, not only with adjacent stretchers B, B, B, B in the same course, but also

Figs. 1.

with nearest parallel bricks B, B in Course III and the similar course below. See also Courses II and IV for header bond.

(e) Quarter-brick laps are inadmissible, except between headers and stretchers in adjacent header and stretcher courses, and occasionally, for obvious reasons, at quoins and junctions.

(f) Lines of stretchers must, therefore, lie exactly over lines of stretchers, and lines of headers over lines of headers.

(g) At quoins and junctions the stretcher courses of the one wall will pass through and become the header courses of the meeting or cross wall.

Figs. 2.

(h) True or old English bond is a fixed and immutable bond, absolutely unchangeable, of complete stretcher courses, repeated as often as desired, and of complete header courses, sandwiched between the rows of stretcher courses.

Figs. 3.

PLANS OF 2 COURSES, IN ANY WALL.

ELEVATIONS OF ANY WALL

CROSS SECTIONS, ANY WALL

LONGITUDINAL SECTIONS

HALF-BRICKS SHADED

A. STRETCHERS. ALL VISIBLE ON FACES OF WALL

TRUE BOND

BASTARD BOND

Modern and True Bond compared.—The differences between English bond and bastard bond may be stated as follows:—

(i) English bond consists of alternate or of periodic courses of headers and stretchers, no header course containing any stretchers, and no stretcher course containing any headers.

(ii) In bastard bond every brick in the interior of any wall, however thick, is a header.

(iii) In English bond the composition and arrangement of every course show clearly on the faces of the wall.

(iv) In bastard bond all the stretchers in any wall, however thick, show on the faces of the wall, serving only to conceal the headers inside. (Since the "stretchers" in bastard bond serve merely to "set back" the headers behind them by half the length of a brick, they might more appropriately be termed "fillers.")

(v) In English bond, in any thickness of wall, for any given length and height, the number of half-bricks or false headers in the wall is a constant number.

(vi) In bastard bond the number of "fillers" or "stretchers" is also a constant. In each case, English or bastard, in any wall 4 bricks long and 4 courses high, the constant number of half-headers or of "fillers" is 16; in two courses, 8.

(vii) In English bond the overlaps are half a brick, and are formed at every possible opportunity, to secure strength by adhesion of mortar to sides as well as to flats of bricks. This is not the case in bastard bond, where flats alone are considered.

(viii) In true bond the stretcher bricks break joint on the faces of the walls. In bastard bond the stretcher joints fall vertically over one another, from base to summit of walls (*Figs. 3*).

Walls built in bastard bond seem from their faces to be built in alternate courses of headers and stretchers, but the similarity extends no deeper than the faces, every stretcher showing on the faces, and

every other brick in the wall being a header in a mass of other headers. In thick walls, as the Author is aware from experience, it is easy to lose the quarter-brick laps, in which case the longitudinal tie for many courses in succession might depend solely on the strength of the mortar joints. From a practical bricklayer's point of view, quarter-brick laps are not always reliable. With the rule of half-brick laps, a quarter-brick actual lap is a practical certainty.

Trial by number of Stretchers v. Headers.—Gwilt gives an example of a piece of walling, 4 bricks in length, 2 bricks thick, and 4 courses high. In English bond (*Figs. 2*) such a piece of brickwork would contain 32 stretchers, 24 whole-headers, and 16 half-bricks, or false headers. In Flemish bond (*Fig. 4*) there are 42 whole-

headers and 20 stretchers. From this example, Gwilt infers the superior strength of English over Flemish bond. Bastard bond, however, for the same wall (*Figs. 1*) would contain 48 headers to only 16 stretchers. These results are here tabulated :—

Bond.	English Two Courses.			Flemish Two Courses.			Bastard Two Courses.		Remarks.
	Stretchers.	Headers.	Half-bricks.	Stretchers.	Headers.	Half-bricks.	Stretchers.	Headers.	
Thickness of Walls.									
Bricks.									
1	8	8	..	12	6	..	8	8	The Flemish wall considered is $4\frac{1}{2}$ bricks long; the other two each 4 bricks long. It takes 4 courses to complete the true English bond; 2 courses each for bastard and Flemish.
$1\frac{1}{2}$	12	8	8	12	12	6	8	16	
2	16	12	8	12	24	..	8	24	
$2\frac{1}{2}$	20	16	8	12	30	6	8	32	
3	24	20	8	..	..	..	8	40	
$3\frac{1}{2}$	28	24	8	..	..	..	8	48	
4	32	28	8	..	..	..	8	56	
$4\frac{1}{2}$	36	32	8	..	..	..	8	64	
5	40	36	8	..	..	..	8	72	
$5\frac{1}{2}$	44	40	8	..	..	..	8	80	
6	48	44	8	..	..	..	8	88	

In comparing the numbers for each bond in the Table, it should be remembered that while the laps in English bond are all half-brick laps, the laps in bastard and Flemish bonds are quarter-brick laps. Bastard bond in thick walling is really "header bond."¹

Trial by Carpentry.—A carpenter is given a number of wooden blocks, say 9 inches by $4\frac{1}{2}$ inches by 3 inches thick, with instructions to form them into a narrow deep beam, to be laid on ordinary ground with a view to distributing loads placed along the top of the beam. He is to be allowed plenty of marine or other strong glue, but no nails or dowels, and he may only cut the blocks in the same manner that bricks are shaped in ordinary brickwork. If the man considers the matter carefully, he will probably employ the true or old English form of bonding, because it gives the glue the best and completest chance of doing its work of holding the blocks together.

See Note to Appendix.

Rankine's Theory of Strength of Brickwork.—Rankine gives¹ calculations for the strength of bond. He ignores the strength of the mortar, and relies on the frictional tenacity of the horizontal joints, the mortar being held to be green and unset. His calculations refer without doubt to an imperfect English bond, completed for header courses only, and but half completed for the stretcher courses, since he shows mathematically that "English" bond is only half as strong longitudinally as transversely. If his method of calculation be applied to the true or old English bond (*Figs. 2*) of alternate courses of headers and stretchers, the longitudinal strength will prove to be a little greater than the transverse strength in thin walls (owing to the presence of the half-bricks), while in very thick walls the strength both ways will be found to be equal. It is quite unnecessary, in true or old English bond, to employ two courses of stretchers to one of headers to obtain equal strength longitudinally and transversely. In this theory it is taken for granted that, however old or well-set the work may be, the mortar must never be depended upon to hold the bricks together. The strength of the bonding is calculated almost as if the wall were built with dry bricks, the coefficient of friction, f , being assumed to be the coefficient for brickwork laid in damp mortar, "which has not had time to acquire appreciable tenacity."

Whilst it cannot be denied that it is sound practice in calculating the stability of structures to ignore the tenacity and adherence of mortar, and to design as if resistances to loads and pressures were obtained solely by weight, mass, and friction, it seems to the Author to be unreasonable to ignore the mortar when calculating the internal strength of masonry or of brickwork. Concrete, for instance, depends for its very existence on the strength of the mortar binding the aggregate. All practical tests of strength of brickwork are made after the mortar is set. It is most unusual, and it is considered bad practice, to load green brickwork. If this principle be conceded, it follows that that form of brick bond is not necessarily the best which gives only the maximum frictional tenacity without reference to adherence of mortar to bricks.

Trial by Frictional Tenacity.—Rankine's calculations apply, therefore, to the case of bastard bond, which is one-half as strong longitudinally as transversely. Reliance being placed only on "frictional tenacity," no attempt is made to secure overlaps except in vertical planes, that is, in both sections. In plan, the bricks do

¹ W. J. M. Rankine, "Applied Mechanics." 5th ed., p. 222. London, 1896.

not break joint.¹ For all practical purposes, according to this theory, it is scarcely necessary that the vertical joints be filled with mortar. Yet the filling of the vertical joints is most necessary if adequate strength against shearing is to be secured.² Assuming that nothing but frictional stability is called into play, the bastard bond is perfect. But when other stresses occur, due perhaps to unequal settlement or to earthquake, it is found in practice that walls in bastard bond crack nearly vertically from top to bottom, and in every such case it will, on investigation, be evident, without doubt, that the crack or split was the result of a comparatively slight cause, and was due primarily to the inherent longitudinal weakness of the bastard bond.

Applying Rankine's theory to the true bond, it will be found that the half-brick overlaps secured in transverse bonding are also fully secured in longitudinal bonding. English bond is, therefore, at least as strong longitudinally as transversely.

Trial by Adhesion and Strength of Mortar.—Admitting that mortar will set in due time, that it will adhere to bricks, that no loads will be applied until the brickwork has had reasonable time to settle and to set; it follows that the best form of brick bonding is that which gives the mortar the best chance of holding the bricks together, and by which also the maximum frictional tenacity is obtained, whether the mortar be set or green. Of all possible forms of bond, the only bond which fulfils the above two conditions is true or old English bond. In this bond, which for thick walling cannot be improved upon, "tie" is secured in two ways. It contains not only the maximum number of half-brick overlaps on the flats of the bricks, offering resistance both by adhesion and by friction; but also, the maximum number of half-brick side laps, offering resistance by adhesion of mortar only.

With bricks, including joints, averaging 9 inches $\times$ 4½ inches $\times$ 3 inches, and correct half-laps, the area covered on the half-side of a brick is 4½ inches $\times$ 3 inches = 13½ square inches. On the half-flat it is 4½ inches $\times$ 4½ inches = 20¼ square inches. In old English bond, the longitudinal bond is perfect. Owing to the half-headers, the transverse tie in 1½ and 2-brick walls is 1 brick, or 2 (13½ + 20¼) = 67½ square inches of adhesion. In 2½ and 3-brick walls it is 2 bricks, or 135 square inches of adhesion. In 3½ and 4-brick walls it is 3 bricks or 202½ square inches of adhesion, and

¹ In Kempe's *Engineer's Year-Book*, 1906, p. 892, it is stated that "No stretchers occur, except those seen on faces of walls. No bricks in the same course should break joint with each other."

² Minutes of Proceedings Inst. C.E., vol. clxi, p. 330.

[THE INST. C.E. VOL. CLXXI.]

so on. The thicker the walls, the less the difference in strength, in longitudinal and transverse ties, in old English bond.

In good work, carefully laid, bastard bond has a longitudinal tie due to quarter-brick laps. In a 2-brick wall this is 2×9 inches $\times 2\frac{1}{4}$ inches = $40\frac{1}{2}$ square inches, as against $3 \times 4\frac{1}{2}$ inches $\times 3$ inches $+ 4 \times 4\frac{1}{2}$ inches $\times 4\frac{1}{2}$ inches = $121\frac{1}{2}$ square inches in old English bond. In a $1\frac{1}{2}$ -brick wall, the comparison is 1×9 inches $\times 2\frac{1}{4}$ inches $+ 1 \times 4\frac{1}{2}$ inches $\times 2\frac{1}{4}$ inches = $30\frac{3}{8}$ square inches as against $2 \times 13\frac{1}{2}$ $+ 3 \times 20\frac{1}{4}$ = $87\frac{3}{4}$ square inches. In a $2\frac{1}{2}$ -brick wall it is $50\frac{5}{8}$ to $155\frac{1}{4}$ square inches; and in a 6-brick wall, $121\frac{1}{2}$ to $391\frac{1}{2}$ square inches. The thicker the wall, the better the comparison in favour of the old English bond. Taking no account of the quarter-brick laps in header courses (as effective in old English as in bastard bond), the true English bond is at least three times as strong longitudinally as the bastard bond; or four times as strong, if the quarter-brick laps in old English bond are allowed for and added. The cross-tie in bastard bond is due to half-brick laps on flats of bricks only. Four courses must be considered as against two, so that bastard bond is 20 per cent. stronger transversely than old English bond, this result being attained, however, at a great sacrifice of longitudinal strength.

Some text-books enlarge on the importance of laying bricks so that every vertical joint in the course immediately below may be correctly covered. In the case of a thick wall, any arrangement of bricks with this end in view must, it is believed, fail; unless the bricks are of perfect shape and exact dimensions, and highly skilled bricklayers are employed. Quarter-brick laps alone being possible, the practical objection already urged against such small laps holds good. With a rule of half-brick laps, it may be reasonably expected that one-third, and at the worst one-quarter laps, will be secured. With a rule of quarter-brick laps, laps of from 1 inch to nothing, in the body of a wall, are probable, especially with careless or inexperienced bricklayers. If the argument be admitted, however, that quarter-brick laps can be always correctly laid, attention is invited to the reversed bastard bond illustrated in *Fig. 5*. The longitudinal strength of this bond is to the longitudinal strength of old English bond as 6:5; the transverse strength as 1:4. It may be asked, are engineers prepared to employ such a bond as this reversed bastard bond in all or any of their works? Yet this reversed bastard bond is practically the modern bond reversed in a heavy retaining or dock wall; that is, a bond designed for effective resistance in one direction only.

From this reasoning it seems clear that if the mortar is so poor that it possesses no strength or power of adhering to the bricks, all that can be relied on is frictional tenacity. If the mortar possesses any strength at all, and if it will bear any tensile stress, however small, it seems worth while to utilize this strength, and to pay attention to side-laps and to the proper filling of vertical joints in the brickwork.

The Bonding of Thin Walls.—There is little doubt that old English bond is unsuitable for walls of thicknesses between $1\frac{1}{2}$ bricks and $2\frac{1}{2}$ bricks, both inclusive, owing to the presence of half-heads. In $1\frac{1}{2}$ -brick walls they amount to one-sixth of the whole content of

Fig. 5.

the walls; in 2-brick walls to one-eighth; and in $2\frac{1}{2}$ -brick walls to one-tenth. Some other form of bonding must be sought for walls of $1\frac{1}{2}$, 2, and $2\frac{1}{2}$ bricks in thickness, and the Author believes this need is met by employing the "thin-wall bond" illustrated in Figs. 6, 7 and 8 inclusive. In this form of bonding it takes three courses to complete the bond, and it will also be noticed that while the longitudinal tie is due to bonding similar to the longitudinal bonding of old English bond, the cross-tie is that of the bastard bond. The longitudinal tie in a 2-brick wall is equal to the longitudinal tie of old English bond. The cross-tie in the same wall is two-thirds that of bastard bond, or 80 per cent. of the cross-tie of old English bond, making no

allowance for loss of strength caused by using half-headers. The thin-wall bond loses strength as the wall increases in thickness. It is, however, well adapted for circular walling, as its use does not

involve the cutting and shaping of bricks, or the employment of specially moulded bricks. The bond changes with every half-brick added to the thickness of the wall, and it is therefore considered

desirable (for use in circular walling) to give details up to 5 bricks thick. An imitation of the bond can be produced by inserting one entire course of stretchers between every pair of courses in bastard bond (Courses I and II) *Figs. 1*. This imitation is shown as “contractor’s bond” in *Figs. 9*, but is not recommended for important works, being weaker longitudinally than “thin-wall bond,” although less troublesome to lay.

It should be noted that the term “bastard bond” is applied by

Figs. 7.

practical bricklayers to any form of brick-laying not in a recognized bond. The Author submits that modern English bond is not only based on a wrong theory, but is opposed to true English bond in every important point, and is therefore a bastard bond. He contends that true old English or Roman bond is not merely a class or form of bond; but that it is an absolutely unchangeable bond, and there is only one correct way to lay it and to estimate its strength.

The Author believes that bastard bond is of comparatively recent

origin, dating probably in its present form from between the years 1870 and 1875. The only practical working bonds known to him are: (1) English bond, with its modifications, thin-wall, diagonal, herring-bone, garden-wall, and chimney bond; and (2) Flemish bond. Bastard bond cannot be admitted as a recognized bond, and the

Figs. 8.

Author has never accepted it as such, regarding it as an unsound and unscientific innovation.

Practicability.—The most important point remains to be considered. Many engineers object to a bond of more than two courses as being impracticable. It takes four courses to complete

true English bond, by reason of double lapping, sides and flats of bricks. This is inevitable. If work is always closed on a header course, and if the put-log holes are invariably the result of omitting false headers, or half-bricks, as they should be, it is not easy to see how laps or flats in header courses can be lost. Mistakes cannot be made in stretcher courses, as the first row of stretchers in each

Figs. 9.

AND SO ON, UP TO ANY DESIRED THICKNESS.
NO HALF-BRICKS NECESSARY
NOTE: THREE COURSES COMPLETE THE BOND.
CONTRACTORS BOND

(Note.—1st and 4th courses to break joint as in true English bond.)

course shows plainly on face of wall, and is a key to the rest and to the courses above and below. Mistakes are impossible in thin-wall and contractor's bonds, as can be shown by models of bricks.

The Paper is accompanied by 18 sheets of diagrams from which the Figures in the text have been selected, and by the following Appendix.

APPENDIX.

THE STRENGTH OF BRICK BOND.

1. Walls are generally called upon to resist only two extraordinary dislocations, viz., (i) splitting into thicknesses, and (ii) cracking vertically or diagonally through the entire thickness of the wall.

2. Resistances to splitting and cracking depend on the same sources of strength, and may be considered together. The sources of strength are—(a) “frictional tenacity” (Rankine, “Applied Mechanics”), and (b) the adhesion of the mortar which holds the bricks together. Rankine ignores (b) altogether, but nevertheless the adhesion of the mortar to the bricks is a most important consideration in the strength of walls. Rankine, in making his calculations, assumes the mortar to be still soft and unset, with the result that his reasoning is inexact, and gives an unfair basis of comparing the strengths of the various bonds in use.

3. Frictional tenacity is illustrated by the following diagram (elevation) :—

One brick rests lengthwise and “dry” on two, which rest “dry” in turn on three, placed on the ground to form a half-brick wall, the laps, a b , being half-brick laps, say $4\frac{1}{2}$ inches $\times$ $4\frac{1}{2}$ inches. W represents the superincumbent load, P any force tending to pull the brick S out of place. If the shaded brick T be now removed, the resistance to P is that due to friction on two half-brick laps = friction on areas 2 inches $\times$ $4\frac{1}{2}$ inches $\times$ $4\frac{1}{2}$ inches = $40\frac{1}{2}$ square inches. If S be now considered as cemented into the half-brick wall, the illustration is complete.

4. Adhesive tenacity is illustrated by the following plan :—

Here X and Y are firmly cemented together on joint c d , measuring say $4\frac{1}{2}$ inches $\times$ 3 inches, and A and B are cemented in turn to X and Y by half-brick laps,

measuring each also $4\frac{1}{2}$ inches by 3 inches. If forces = P_1 are now applied to pull X and Y apart lengthwise, the adhesion of the cementing matter to the bricks offers resistances on areas aggregating 3 inches $\times$ $4\frac{1}{2}$ inches $\times$ 3 inches = $40\frac{1}{2}$ square inches.

5. If a brick is built into a wall in such manner that half its length projects, the power, P, to pull it out must be greater than the combined resistance due to frictional tenacity and to adhesive tenacity, as described above. If the wall has taken its final settlement, and the mortar has thoroughly set, it will be found that the total resistances are probably all due to adhesive tenacity only, that is, due to the adhesion of the mortar to 81 square inches of surface. This is the theory of strength of true or old English bond, and to this end all specifications regarding the wetting of bricks, the keeping damp of brickwork, and the full flushing up of all joints with sound mortar are framed.

NOTE.—The Author has since ascertained that bastard bond is actually a header bond, of the alternate header courses of a form of bond still occasionally used in Sussex, and illustrated and referred to in *Indian Engineering*, vol. xlii (1907), pp. 7, 77 and 124. While true English bond (*Figs. 2*) may be called the English bond of the half-brick laps, "Sussex" bond might be termed the English bond of the quarter-brick laps.