metal, the mortar will be empty, but if it contains only a small quantity of such a metal, there remains at the bottom of the mortar, shining flat spangles of the metal, if the metal was easily fusible and malleable; but a metallic powder if the metal was hard to be fused or not very malleable.

In this manner we may very plainly detect one-half per cent. of tin, and a still less proportion of copper in a mineral; if several metallic oxides are contained in the same mineral, they are generally reduced together to an alloy, sometimes separate reguli of each mineral are given.

The metals which in this manner may be reduced are molybdenum, antimony, wolfram, tellurium, copper, bismuth, tin, lead, zinc, nickel, cobalt, iron, silver and gold. Among these are some which are either totally, or in part, volatilized, and cover the coal with their oxides; to these belong antimony, tellurium, bismuth, lead and zinc: arsenic, cadmium and quicksilver are also reduced with soda, but are again immediately volatilized, and can only be obtained in a metallic form by sublimation with soda in glass tubes.

If, in reducing with soda, a metallic regulus is obtained, which is an alloy of several metals, it must be handled with borax or phosphate of soda, in the manner already described.

To be Continued.

On the Ores used at Freiberg.—Translated from the German of C. A. Winkler. By THEO. F. MOSS, Mining Engineer.

At present between 180,000 and 190,000 cwt. of ore are used yearly at the works of Freiberg; of which from 60 to 70,000 cwt. are used in the amalgamation works, and the rest worked up in the furnaces.

With few exceptions all the ores are brought from the numerous mines of the Freiberg mining district, and are in a powdered form.

These ores are, in relation to their component parts, of great variety. The quantity of silver in a cwt. of ore, varies from 0 to many 100 ounces in the cwt., and some of them are of the richest description of silver ores, but the average amount is between 2 and 3 ounces to the cwt.

Some of the ores are more or less rich in lead, but the quantity of lead ores which contain more than 30 per cent., is hardly $\frac{9}{100}$ of the whole mass of ore; copper ores which contain several pounds of copper in the cwt. are but few; but traces of copper are found in most of the ores, therefore the silver from the amalgamation process always contains some copper, although the copper ores are never at Freiberg, used in the amalgamation works. About 14 to 18 per cent. of the whole quantity of ore is either poor in silver, or totally free of it, and is iron pyrites, used in the first smelting process.

The other component parts of the Freiberg ores are very various, as is to be expected from the various and numerous veins from which the ores are brought. The ordinary mixtures are quartz, hornstone

jasper, heavy spar, and calcareous spar; fluor spar, on the other hand, is at present but seldom met with. Iron pyrites is common, but is not at hand in sufficient quantities to supply the necessary addition for the first smelting; some of the ores contain a great deal of zinc, antimony or arsenic, and iron ochre and carbonate of iron are found in greater or less quantities.

The Freiberg ores belong, on the whole, to that class of ores which are with difficulty smelted, and the most infusible kinds are those which are composed in most part of quartz or heavy spar.

It is worthy of mention that some gold is found in most of the Freiberg ores, and appears to be contained in the pyrites. The percentage of gold is, however, so trifling, that it would not cover the cost of separation. A small profit would accrue from separating the gold from the silver obtained by the smelting process from some varieties of the pyrites, were it not found more profitable to use these ores in the amalgamation, when most of the gold is lost in the reviving process (*unquickprozess*) without being concentrated in the silver amalgam.

The ores used in the amalgamating works must neither contain lead nor copper. Lead would make the amalgam impure, and the lead would be lost in the residuum; copper ores by the Freiberg amalgamation process would cause the silver to contain too much copper, and much of the copper would also be lost in the residuum.

Therefore, the ores which are used for the amalgamation (*verquickung*) contain as little lead and copper as possible, and from 3 to 4 ounces silver to the cwt. of ore, but at the same time sufficient pyrites for the decomposition of the salt used.

All other description of ores, whatever may be the proportion of silver, lead, copper or pyrites, are given over to be smelted at the furnaces.

Experiments and Observations on Muser's Discovery, proving the Effect is neither due to Light nor Heat. By HORATIO PRATER.

(Continued from Page 72.)

6. *As regards Impressions on Glass.*—We have already observed that heat does not seem to increase the effect of *metal* coins on glass. Neither did *long contact*; for a fourpenny piece, left a *week* on a piece of looking-glass, only left the usual spectrum, no *figure* being visible. The same remark applies to large *printed* letters. At least, some paper with these, after remaining pressed two or three days without giving any impression, was then heated for five hours, so pressed, at about 160°, but no impression was made. On another occasion, print and writing were left a week on a glass mirror without leaving an impression. When, however, thinner paper and larger letters were used, and heat and pressure applied as above for four or five hours, these letters were plainly visible; but, as appeared to me, far more easily erased than were the spectra of coins on copper plates.* A

* On a copper plate also this *thin paper* (not being well dried first) gave a permanent and very visible spectrum, the lettering being clearer than on glass: not due to oxidation, &c.