(Paper No. 2331.)

“Stress-Diagrams of Solid Structures.”

By PROFESSOR ROBERT HENRY SMITH, Assoc. M. Inst. C.E.

So far as is known to the Author, the modern graphic method of finding stresses has been applied to flat structures only, although, so long as the method is thus restricted, it deals incompletely and imperfectly with actual problems. No structure can have sufficient lateral stability against lateral forces unless its lateral dimensions be large in proportion to these upsetting forces. The two side-girders of a bridge stand only because they are connected by cross-girders and wind-bracing. Every engineering structure of importance must be treated as a solid structure, in order to arrive at a true knowledge of the stresses acting throughout it.

The more important mathematical differences between the two-dimensional and the three-dimensional problems are as follow :—

If l represents the number of links and j the number of joints, then, in a flat, stiff, but non-redundant structure, the relation between these numbers is

$$l = 2j - 3.$$

In a solid, stiff, but non-redundant structure, the corresponding relation is

$$l = 3j - 6.$$

These rules apply only to structures in which each link has two joints only, and is stressed only along the line joining these two joints. A simple modification of the meaning of the formula, however, makes it applicable to structures containing beams; that is, links whose transverse sections are subjected to shear forces and bending moments. The modification is that each beam is to be counted as one link only, no matter how many joints it contains, and that in counting the joints only two occurring in any beam are to be included in the reckoning.

For stable equilibrium, the plane structure requires at least two supports, while the solid structure must rest on its foundation at at least three places.

In a plane structure, supported at two places, the condition of force- and moment-balance is sufficient to determine the two magnitudes of the supporting forces and the direction of one of them only; the direction of the other (or what comes to the same thing, the magnitude of the abutment thrust) being determined by conditions irrespective of the balance of the load.

In a solid structure, secured to a base at three places, the condition of force- and moment-balance of the loads is sufficient to determine six only of the elements defining the three supporting forces; for instance, the three magnitudes and the three directions in elevation. The three directions in plan must, in this case, be determined independently of the condition of equilibrium. If there be four supporting forces, from this condition the four magnitudes and two directions, either in plan or elevation, can be calculated.

In what follows, the structure is represented in plan and elevation, and the stress-diagram is also shown by help of plan and elevation. To these is added what may be called a "composition diagram," in which the components of stress, found by means of the plan and elevation, are combined into total or resultant stresses.

Bow's notation of the diagrams is used. Here, as in plane problems, the letter-names are given to surfaces or superficial polygons bounded by the links. These polygons are called "pens." Capital letters and numbers are given as names to the pens in the frame-diagram, and corresponding small letters and numbers to the corresponding points in the stress-diagrams.

In building up a stress-diagram, a certain cyclic order must be adhered to throughout the whole construction, the stress-lines being arranged in the stress-polygon for each joint in the same order as that in which the links are met in making a circuit round the joint. This may be either left-handed or right-handed cyclic order, there being two different possible stress-diagrams, which are the exact reverse of each other. In plane problems there is no difficulty in following this rule. In the solid construction, however, the pens, which may lie clear of each other in the plan, generally overlap each other in elevation; and the cyclic order in which the lines of the forces acting at a joint are cut, in making the (say) right-handed circuit of the joint in plan, is not usually the same as that in which they are cut in making the circuit of the same joint in elevation. Since the pens generally lie clearer of each other in plan than in elevation, they are here lettered in plan. The bar separating any two plan-pens, C and D is called CD, and

along this bar in elevation is written CD. The cyclic order for each polygon in the stress-diagram is obtained by reference to the plan alone, and in elevation the stresses follow each other in the same order as in the plan.

To shorten the written description of the construction of diagrams, the following system of writing out the process is employed.

To express "from the two known points d and e , draw two lines parallel to DG and EG, and mark their intersection g ," the symbol " $\begin{matrix} d \\ e \end{matrix} > g \parallel \begin{matrix} DG \\ EG \end{matrix}$ " is used. But it is understood that the general rule is to draw dg in stress-diagram parallel to DG in frame-diagram, and eg parallel to EG. This symbol is, therefore, contracted to " $\begin{matrix} d \\ e \end{matrix} > g$ " simply when this general rule is to be followed. But when the rule has to be departed from; if, for instance, dg were to be drawn parallel to QP and eg parallel to RT the full symbol " $\begin{matrix} d \\ e \end{matrix} > g \parallel \begin{matrix} QP \\ RT \end{matrix}$ " is written in.

Constructions in plan are prefixed by (π); those in elevation by (ϵ) or by (σ), which latter means "side elevation."

When a point has been found in the plan stress-diagram, the corresponding point has often to be found in elevation by projecting vertically upwards from plan to elevation, or *vice versa*. To express "find point l in elevation by drawing from point m , already known in elevation, a line parallel to ML in elevation, and by projecting vertically upwards on to this line from the point l , already found in plan," there is employed the symbol " $m \uparrow l$." The converse process of finding l in plan, from its already found elevation, is written " $m \downarrow l$." If the line to be drawn in plan from the known point m is to be parallel, not to ML, but to NQ, the construction is written " $m \downarrow l \parallel NQ$." This latter symbol, however, is seldom needed.

To express "find point f by plotting from h (already known), the line hf equal and parallel to no (also known)" there is used the symbol " $h f \# n o$."

Again " $k l \# s t$ " means "plot from the known point k the line kl equal and opposite to st ."

Plate 12, Fig. 1, represents the simplest possible solid structure, namely, a tetrahedron. It has four joints and six bars, and therefore fulfils the condition of stiffness and non-redundancy, $l = 3j - 6$, or $6 = 3 \times 4 - 6$.

The construction is shown in its most general form. By taking

special planes of projection it may be made easier, but would then illustrate the method only imperfectly.

ABC and $A^1B^1C^1$ are any two projections of the frame on two planes at right angles to each other. GG is taken as ground line. The names $A B C$ are given to the plans of the three upper faces of the tetrahedron, and **1, 2, 3, 4**, to the plans of the outside spaces bounded by the plans of the frame and of the external-force lines. No name is given to the lower face of the tetrahedron. The plan now assigns a name to each link and external-force line. The left-handed cyclic order has been followed in this diagram. In the elevation, accented letters are used to distinguish them from the plan letters, but this distinction will be found unnecessary in subsequent examples.

It is to be noted that, in plan, the joint at which the force **12** acts lies inside the boundary of the structure. An imaginary link B_1B_2 , and an imaginary joint **1** B_1B_2 **2** have to be introduced in consequence, the force **12** being supposed to act at the imaginary joint **1** B_1B_2 **2**.*

The data for the problem are the dimensions of the structure; the point of application, the direction and the magnitude of the load **12**, $1'2'$; the direction in both plan and elevation of the supporting force $34, 3'4'$; and the direction of the elevation of the supporting force $2'3'$.

At each soluble joint of a solid structure there act, first, a number of known forces that can be compounded into one known resultant, and, second, the three unknown stress-forces exerted by three links whose stresses have not been determined. The top joint of Fig. 1 is therefore typical of the general problem.

The mode of solution is to resolve the known force into two components, one perpendicular to the plane of any two of the unknown forces, and the other parallel to this plane. The third unknown force being imagined similarly resolved into two components perpendicular and parallel to the same plane, it is clear that its perpendicular component must be equal and opposite to the perpendicular component of the known load. If, therefore, there be plotted from the joint along the line of the known force a length representing that force to scale; and if from the end of this

* This device means nothing more than that in the stress-diagram the line representing force **12** appears twice under the two names **12** and b_1b_2 , and that the line representing the stress along bar $1B_1$ or B_22 , also appears twice under the two names $1b_1$ and b_22 . The repetition cannot be avoided when "external forces" are applied at "internal joints."

line be drawn another line parallel to one of the three "unsolved" links, to meet the plane of the other two, then the length of this line, measured to its intersection with this plane, will represent the stress along the parallel link, the scale being the same as that to which the known force has been plotted. This second force being thus found, the remaining two can be determined at once by closing the polygon by lines parallel to the links exerting them.

In Fig. 1 the force 12 is plotted to scale from the joint to the point ff^1 in plan and elevation, and from ff^1 is drawn a line parallel to AB , A^1B^1 to intersect the plane of AC , BC . The intersection is lettered $q q^1$, and is found as follows:—The vertical and horizontal traces of the plane AC , BC , are found in the well-known manner. They are marked in the diagram $V_{AC, BC}$ and $H_{AC, BC}$. Through f and f^1 are now drawn lines $f q$ and $f^1 q^1$ parallel to AB and A^1B^1 . These are plan and elevation of the line through ff^1 parallel to AB , A^1B^1 . The plan $f q m n$ is also the plan of the line of intersection of a vertical plane through this same line and the plane AC , BC . The plan cuts $H_{AC, BC}$ in a point m , whose elevation is m^1 on $G G$. This is one point in the intersection just mentioned; it is the point where this intersecting line cuts the horizontal plane. Similarly the point where it meets the vertical plane is n on $G G$, whose elevation n^1 is found on $V_{AC, BC}$. Thus $m^1 n^1$ is the elevation of this intersecting line. Since $q q^1$, the point sought, lies in this line of intersection, therefore, if $m^1 n^1$ be produced to meet $f^1 q^1$ in q^1 , and q on $f q m$ be obtained by vertical downward projection from q^1 ; $q^1 q$ is the point where the line $f^1 q^1$, $f q$ through point $f^1 f$ parallel to $A^1 B^1$, AB meets the plane of AC , BC . Thus $q f$ and $q^1 f^1$ are the plan and elevation of the stress on the bar AB , $A^1 B^1$.

In the elevation and plan stress-diagrams are now plotted—

$$a b_1 \# q f \quad a^1 b_1^1 \# q^1 f^1 \quad b_1 b_2 \# 12 \quad b_1^1 b_2^1 \# 1^1 2^1$$

and the points c and c^1 are obtained by drawing

$$(\pi) \frac{b_2}{a} > c \parallel \begin{array}{c} B_2 C \\ A C \end{array} \quad \text{and} \quad (\epsilon) \frac{b_2^1}{a^1} > c^1 \parallel \begin{array}{c} B^1 C^1 \\ A^1 C^1 \end{array}.$$

The point a^1 having been chosen vertically over a , the points $b_1^1 b_2^1 c^1$ will be found exactly above $b_1 b_2 c$ if the drawing be accurate. This is a useful check. It may at once be said that it requires the most careful possible draughtsmanship to maintain

accuracy throughout a complicated solid stress-diagram; and that it is practically impossible to get it to "close," at the final polygon, unless throughout the whole construction the accuracy of the drawing be continually checked, by making sure that every point in elevation is exactly over its plan. The only satisfactory way to do this is to draw one, two, or three (according to the size of the diagram) lines across the paper very accurately vertical, and to measure horizontally with the dividers from each pair of points to one or other of these lines.

Next in plan, from joint (C 34 A) along AC to p , is plotted a length = ac . Through p so found, and its elevation p^1 , is drawn a line parallel to 34, 3¹4¹, these directions being among the data. The intersection of this line with plane C3, 4A, is next found. This involves the finding of the traces of this plane. They are ascertained as in the previous case, and are marked $V_{C3, 4A}$, and $H_{C3, 4A}$, and the intersection, found as before, is marked rr^1 . Then rp and r^1p^1 are the projections of the supporting force 34. From r and r^1 are drawn $rs \parallel A4$ and $r^1s^1 \parallel A^14^1$ to meet C3 and C¹3¹ in s and s^1 . Then rs, r^1s^1 is the stress on 4A, 4¹A¹; and the lines from s, s^1 to the joint (C 34 A) give the stress on C3, C¹3¹. The polygon of stress for this joint is thus completed; but as it is not in correct cyclic order, it has to be rearranged in inserting it in the stress-diagram. It there appears as $ac34a$ and $a^1c^13^14^1a^1$.

Next for the joint (23CB), the two forces exerted by the bars 3C and CB are already known, and as the directions in elevation of the two others are known (2¹3¹ in direction being among the data), the polygon can at once be completed in elevation by drawing

$$(\epsilon) \quad b_2^1 > 2^1 \parallel \begin{array}{l} B^1 2^1 \\ 3^1 2^1 \end{array}.$$

Then in plan 2 is found by

$$(\pi) \quad b_2 \nabla 2.$$

Plan 2 is now joined with 3, the second supporting force 23, 2¹3¹ having been now calculated.

Next the stress parallelograms in plan and elevation for the imaginary joint (12 B₂ B₁) are drawn in; thus—

$$\begin{array}{l} b_1 > 1 \parallel \begin{array}{l} B1 \\ 21 \end{array} \quad \text{and} \quad b_1^1 > 1^1 \parallel \begin{array}{l} B^1 1^1 \\ 2^1 1^1 \end{array}.$$

It only remains to join points 4 and 1, 4¹ and 1¹. These give the

remaining supporting force; and it will be seen that the diagram for the joint at which this force acts is complete.

It should be noticed that, in this example, there does not occur at the end of the construction the usual check of the accuracy of the work customary in plane diagrams. The tests mentioned above, regarding pairs of points being vertically above and below each other, are only partial, and would not reveal any miscalculation of the supporting forces due to wrong method, &c.

The absence of this check is due to the case not being perfectly general. The known load applied to the structure is here represented by a single force. In the general case the group of known forces is incapable of being reduced to a single equivalent force. It may be reduced to one force plus a force-couple; but this reduction is not a convenient one for the present purpose. Another mode of reduction is to two non-intersecting forces perpendicular to each other. For the present, as well as for other purposes, this latter reduction is more convenient because, in making it, one of the two forces may be taken in any convenient direction. The whole set of forces is reduced to one force lying in a certain plane (which may be chosen as any whatever) and a second perpendicular to this plane.

As this mode of reduction is not mentioned in books, the convenient graphic mode of effecting it is shown in Fig. 2. Here three rectangular planes of projection are represented by (π) , (ϵ) , and (σ) , or "plan," "front," and "side elevation." The individual forces of the system to be dealt with are to be represented in projection on each of these views. Each set of projections is to be compounded into a single resultant by the ordinary well-known graphic method. These three resultants are marked ρ_π , ρ_ϵ and ρ_σ . Now the whole group of forces may be looked on as equivalent to ρ_π parallel to the horizontal plane and the vertical component (parallel to $O V$) of ρ_π or ρ_ϵ . Calling this vertical component ρ_v ; calling the component of ρ_π or ρ_ϵ parallel to $O E$ (say east) ρ_e ; and that of ρ_π or ρ_σ , parallel to $O S$ or $O S^1$ (say south) ρ_s ; the system may also be resolved into ρ_e along with ρ_v , or into ρ_σ along with ρ_e . To determine the relative positions in which these forces must be taken, suppose ρ_π to act (horizontally) at the level $a b$; draw $a d \perp O E$, and plot on this line the point d at the same distance from $O E$ that b stands from $O V$. Then the whole system is equivalent to ρ_π taken at the height $b a$, and ρ_v acting along the vertical line whose plan is d . The position of d depends on the height chosen for ρ_π . Draw $d d^1 \parallel \rho_\pi$; then $d d^1$ is the locus of the possible positions of d .

Similarly, if f and e are taken on ρ_π and ρ_σ at equal distances from $O E$ and $O V$, and if $eg \perp OV$ and $fg \perp OE$; then the system is also equivalent to ρ_e taken in an east-vertical plane through f or e , together with ρ_s (the southward component) taken through point g . If $gg^1 \parallel \rho_e$, then gg^1 is the locus of possible positions for g , corresponding with ρ_e taken at different distances south of the vertical plane OE . Again, from any point i in ρ_e are drawn $ih \perp OE$ and $ik \perp OV$, and the point k is placed at a distance from OV equal to that of h from OE . kk^1 is drawn $\parallel$ to ρ_σ . Then k is the position at which ρ_e (the east component) must be taken along with ρ_σ taken in the south vertical plane through i or h , in order that these two may be a correct equivalent for the whole system of given forces. kk^1 is the locus of k .

Fig. 3 shows the general method of finding three unknown supporting forces of a solid structure. The points of application $\alpha\alpha^1$, $\beta\beta^1$ and $\gamma\gamma^1$ of these forces are supposed to be known both in plan and in elevation. The directions in plan **34**, **45** and **51** are also taken as known. The loads on the structure have been compounded in three rectangular projections to ρ_π , ρ_e and ρ_σ . On ρ_e any point δ^1 is chosen, and from it by the construction of Fig. 2 is found δ in (π) , such that the whole set of loads is equivalent to ρ_π at the level of δ^1 , and the vertical component of resultant load ρ_e through δ . Next draw $\delta\lambda \parallel \rho_\pi$ to meet $\alpha\gamma$ (any side of the triangle $\alpha\beta\gamma$) in λ . Project upwards from λ to λ^1 on ρ_e . The whole set of loads is now taken as equivalent to ρ_π at the height λ^1 and ρ_e at λ . Draw $\lambda^1\theta^1$ horizontal and take on it θ^1 directly over θ , the intersection of ρ_π and $\alpha\gamma$. A linkage with the five joints $\alpha\alpha^1$, $\beta\beta^1$, $\gamma\gamma^1$, $\lambda\lambda^1$ and $\theta\theta^1$ is imagined erected on the base $\alpha\beta\gamma$, with the force ρ_e applied at the joint $\lambda\lambda^1$, and the force ρ_π applied at the joint $\theta\theta^1$. The face $\gamma\alpha\lambda\theta$ (including two triangular pens) is vertical, and is represented in plan by a single line; but to give opportunity for distinct lettering, the base link $\alpha\gamma$, and the oblique link $\lambda\gamma$ are shown in plan by curved dotted lines (drawn at random). In plan, also, the vertical force-line of ρ_e is shown by a finite dotted line from λ with an arrowhead attached, although its real projection is a point only. The links are $9 = (3 \times 5 - 6)$ in number, and are named **5C**, **CB**, **BA**, **A4**, **CD**, **BD**, **AE**, **DE**, and **E** (**1, 2** or **3**). The pen **D** is divided in two parts by ρ_π , and **E** into three parts by ρ_π and ρ_e (in plan).

The horizontal components of the forces ρ_π , or **12**, **34**, **45** and **51** must balance among themselves. Therefore the lines **45** and **51** are produced to meet in ν and ρ_π , and **34** to meet in μ ; and $\mu\nu$ is joined. Then the resultant of ρ_π and **34** must lie along the line $\mu\nu$

and that of 4 5 and 5 1 also along the same line, because these two resultants balance each other.

In the plan stress-diagram draw

$$(\pi) d_1 d_2 \nparallel \rho_\pi \quad \begin{array}{c} d_1 \\ d_2 \end{array} > 4^1 \parallel \begin{array}{c} \nu \mu \\ 3 \ 4 \end{array} \quad \begin{array}{c} d^1 \\ 4^1 \end{array} > 5^1 \parallel \begin{array}{c} 1 \ 5 \\ 4 \ 5 \end{array}$$

Then $d_2 4^1$, $4^1 5^1$ and $5^1 d_1$ are the plans of the three supporting forces sought, namely **3 4**, **4 5** and **5 1**.

In the rest of the construction the right-handed cyclic order has been followed.

For the balance at joint θ , since the plane D B and C D is vertical, the resultant of the two forces exerted by these bars is in plan along the line $a \gamma$. Therefore, draw

$$(\pi) \begin{array}{c} d^1 \\ d_2 \end{array} > c^1 \parallel \begin{array}{c} D \ C \\ B \ C \end{array} \quad \text{Then in } (\epsilon) \text{ draw } d_1 d_2 \text{ horizontal, and place } d_1 d_2 \text{ in } (\epsilon) \text{ directly over } d_1 d_2 \text{ in } (\pi), \text{ so that } d_1 d_2 \text{ in } (\epsilon) \text{ represents the elevation of the known force } \rho_\pi \text{ acting at } \theta^1. \text{ Then draw}$$

$$(\epsilon) d_2 \uparrow c^1 \parallel B \ C.$$

Thus $d_2 c^1$ in (π) and (ϵ) represents the force exerted by link B C at joint θ . Next draw

$$(\epsilon) \begin{array}{c} d^1 \\ c^1 \end{array} > c \parallel \begin{array}{c} D \ C \\ D \ B \end{array} \text{ and } c \ b \nparallel c^1 d_2. \text{ This gives } b \text{ in the line } d_1 d_2, \text{ because link D B is horizontal, and, therefore, parallel to } d_1 d_2. \text{ Next draw}$$

$$(\pi) d_2 \downarrow b \parallel D \ B \text{ and } d_1 \downarrow c \parallel D \ C. \text{ Join } b \ c. \text{ This gives } b \ c \nparallel d_2 c^1 \text{ if the drawing has been accurate. The stresses in the three bars D B, B C and C D are now given in } (\pi) \text{ and } (\epsilon) \text{ by } d_2 b, b \ c \text{ and } c \ d_1.$$

At joint λ the bar A B has no stress in it, because the other three forces lie all in one (vertical) plane. In both (π) and (ϵ) , therefore, a is marked coincident with b , and then

$$(\epsilon) d_2 e_1^1 \nparallel \rho_e \quad \begin{array}{c} e_1^1 \\ a \end{array} > e_3 \parallel \begin{array}{c} D \ E \\ A \ E \end{array} \quad e_3 e_2 \nparallel \rho_e. \text{ Join } e_2 d_2. \text{ This gives } d_2 e_2 \nparallel e_1^1 e_3.$$

$(\pi) a \downarrow e_3$, and e_2 coincides with e_3 , because $e_2 e_3$ or ρ_e is vertical. The polygon for this joint is now complete in both (ϵ) and (π) , viz., $a \ b \ d_2 \ e_2 \ e_3 \ a$. (By accident the point $(\epsilon) e_2$ falls on line $c \ b$.)

For joint α draw

$$(\pi) \begin{array}{c} a \\ 4^1 \end{array} > 4 \parallel \begin{array}{c} A \ 4 \\ A \ E \end{array} \quad 4 \ 3 \nparallel 4^1 d_2. \text{ This gives } 3 \text{ on line } e_3 d_2, \text{ which line must be produced to } 3. \text{ Then draw}$$

$$(\epsilon) e_3 \uparrow 3 \quad a \uparrow 4. \text{ Join } 3 \ 4.$$

The polygon $a e_3 3 4 a$ for this joint is now complete in both (π) and (ϵ) .

For joint β draw

$(\pi) 4 5 \parallel 4^1 5^1$. Join $c 5$. If the drawing has been accurate $c 5 \parallel C 5$. Draw $(\epsilon) c \uparrow 5$. Join $5 4$. The diagram $c b a 4 5 c$ for this joint is now finished.

Next plot—

$(\pi) 5 1 \parallel 5^1 1^1$. Join $1 3$ and mark 2 coincident with 3 .

$(\epsilon) 3 2 \parallel \rho_v 2 \uparrow 1$. Join $5 1$.

There are now obtained the elevations $3 4$, $4 5$ and $5 1$ of the three supporting forces sought for, which are therefore completely known. As a check, the diagram for joint γ should be finished by drawing $(\pi) e_2 e_1 \parallel d_2 d_1$. Join $e_1 1$ which should lie on line $c d_1$. $(\epsilon) 1 \uparrow e_1$. Join $e_1 d_1$ which should be parallel to $E D$. It will also be found that there are three parallelograms, showing the balance at the three imaginary joints ($2 3 E_3 E_2$), ($1 2 E_2 E_1$) and ($E_1 E_2 D_2 D_1$).

In the "composition diagram" the external forces alone have been shown. From any point O^1 are plotted horizontally the plans of these forces, and vertically the vertical components only (not the elevations), these latter being obtained from (ϵ) . Both points thus obtained for each force are marked with the proper name of the force; for example, the diagonal distance between the two points marked $4 5$ gives the total magnitude of this force. The inclinations of these diagonal lines, to the horizontal line through O^1 , also give the actual inclinations of the force-lines to a horizontal plane. The dotted diagonal from $1 2$ to $2 3$ gives the magnitude that the resultant load would have if it were capable of being looked on as a single force; it being, however, incapable of being properly so regarded.

Of course, any other imaginary link-work on the base $a \beta \gamma$, and with two other joints in any of the possible lines in which ρ_π and ρ_v may be taken, would also serve to find graphically the three supporting forces; but the choice of this particular one here used saves labour, because the traces of planes have not to be found by special construction, and because $a b = 0$.

Fig. 4 shows a complete example of the application of these methods. The structure is a pier on a rectangular base. The dimensions are not taken from any actual pier, but have rather been chosen so as to make this illustrative example not difficult to read; that is, so as to give, as far as possible, the plan-pens clear of each other.

At the top joints four known vertical forces, $A_1 A_2$, $A_2 A_3$, $A_3 A_4$,

and A_1A_1 act. At two of these top joints and four other joints at one side, transverse forces act, which may be looked on as compounded of weights and wind-pressures. These are all known, and are here taken as equal, but no use is made in the construction of their equality. The holding-down force **78** at one of the corners of the rectangular base is also supposed to be completely known. The plan directions of the other three foundation reactions are also among the data.

The structure is shown in plan, front and side elevation. The latter is only used for finding the unknown reactions at the base.

The known forces are plotted off in plan, front and side elevation force-diagrams in the consecutive (right-handed) order shown, giving the three unclosed polygons—

$$a_1 \ a_2 \ a_3 \ a_4 \ 1 \ 2 \ 3 \ 4 \ 5 \ 6 \ 7 \ 8.*$$

These give three lines a_1 8, which are the vector projections ρ_π , ρ_e and ρ_σ . The positions of these are found by choosing three poles, and parallel to the three pencils of lines from these, drawing three simple link-polygons, or "single-pens," through the spaces between the force-lines in the three views. Then the construction of Fig. 3 is applied to find the forces 8 9; 9, 10; and 10, 1 exerted by the foundation. Two of these are directed upwards; the third, 10, 1, has a downward component, that is, the side forces shown will throw the holding-down bolts at this corner into tension.

The values found for these three forces are next checked by completing the three above-mentioned dotted single-pens, including the three newly-found forces. If they be found accurately, all the three single-pens will close perfectly. (In the example here shown the closure error in one of them was about 0.01 inch, and in the other two was nil, or less than the breadth of a fine line, the scale of the original drawings being 1 inch = 16 tons for the stress-diagram, and 1 inch = 5 feet for the frame diagram.)

Of the three polygons in the stress-diagram showing the balance of the external forces, the dotted one, or that in "side-elevation," is used no further.

It should be noted that in the elevations of the structure, although it is an "open" linkage, those links on the hinder surfaces are shown in dotted lines to distinguish them from those in front. Similarly in plan, two links are shown by dotted lines,

* The necessity of reducing the drawings to the admissible size of plate has led to the side elevation being shown above instead of beside the front elevation, and also to the frame and stress diagrams being placed on two separate plates. This inconvenient arrangement was unfortunately unavoidable.

namely, two horizontal diagonal bracing bars, one from joint (W X Y Q P O, &c.) to joint (L K J R S, &c.), and the other from joint (7 8 W, &c.) to joint (X 9 10 S, &c.). There are sixteen joints and forty-two links, this making the pier stiff and non-redundant.

The space A is divided into four spaces, in order that there may be names for the four vertical loads applied at its corners. In the plan stress-diagram, of course, these four forces are all represented by one point, namely, *a*.

A sort of gap or hiatus in the elevation diagram makes it necessary to repeat the points *a*₁ *i h p q y*. They are thus marked in the upper part, and *a*₁ *1¹ i¹ h¹ p¹ q¹ y¹* in the lower part of the elevation diagram. This hiatus is due to the external forces *A*₁ *A*₂, *A*₂ *A*₃, &c., having these lines shown in an internal space. It could have been avoided by drawing these four lines outward, instead of inwards. They would then cut up the other pens into a large number of subdivisions, a large number of imaginary joints and imaginary links, and stress-lines representing the stresses on these imaginary links, would need to be introduced into the construction. As the wind-force lines already cut up the pens to a considerable extent, this extra confusion is avoided by permitting this gap. From *h* to *h*¹ the vertical distance equals the sum of the four vertical loads.

The pens V N J R are each split into two by the line of the horizontal diagonal across the base. Similarly, pens O and K are split in two by the line of the horizontal diagonal at the level of Q Y and M U.

Since all except these two bars lie in one or other of four main planes, two of which are perpendicular to the elevation projection plane, the traces of planes need not be found by special construction, except in solving one joint. Thus, the resultant of the forces *q j*, *j k*, *k c*, *c b*, *b i* is known to be in elevation parallel to the elevation I B or J K, independently of the individual magnitudes of these forces. This greatly lessens the labour of construction, but as nearly all engineering structures may be shown on projections suitably chosen, so as to afford similar advantages, this example is a fair illustration of the amount of labour involved in solving the stress problem by this graphic method.

The construction proceeds as follows, using the notation already explained. Note that as bars A B, C K, J R, S 10, A F, G O, N V and W 8 are perpendicular to the (*ε*) plane; therefore in (*ε*) the following pairs of points coincide:—

$$a b, c k, j r, s 10, a f, g o, n v \text{ and } w 8.$$

To indicate that k is to be marked coincident with c , there is written simply $ck = 0$.

Joint (A I B).

$$(\epsilon) a_4 b = 0 \quad \frac{b}{a_1} > i^1 \quad a_1 i \# a_1^1 i^1 \quad (\pi) a \downarrow i \quad \frac{a}{i} > b.$$

Joint (A E F).

$$(\epsilon) a_2 f = 0 \quad f e_4^1 \# 45 \quad \frac{e_4^1}{a_3} > e_4 \left\| \begin{array}{c} \text{F E} \\ \text{A E} \end{array} \right. \quad \frac{f}{e_4} > e_5.$$

$$(\pi) a \downarrow e_4 \quad e_4 e_5 \# 45 \quad \frac{e_5}{a} > f.$$

Joint (A F G H I).

$$(\epsilon) \frac{f}{i} > h \left\| \begin{array}{c} \text{F G or G H} \\ \text{I H} \end{array} \right. \quad \text{Owing to symmetry of construction} \\ i h = 0.$$

$$(\pi) i h = 0 \quad \frac{h}{f} > g. \quad (\epsilon) h \uparrow g.$$

Joint (A B C D E).

$$(\epsilon) e_4 d_3^1 \# 34 \quad \frac{d_3^1}{b} > d_3 \left\| \begin{array}{c} \text{E D} \\ \text{B C or C D} \end{array} \right. \quad d_3 d_4 \# 34. \quad \text{Join } d_3 e_4$$

$$(\pi) e_4 \downarrow d_4 \quad d_4 d_3 \# 34 \quad \frac{d_3}{b} > c. \quad (\epsilon) b \uparrow c.$$

Joint (H G O P). No external force acts here, and the bars O P and H G are in alignment; therefore, the stresses in these two bars are equal, since only two other forces act at this joint. $\therefore op = gh$.

$$(\epsilon) go = 0 \quad hp = 0. \quad (\pi) go = 0 \quad hp = 0.$$

Joint (D C K L).

$$(\epsilon) ck = 0 \quad d_3 l_2^1 \# 23 \quad \frac{l_2^1}{k} > l_2 \left\| \begin{array}{c} \text{D L} \\ \text{K L} \end{array} \right. \quad l_2 l_3 \# 23. \quad \text{Join } l_3 d_3.$$

$$(\pi) d_3 \downarrow l_3 \quad l_3 l_2 \# 23 \quad \frac{l_2}{c} > k.$$

Joint (K C B I H P Q J).

$$(\epsilon) \frac{k}{p^1} > q^1 \left\| \begin{array}{c} \text{K J or J Q} \\ \text{P Q} \end{array} \right. \quad \text{This gives } p^1 q^1 = 0 \text{ and } \therefore pq = 0.$$

$$(\pi) pq = 0 \quad \frac{q}{k} > j. \quad (\epsilon) k \uparrow j.$$

Joint (J Q Y R). Y R is in line with J Q. $\therefore qj = yr$.

$$(\epsilon) q^1 y^1 = 0 \quad qy = 0 \quad jr = 0. \quad (\pi) qy = 0 \quad jr = 0.$$

Joint (O G F E D L M N).

(ϵ) $d_4 d_5 \# 4 \ 5$. Join $e_5 d_5$ $l_3 l_4 \# 3 \ 4$ $l_4 l_5 \# 4 \ 5$. Join $d_5 l_5$

$l_5 m_6^1 \# 5 \ 6$ $\frac{m_6^1}{o} > m_6 \left\| \begin{array}{c} \text{M L} \\ \text{O N or N M} \end{array} \right. m_6 m_5 \# 5 \ 6$. Join $m_5 l_5$.

(π) $d_4 d_5 \# 4 \ 5$ $d_5 \Downarrow l_5$ $l_5 \Downarrow m_5$ $m_5 m_6 \# 5 \ 6$ $\frac{m_6}{o} > n$.

(ϵ) $o \Updownarrow n$.

Joint (N M U V).

(ϵ) $n v = o$ $m_6 u_6^1 \# 6 \ 7$ $\frac{u_6^1}{v} > u_7 \left\| \begin{array}{c} \text{M U} \\ \text{V U} \end{array} \right. u_7 u_6 \# 6 \ 7$. Join $u_6 m_6$.

(π) $m_6 \Downarrow u_6$ $u_6 u_7 \# 6 \ 7$ $\frac{u_7}{n} > v$.

Joint (8 9 X W).

(ϵ) $8 w = 0$ $\frac{9}{w} > x$. (π) $9 \Downarrow x$ $\frac{x}{8} > w$.

Joint (10, 1 T S).

(ϵ) $10 s = 0$ $\frac{1}{s} > t_1$. (π) $1 \Downarrow t_1$ $\frac{t_1}{10} > s$.

Joint (7 8 W V U T).

At this joint the horizontal diagonal bracing bar will be called $V_1 V_2$. At its other end it will be called $R_1 R_2$. Its stress appears twice in the diagram as $v_1 v_2$ and $r_1 r_2$, the two equal and opposite pulls it exerts at the two joints. At this joint the thrust $t_7 \ 7 \# t_1 \ 1$ is already known. The three unknown forces are $w v$, $v_1 v_2$ and $u t$ exerted by the bars $W V$, $V_1 V_2$, and $U T$. Find the traces in (π) and (ϵ) of the plane containing $W V$ and $V_1 V_2$. They are marked long-dotted lines lettered $(W V, V_1 V_2)_\pi$ and $(W V, V_1 V_2)_\epsilon$. In both (π) and (ϵ) stress-diagrams plot $7 \ t_7 \# 1 \ t_1$. Also in both (π) and (ϵ) plot from w the known stress $v_1 u_7$ of the bar $V U$. Thus

(π) $w v^1 \# v u_7$. (ϵ) $w v^1 \# v u_7$.

$t_7 v^1$ in (π) and (ϵ) is the resultant of the known forces at this joint. Plot this backwards in both (π) and (ϵ) from the joint to point a .

In (π) draw $a \beta \gamma \parallel U T$ meeting $(W V, V_1 V_2)_\pi$ in β , and the ground line in γ .* Project β to β^1 on the ground line, and γ to γ^1 on $(W V, V_1 V_2)_\epsilon$. Draw $\gamma^1 \beta^1$ to meet in η^1 the line $a^1 \eta^1 \parallel U T$ in (ϵ). Project η^1 downwards to η on $a \beta$. Then $\eta^1 a^1$ and ηa are the (ϵ) and (π) projections of the stress on $U T$.

* The points γ and γ^1 fall beyond the limits of the drawing as engraved.

Then proceed thus:—

$$(\pi) \quad t_7 \, u_7^1 \# a \, \eta \quad u_7^1 \, v_2 \# w \, v^1 \quad \frac{v_2}{w} > v_1 \left\| \frac{V_1 \, V_2}{W \, V}.$$

$$(\epsilon) \quad t_7 \, u_7^1 \# a^1 \, \eta^1 \quad u_7^1 \, v_2 \# w \, v^1 \quad \frac{v_2}{w} > v_1 \left\| \frac{V_1 \, V_2}{W \, V}.$$

Joint (R Y X 9 10 S).

$$(\pi) \quad s \, s^1 \# v_2 \, v_1 \quad s^1 \, r^1 \# r \, y \quad \frac{r^1}{x} > y_2 \left\| \frac{S \, R}{X \, Y} \quad y_2 \, r_2 \# y \, r \quad r_2 \, r_1 \# v_1 \, v_2.$$

Join $s \, r_1$. This gives $s \, r_1 \# r^1 \, y_2$.

$$(\epsilon) \quad s \, \uparrow \, r_1 \parallel S \, R \quad r_1 \, \uparrow \, r_2 \parallel R_1 \, R_2 \parallel V_1 \, V_2 \text{ or } r_1 \, r_2 \# v_2 \, v_1 \\ r_2 \, \uparrow \, y_2 \text{ or } r_2 \, y_2 \# r \, y^1. \text{ Join } y_2 \, x.$$

The stress diagram for this joint in (π) and (ϵ) is now obtained, namely, $x \, 9 \, 10 \, s \, r_1 \, r_2 \, y_2 \, x$. The most important check on accuracy yet obtained consists in finding the line $y_2 \, x$ in (ϵ) parallel to $Y \, X$. In the drawing of this present diagram the two were exactly parallel.

Joint (V W X Y Q P O N).

Here all the forces have been found, except that exerted by the horizontal diagonal. The summation of them is not as yet, however, shown completely on the diagram. Beginning with the force $v \, w$ there is already plotted consecutively $v_1 \, w \, x \, y_2$ both in (π) and in (ϵ) . Next mark q_2 and p_2 coincident with y_2 , because $y \, q = 0 = q \, p$. Then in both (π) and (ϵ) plot

$$p_2 \, o_2 \# p \, o \quad v_1 \, n_1 \# v \, n \quad n_1 \, o_1 \# n \, o$$

these being mere repetitions of stresses already found. Join $o_2 \, o_1$. This is the stress on the horizontal diagonal, and must be found parallel to this bar both in (π) and (ϵ) . This is, therefore, a double check on the accuracy of the drawing.

Joint (K J R S T U M L).

All the stresses at this joint have now been found, although they have not been built into a consecutive diagram. This being done, there is obtained in both (π) and (ϵ) the polygon

$$k_1 \, j_1 \, r_1 \, s \, t_1 \, t_2 \, u_2 \, m_2 \, l_2 \, k_2 \, k_1$$

the last stress $k_2 \, k_1 \# o_2 \, o_1$ being the stress on the horizontal diagonal. The double check consisting in the closure of this polygon in both (π) and (ϵ) is not independent of that given at the previous joint; it merely shows that no new errors have arisen in transferring the vectors from one to another part of the paper.

This completes the plan and elevation of the stress-diagram. From them is constructed the "composition stress-diagram," in

the manner already explained. On it can be read off to scale the whole stress on each bar of the structure along a diagonal line (not drawn), joining two similarly-named points on the vertical and horizontal axes.

No solid structure that is stiff and non-redundant, and which contains no beams, can present difficulties in the construction of its stress-diagram that are not fairly illustrated in this example; except in cases corresponding to those in plane problems where recourse has to be had to the "method of sections," or "the method of two trials and two errors." This happens when it is not possible to pass from the already "solved" part of the structure directly to a "soluble" joint. There is an example of this in the last Fig., where, having worked from the top down to joint (N M U V), it is found impossible to proceed to any joint contiguous to those already solved. There are, however, in this case two detached soluble joints, namely, (89 X W) and (10,1 T S), which are next taken, and thus no need of the method of sections arises.

A soluble "section" in a plane structure cuts three bars. In the solid problem, the soluble section cuts six bars. The total external load on the part of the structure lying on either side of the section is reducible to two non-intersecting forces. The problem is, therefore, to find the six magnitudes of six forces whose lines of action are completely known, which will balance this known load. The analytical solution of this problem is obvious; it consists in solving six simultaneous linear equations of a somewhat complicated character. The graphic solution is not so easily recognizable. The following method, although not perfectly general, will apply to most cases likely to occur in engineering practice. It assumes that the lines of the six bars may be taken in three pairs, each of which pairs intersect in a point. Let the planes of these three pairs be called A, B, and C; and the three points in these planes, where the pairs of lines meet, be called $\alpha \beta \gamma$. Let all the external forces applied to that portion of the structure on one side of the section (not on one side of plane $\alpha \beta \gamma$) be compounded to a single force lying in the plane $\alpha \beta \gamma$, and a single force perpendicular to the same plane. Call the former force ρ_π (lying in $\alpha \beta \gamma$), and the latter ρ_ν . The pair of stress-forces acting along the pair of lines meeting at α may be imagined compounded to a single force acting in plane A through point α . Refer to this still unknown resultant by the name a , and imagine it resolved at point α into two components, one a_ν perpendicular to plane $\alpha \beta \gamma$, and the other a_π lying in this plane. Deal similarly with the stresses acting at β and γ , calling the components b_ν and b_π at β ,

and c_v and c_r at γ . By taking moments of ρ_v and a_v (whose positions are known) round the axis $\beta \gamma$, the value of a_v can be found; these two moments being equal and opposite, because the lines of all the other forces pass through the axis $\beta \gamma$. Similarly, b_v and c_v can be found by taking moments round $a \gamma$ and $a \beta$. After finding the positions in the diagram of ρ_v , a , β , and γ , this process can be carried out either arithmetically or by the well-known graphic construction.

Next, suppose a_r resolved into two components, both in the plane $a \beta \gamma$, one being perpendicular to, while the other is parallel to, the intersection of the planes $a \beta \gamma$ and A . That perpendicular to the intersecting line bears a definite proportion to a_v (namely $= a_v \times \cot.$ angle between $a \beta \gamma$ and A), which enables it to be readily calculated. The other acts in the plane $a \beta \gamma$ along a known line, namely, the intersecting line of the two planes. Treat the forces at β and γ similarly. The problem is now reduced to finding the three magnitudes of three forces, acting along the three known lines of intersection of plane $a \beta \gamma$ with planes ABC , the forces which these are to balance being now all known. This can be done by the method followed in Figs. 3 and 4. All three components of the resultant stress acting at a being now known, their resultant can be found, and this resolved into two components along the given lines of the two bars. A similar process gives the stresses along the other four bars, meeting at β and γ .

This process, as described, may appear tedious, but the work involved does not really occupy a great deal of time. After finding the points $a \beta \gamma$, it will generally be convenient, for the rest of the construction, to make a plan of the six bars and the force-lines on the plane $a \beta \gamma$. If it be important to find the real stresses throughout the structure, probably many engineers would prefer to carry out the "method of sections" in this graphic way, rather than by constructing and solving the six simultaneous equations that form the algebraic solution of the same problem. It must be remembered that, in order to state these equations in definite terms, it is necessary to calculate the three direction-cosines of each of the six bars, namely, eighteen direction-cosines in all.

The Paper is accompanied by two sheets of tracings, from which Plate 12 has been engraved.

Fig : 4 .

[illegible]

SIDE ELEVATION.

FRONT ELEVATION.

P L A N .