25 January, 1898.

Sir JOHN WOLFE BARRY, K.C.B., LL.D., F.R.S., President,
in the Chair.

(*Paper No. 2996.*)

“Reservoirs with High Earthen Dams in Western India.”

By WILLIAM LUMSDEN STRANGE, Assoc. M. Inst. C.E.

RESERVOIRS in India are required to store water for irrigation as well as for the supply of towns. For the former purpose the sites are generally selected in elevated places at the head of fertile valleys; for the latter, as near as practicable to the population to be served. The storage-capacity required for the former class of reservoirs, although it is, as a matter of economy, designed for only 1 year's supply, as a rule very greatly exceeds that for the latter, even providing, as such works should in India, a sufficiency for 2 years' consumption. Hence the size of the dams for irrigation reservoirs, or “tanks,” as they are locally called, is usually much larger than that for town-supply works.

Irrigation reservoirs may be divided into two classes, according to their situation: (a) Ghaut-fed, with an assured annual replenishment, and (b) Eastern, with an uncertain annual replenishment. The chief objection to reservoirs of the first class is that they are generally some distance above the canals, and thus there is considerable waste of water in transit. To the second class the chief objection is their precarious supply; but, on the other hand, they are situated conveniently to the distributing-works.

Rainfall.—In the Bombay Presidency the rainfall is practically confined to the “rains,” lasting from the beginning of June to the middle of October, and, in the southern portions, to the early part of November. In amount, it varies between 300 inches annually at Máhableshwár, the highest station in the Western Ghauts, to less than 20 inches in what is known as the “famine zone,” distant between 50 miles and 100 miles east of the main watershed. The months of heaviest rainfall are generally July (due to the south-west monsoon) and October (due to the north-east monsoon). The

other months of the "rains" have a comparatively small fall; the rest of the year is generally rainless, and is very seldom productive of replenishment to reservoirs. Construction work is limited to this last-named period of 7 months. Bombay is fortunately seldom disturbed by cyclones, but in Bengal and Madras there are occasionally violent cyclonic storms.

Climate.—During the "rains" the climate is cool but fever-producing. The "cold weather" succeeds and lasts till the middle of February; it is cool and bracing, but fever-producing, especially at its commencement. The "hot weather" closes the working year, and, although it is sultry, is, on the whole, the most healthy period except when outbreaks of cholera occur.

Physiography.—The Bombay Presidency comprises four main physical divisions:

(a) To the north is the practically rainless plain of Sind, the irrigation of which has been developed by several canals of the largest size drawing from the Indus.

(b) To the south of (a) is the level and hot fertile plain of Guzerát, where the rainfall is generally well distributed, and large irrigation storage works have, in consequence, not been recently constructed. South of this again is the Presidency proper, which is divided into—

(c) The Konkán, which lies between the sea and the Western Ghauts; it has a rainfall, abundant throughout, and excessive near the watershed, and artificial irrigation is not practised to any extent; and

(d) the Deccán, which is the tract to the east of the Ghauts. Here the rainfall is capricious, and, to the east, very scanty; it is in this portion that almost all the large storage reservoirs have been constructed, and it is this area which will chiefly be considered in this Paper.

Geology.—With the exception of the southern part, where metamorphic rocks occur, the whole of the Deccán consists of the Deccán and Málwa trap formation. The trap exists in all varieties, from the hardest compact rock to schistose strata, which, in the course of ages, have decomposed first to "murum," a friable, stony material, and then to various argillaceous soils, of which the best known and most widely distributed is the black "cotton soil." The rock is finely crystalline and heavy; the better varieties, especially the boulder rock, are practically unchangeable, are very hard to work, and break with a conchoidal fracture. There are others which at first sight appear nearly as durable, but, in the course of a few seasons, and occasionally in a single

year, decompose under the extreme meteorological conditions into friable and clean "morum." They are distinguished by a less crystalline and duller appearance, and are occasionally traversed by lighter-coloured bands, or by quartz veins. Great care is necessary to discriminate between the useful and the useless varieties, for both are hard and sound when first excavated. The black "cotton soil" has been chiefly used for the construction of the older dams in consequence of its abundance and watertightness. It is, however, by itself, a treacherous material, absorbing water easily, and cracking when dry; its frictional resistance to slipping is small, owing to its unctuous character and freedom from binding grit.

Hydrology.—The surface of the country, especially in the hilly parts, is veined by numerous watercourses or "nullas." During heavy rain these become torrents; on its cessation they quickly dwindle to small rills and soon afterwards dry up. As a general rule, except for a few days in the year, they are dry.

As the streams increase in size so does their violence diminish and the duration of their supply increase, but, with the exception of a few rivers of the largest size, they all become torrents during heavy rain, and few have a perennial flow of even small amount.

Materials.—The materials required for dams and their subsidiary works, viz., stone for building and pitching, argillaceous soils and "morum," metal and "kankar" (nodular hydraulic limestone), are generally abundant and close at hand; otherwise, where the works are situated in out-of-the-way localities, it would not be feasible to construct them economically.

Labour.—Dams are constructed almost entirely by manual labour, large numbers of men, women and children being employed for this work. On some of the large famine-works some 20,000 persons have been engaged at one time. The soil is loosened by pickaxes, scraped with large hoes into basin-shaped iron baskets, holding about $\frac{1}{3}$ cubic foot each, by other men, and the loaded baskets are carried to the site as head-loads by women and children. The bulk of the labour is furnished by the poorer agricultural inhabitants of the locality, and the numbers are thus largely affected by the character of the season. These people work in gangs of between twenty and fifty each under a head-man, and are most usefully employed on task-work. There are also, but in much fewer numbers, gangs of trained labourers, who wander about the country for work; these gangs prefer to be as independent as possible, and almost invariably work by piece-work. In addition to human labourers, pack-animals—donkeys,

oxen and buffaloes—have always been employed by the natives. More recently carts, and, still more recently, small portable tramways and light trucks have been used; these last-named are especially useful, cheap and expeditious where the lifts are not too high.

Old Native Works.—There are many small native “tanks” in Guzerát, and still more in the south of the Deccán; these vary in size between mere ponds, for the irrigation of a single field, and reservoirs covering 500 acres. The dams of the last-named are long, but none are more than 30 feet in height. In the Madras Presidency there are thousands of such tanks, which are not reservoirs, in the usually accepted sense, but are only intended to tide over breaks in the monsoon so as to enable the rice-crop to be grown. The natives have, however, left examples in many parts of the country¹ of stupendous works of this class, one of which is the ruined² Madág tank, on the border-line between the Dhárwár Collectorate (south of Bombay Presidency) and Mysore, which is believed to have been constructed during the Vijayanagár dynasty, A.D. 1335–1570. The dam occupies a splendid natural position between two spurs, averaging 800 feet apart. Its height is 100 feet, its top width 400 feet, and its base width over 1,000 feet. The lake must have had an area of nearly 40 square miles.³

These native constructions, being formed carefully by small head-loads, and being fairly consolidated by the treading of animals and labourers, have stood well, and when formed of suitable earth have become in the course of time extremely compact. They were constructed without puddle trenches or puddle walls, and in consequence even the smaller dams leak to a certain extent, although their beds are silted up. The chief cause of failure was the insufficient provision for the discharge of floods.

The modern construction of Indian reservoirs will now be described, each main subwork being separately dealt with.

PUDDLE TRENCH.

The puddle trench is excavated along the centre-line of the dam, and is taken down with a base width of between 6 feet and 10 feet, and with as steep side-slopes as possible (for timbering is not resorted to on account of its expense), well into sound

¹ Minutes of Proceedings Inst. C.E., vol. lix. p. 53.

² *Bombay Gazetteer*, vol. xxii., Dhárwár.

³ For other examples, see *The Engineer*, vol. lxiii. p. 189.

retentive clay, or, at least, 1 foot into sound trap rock.¹ The puddle mixture is formed of three parts of black or other argillaceous soil and two parts of sand. The bottom layer, about 1 foot thick, is formed of carefully kneaded balls of the mixture, which are thrown on to the bed and trodden on it to form a watertight junction. For the subsequent layers the mixture is inserted dry, is well watered and worked up by treading, each layer on completion being covered by the dry material of the next one to prevent its being cracked by the sun. The puddle is carried up 1 foot above ground to key into the body of the dam.

In excavating the puddle trench, the greatest care should be taken to avoid all sudden steps in its longitudinal section and vertical sides in its cross section. On both sections it is essential that the trench should be bounded by slopes. The material being compressible, a step would tend to cause a crack above it, while a vertical side, or, still worse, one sloping downwards away from the centre line, would tend to the formation of a hollow space. Timbered trenches, owing to their vertical sides, are objectionable for puddle work on this account.

River Crossing.—In the river-bed additional precautions are taken to prevent leakage. The main puddle trench is diverted about 20 feet upstream, and a concrete trench, about 5 feet wide, is constructed on the centre line of the dam, across the river-bed and well into its banks, and is run at each end into the puddle trench, which is thickened to receive it. The practice of having two trenches at the river-bed crossing appears open to the objection that, assuming the trenches are efficient, the result is at the centre of the highest section of the dam there must be an area—that between the trenches—of sodden foundation into which a certain amount of water must leak, and from which it cannot easily escape owing to the presence of the down-stream trench. Earth through which water percolates is much sounder than that in which water stagnates; probably, because in the former case the moisture passes between the ultimate solid particles of the soil, while, in the latter, they are in a state of solution. The presence of this sodden area must tend to cause bulging of the foundation and settlement of the superstructure. The more expedient plan would be to widen and deepen the main central trench at the river crossing, and, if necessary, to have in it a central concrete trench.

Concrete and Puddle Trenches.—In England puddle is relied upon

¹ Minutes of Proceedings Inst. C.E., vol. lxxvi. p. 288.

to make the concrete beds and walls¹ of service reservoirs watertight. On the other hand, it is the practice of some engineers² to abandon a puddle trench for one of concrete. This is probably because narrow-timbered trenches are used, and the concrete can be rammed watertight to fill the whole space. An objection to the use of concrete is that, if for any reason a settlement crack should be formed, or two layers be not in watertight union, a permanent leak will be set up. In the case of puddle such faults would tend to remedy themselves by the compression of the material. Allowing that well consolidated concrete is more watertight than an equal thickness of puddle, it remains to be seen if thicknesses of the two materials of equal cost would differ so much in efficiency. In India concrete would cost nearly eight times as much as puddle, and although the latter is not so efficient as English puddle, still the much greater thickness economically permissible renders it as safe to use as concrete. Moreover, in the open puddle trenches as excavated in India, it would not be practicable to construct cheaply a thin, watertight concrete wall. When keying a trench into solid rock a narrow concrete trench may be substituted with advantage for puddle. The depth to which that key is necessary is a matter for consideration, as care should be observed not to fissure the rock by blasting.

Position and Dimensions.—The centre line of the dam is, no doubt, the best position for the puddle trench to ensure a symmetrical settlement over it and to interpose a sufficient extent of dam and natural soil to impede the percolation of reservoir water. Otherwise, for the sake of getting as much of the base of the dam as dry as possible, it would be advisable to place it somewhat upstream, say to the inner edge of the upstream third of the base. Fortunately, in Western India good watertight foundations can be usually met with at a reasonable depth, and the unstratified nature of the geological formation is also a favourable feature. At the same time it may be necessary to consider to what depth a puddle trench should be sunk when a perfectly satisfactory foundation for it cannot be found. At the Cant Clough³ reservoir for the Burnley Corporation, the concrete trench was sunk between 160 feet and 190 feet, and even then did not reach perfectly watertight strata. It is very

¹ Minutes of Proceedings Inst. C.E., vol. lxxiii. p. 1.

² *Ibid.*, vol. lix. p. 61.

³ *Ibid.*, vol. lix. p. 61; and *The Engineer*, vol. lxxiii. p. 13.

doubtful if even such a great depth would entirely prevent the passage of water although it would be useful in affording, on the downstream side, more natural means of drainage for the infiltrating water.

The rate of filtration of a soil depends upon its porosity, which governs the frictional resistance to flow, and the slope and length of the filamentary channels along which the water may be considered to pass. It is evident, therefore, that the direct rate of infiltration in a homogeneous soil must decrease from the top to the bottom of the puddle trench. The best section for a puddle trench is thus a wedge, such as an open excavation would give. It is true that the uppermost infiltrating filaments, when stopped by the puddle, will endeavour to get under it, but a depth will be eventually reached when the frictional resistance along the natural passages will be greater than that due to the transverse passage of the puddle trench, and it is when this occurs that the latter may be stopped without danger, as the filtration to it will be less than that through it. This depth requires to be determined in each case, but in fairly compact Indian soils 30 feet will be a fair limit.¹

Where a sound clay bottom can be met with, the trench need only be sunk 10 feet into it with a minimum total depth of 20 feet from the surface. The puddle trench should be sunk through fissured rock and at least 1 foot into sound rock where this is met with at a smaller depth than 30 feet, and is not overlain by a layer of 10 feet of good sound clay. In all cases it should be recognised that the maximum subsoil flow occurs along the top of the impermeable stratum, and care should be taken to intercept it by keying the trench well into the stratum. This may be best done in the case of hard soils by forming a concrete trench below the puddle one. Where the geological formation is stratified, these depths may have to be exceeded; but it is a question if it is necessary to go to a great depth in order to endeavour to intercept small subsoil flows. Also, where the dam is situated on a narrow ridge of porous soil, the depth would have to be increased; but, as a rule in Bombay, such ridges have a naturally good rock foundation.

In India the inflowing water replenishing the reservoir is

¹ Mr. David Gravell cites the opinion of Sir Robert Rawlinson, that 30 feet depth of puddle trench is sufficient if a thick bed of concrete is placed at the back with a well for collecting water and a pipe leading this off to the downstream side, as was done in the case of Yarrow Dam; *The Engineer*, vol. lxi. p. 189.

always heavily charged with silt, so much so that the storage capacity of even modern works has been seriously diminished by it. This silting up of the beds very sensibly diminishes the tendency to leakage, although it would be wrong to entirely depend upon it, as is evident by the old native reservoirs for which no puddle trenches were constructed. Even the smaller ones of this class are more leaky than is desirable. The best modern example of the tendency of reservoir beds to become water-proof is the Muchkhundi Tank, Bijápur Collectorate, formed by a masonry dam on a vertically schistose formation. This, at first, held but little water, but it has annually become more watertight, and the loss from leakage is now but small, although the work has only been completed 12 years.

In all well-constructed modern dams the actual value of the loss of water by leakage through the subsoil is not sufficient to justify the cost of expensive measures to lessen it, and, in most cases, it would be comparatively easy and cheap to pick up the escaping water lower down the stream and utilise it for irrigation.

The width of the trench is a matter of importance. A base width of 10 feet should be taken as the minimum allowable, and a greater width, say up to 14 feet, is desirable, so that rollers may be used to effect the maximum amount of artificial consolidation. Where the dam is high the base width may be made equal to one quarter of the full-supply depth of the reservoir at the point considered. The bed of the trench should be roughened so as to prevent the formation of a definite line of subsoil flow. The side-slopes of the trench should be as steep as practicable, but not steeper than $\frac{1}{4}$ to 1. With such slopes and a base width of 14 feet, a trench 30 feet deep would have a top width of 29 feet to resist the maximum rate of direct infiltration. It is better and cheaper to rely upon a comparatively shallow, well-drained puddle trench than upon a narrow and deep one, as the largest amount of subsoil leakage generally takes place near the surface.

In Bombay dams the puddle trench is only carried as far as the high flood-level margins of the reservoirs. As this is usually 5 feet or 6 feet above the full-supply level and the natural slopes of the ground are flat, this extent of trench is sufficient, under the conditions in force, and the arguments for not greatly deepening the trench apply still more forcibly to not increasing its length.

The puddle material is usually carried up a little above the surface of the ground in order to cut off the flow along the base of the dam. This extra height should be constructed at the same

time as the dam on each side of it, and should be rolled and consolidated with it, the only difference between the parts being that of the material employed in them. If the completion of the puddle trench has to wait for the dam, its upper surface should, at first, be kept at ground-level for convenience of work till the dam can be raised, and if any cracks occur, the temporary surface should be cut out and re-made.

Puddle walls in the dams themselves never occur in Bombay practice, for reasons which will be given later.

Filling.—The material of the puddle-trench filling should be the most retentive clay procurable. A mixture of more permeable material, such as “murum,” can only be effective in preventing shrinkage and the formation of cracks. The layers of puddle should, however, be so quickly formed on each other that the sun should have no time to act in causing the material to crack. It is true that an admixture of impermeable stone with the clay, if it can be ensured that each particle of aggregate is separated from the rest of the matrix, may be watertight; but the mixture would not be homogeneous, and the water would have a shorter course in passing from one stony particle to another than it would have through solid clay. When once the puddle trench is under the dam it is under practically settled conditions and cannot well crack. It will, on the contrary, tend to be compressed, and if water is absorbed from it by the subsoil, the compression will be aided and the material improved.

Experiment¹ has shown that a good natural specimen of clay when dried lost 25 per cent. of its weight, and 10 per cent. of its bulk; it then became extremely compact, and, if not allowed to expand, offered great resistance to the passage of water. A dried specimen of this clay reduced to a fine powder absorbed about 75 per cent. of its weight of water, and allowed of free percolation. When this powdered clay was pressed into a tube 8 feet long and 3 inches in diameter it absorbed 35 per cent. of its weight of water, but there were no traces of filtration through the tube. The compressed particles of clay, in absorbing the water, expanded so as to become watertight. On a large work it would not be economically practicable thus thoroughly to desiccate clay, nor feasible to consolidate the whole dry mass. The experiments show, however, the advisability of using no more water in the puddle trench than is necessary to produce a compact substance by rolling. The further compression of the trench-filling should be

¹ *The Builder*, vol. li. p. 400.

given by the superincumbent weight of the dam, which should be allowed to act for as long a time as possible before the reservoir commences to fill, so as to prevent filtration through the green material. In a wet state clay reaches its extreme point of expansion, and, when thus exposed to the action of water, filtration must take place between the separated particles. Clay is, moreover, so retentive of water, that, if once soaked, it will be long before it parts with the excess of moisture; hence the greatest care should be taken during construction to use the minimum amount of water.

Drainage.—Notwithstanding all precautions, some water will certainly pass through the puddle. Its amount may not be great, but its effect in soddening the area below and downstream of the dam may be considerable. In Figs. 8-12, Plate 3, is shown a method for safely leading away such water. A dry-stone drain, having a vent of say 4 inches by 6 inches, would be formed at the downstream base of the puddle trench; this would be enclosed in a mass of sound, clean rubble, say 4 feet by 3 feet, and this, in its turn, surrounded by a 1-foot layer of clean gravel, quarry spalls, coarse sand, &c., to prevent the flow of the superincumbent earth into the interstices. Where the base of the puddle trench can be excavated by hand, the drain can be shut off from the upstream part of the trench by a natural barrier of impermeable material so as to lessen the chance of direct creep of water. Where, however, it has to be blasted, a level bed would be formed throughout, or the drain sunk below the general bed when this can be done without opening fissures upstream. This drain would be led at intervals, by side-cuts and drains, through the ridge on which the dam stands, or, should this be impossible, down into the main "rear drain" below the dam. The base of the puddle trench should be wide enough to prevent direct leakage being induced along it into the drain. In a well-constructed puddle trench the subsoil water will tend to descend along the upstream face of the puddle to the base, and will then endeavour to force itself up, thus rendering the clay more absorbent and permeable. Where, however, a means of escape is provided, as by the drain above described, the small amount of percolation will be led harmlessly away, and the puddle material kept as compact as possible.

It might be considered advisable to continue the drain vertically along the downstream face of the trench, but such a long, thin layer might suffer distortion or disturbance from the lateral pressure of the puddle and the earthen sides of the trench, and

might become discontinuous and thus of little use. In the case of a concrete trench in hard soil this would not occur, and it might, with advantage, be backed by a rubble lining to act as a drain, Fig. 12, Plate 3.

Subsoil Water escaping the Trench.—Many existing dams show that subsoil infiltration below the puddle trench occurs harmlessly. The water-level of wells for some distance below the dam is raised, and small clear springs issue at rock outcrops. The total quantity thus escaping is relatively small, and it is not worth while to incur a large outlay to endeavour to entirely prevent it. Assuming the puddle trench to be soundly made and well drained at the base, it will intercept all infiltrating layers which come against it; owing to its depth, water passing below it must come from a considerable distance, and its rate of flow must therefore be small. Except along the downstream slope of the trench (where it will be intercepted by the base drain), water will have no tendency to rise below the base of the dam, owing to the great superincumbent weight on it, but will seek an easier escape along some of the natural leakage-planes of the subsoil. Its quantity will almost invariably be small, but, should it be large, it may safely be dealt with at small expense by a downstream deep drain.

FOUNDATIONS.

It is usually specified that the foundation of a dam should be stripped of all surface soil for 1 foot in depth, all plants rooted out, all slushy, sandy or loose material removed from the site, and all steep slopes benched to receive the earthwork.

The best foundation for a dam is compact rock, provided it is level, or at least does not slope downstream, as it would then tend to cause a slip. To prevent this its surface should be well roughened by shallow trenches parallel to the axis of the dam. The next best foundation is compact "murum," as neither of these will move appreciably under the weight of the dam. After these come, in the order named, "mán" (a soft clay rock), brown, and black soils; but they require special precautions for drainage, as they will yield under a heavy weight when sodden. "Kara," a light, powdery, marly soil, is the worst possible foundation, as it easily becomes sodden and slushy. In short, it is necessary to secure a compact, well-drained base for an earthen dam, although it is not necessary to have the absolutely rigid foundation required for a masonry dam. The thorough drainage of the base is a matter of vital necessity. To ensure it, it is always de-

sirable to select a site where the fall of the main natural drainage lines will facilitate the passage of all subsoil water.

Benchd Foundations.—It is at the junction of the dam with the ground that the maximum amount of leakage may be expected, as the top soil is weathered and is not so consolidated as the subsoil. In India the soaking of the monsoons and the great drying effect of the hot weather produce considerable movements in the top soil. When black soil dries, numerous cracks, several feet in depth, are produced, and the lines of separation probably go considerably deeper. With brown soils the cracking is much less, and with those consisting of murum it is hardly apparent. In most cases, therefore, it is desirable to take greater precautions to prevent leakage along the base of the dam. For all soils that can be excavated by hand the section given in Figs. 9, Plate 3, is recommended as one well calculated to prevent the formation of a definite line of flow, and, by interposing many obstacles on the upstream side to the passage of water, to retard infiltration. The whole bed of the dam, outside the area occupied by the puddle trench, is stripped of unreliable surface soil and is then excavated into large furrows, parallel to the axis, which have the further advantage of tilting up the dam, so that its layers tend to slip inwards, not outwards. At the bases of the upstream benches small trenches are cut and filled with clay stopping to cut off leakage. Some of these should be deeper than the others, so as to make the junction line as broken as possible and to cut off all surface flows. On the downstream side the small trenches are made into drains, filled with drystone covered with a protecting casing of fine gravel, and leading out of the dam at intervals. These will uniformly drain the base of the dam, thus preserving the subsoil compact and preventing water rising into the embankment.

Excavation in the Reservoir-Bed.—It is usually specified that no excavation should be allowed within 200 feet of the upstream and 150 feet of the downstream toe. A better plan would be to make the distances some multiples of the height of the dam, as it is obviously unnecessary to take such precautions at the low flank as at the high gorge embankment over the river-bed. Such a specification for the reservoir-bed is undoubtedly good in that it would leave it with a covering, as watertight as possible, near the dam; and it might be amplified by prohibiting the entire stripping of surface soils or the digging of murum quarries within ten times the height of the dam from its toe. Although such excavations will soon silt up, still they may at first cause subsoil filtration which will act prejudicially on the newly-formed dam.

The "Surface Drain" at the Downstream Toe, Figs. 9, Plate 3.—There does not seem to be any harm in making excavations of small depth at a short distance from the downstream side of the dam provided they are drained and the formation of swamps is prevented. The general line of thrust due to the weight of the dam must be inclined downwards and the natural surface in the rear does not act as a buttress. Its only useful property must be its weight, tending to prevent bulging upwards of the subsoils; a slight removal of the top soil will have an inappreciable effect in this direction. It is far more important to secure thorough drainage of the ground immediately downstream of the dam, and, for this purpose, it is advisable to slope off the natural surface, say for 30 feet, at 1 in 10 from the toe. This slope will prevent water lodging even should weeds and rushes grow on it. This "surface drain" should be diverted downstream at intervals so as to prevent the formation of a scour channel along its course during heavy rainfall.

The "Downstream Drain."—Just clear of this "surface drain" should be a parallel "downstream drain," Figs. 9, Plate 3. This may have a base width of 5 feet with steep side-slopes and a depth of between 10 feet and 15 feet. It should have a small drystone drain with a 4-inch by 6-inch vent at the base, and, as it may be filled with dry material excavated from the waste weir, &c., it should not be expensive to construct. It will effectually drain the ground to the downstream of the dam, and will intercept the percolation passing the puddle trench and likely to rise in the neighbourhood of the dam. It should lead to the main "rear drain" below the dam described below.

It will also have a decided effect in reducing the salt efflorescence, which damages agricultural land below some dams. This is due to the upward passage of subsoil water, charged with dissolved salts, in excess of that which the natural subsoil drainage can pass off. As this upward moisture is being continually evaporated by the sun, the salts are crystallised out on the surface. The foundation drains below the downstream part of the dam can be led at intervals into this "downstream drain."

Open and Underground Drains.—Shallow drains are of little use in draining the rear of the dam, as they do not intercept the main sources of infiltration. The water rises between them to the surface, and, where this is clayey, marshy ground is formed, and on this grow in profusion reeds and water-plants which add a further obstacle to complete drainage.

The system of underground drains, filled with dry material,

surrounded by a filtering layer and having a cover of, say 2 feet of finer material and soil, is, in India, decidedly better than one of open drains. Owing to the severity of the rainfall and the rapid growth of plants, the sides of the latter are certain to crumble in and choke the flow. Their maintenance in water-charged earth is sure to be expensive, and, if not continuously carried out, they are liable in the course of a few years to be obliterated. The underground drains, on the contrary, run clear, weeds cannot grow in them, the sides cannot tumble in, nor can silt be washed into them from the surface.

Rear Drains.—At all valley lines crossed by the dam, “rear drains,” Fig. 8, Plate 3, should be run with as good a fall as possible. They should pass off the flow from the “downstream drain” and the “puddle-trench drain,” *ante* p. 134, to the natural drainage lines of the country. Where they are in soil they should be of the underground type. The main rear drain in the river bed will generally be in rock, and can in such a case be in open excavation, protected from the inflow of silt, &c., by raised side banks. As it will drain the highest part of the dam, the greatest care is necessary that it should always be clear.

The bed of the puddle trench at the river crossing will probably be near the surface; but, where it is not, and the natural fall is gentle, its base drain should be connected with the rear drain by an upwardly inclined transverse drain having its mouth a little above the bed of the latter, to prevent the inflow of water from it. This transverse drain, by affording an easy exit to the puddle-trench drainage, will prevent the base of the dam from becoming sodden. This artifice of upwardly draining subsoil water has already been tried with success in agricultural practice, where a retentive soil on rising ground is underlain by an imprisoned, permeable and water-bearing stratum. It assimilates in principle to the artesian well.

Sandy River-Bed Foundations.—Where the river-crossing is in deep and compact sand, it may occasionally be more economical to leave this on the downstream side of the puddle trench, preventing its motion by a strong masonry toe-wall. The sand will thus act as a natural drain to the base of the dam. The upstream base of the dam should, of course, be cleared of sand, and, as a further precaution against direct infiltration, the puddle trench should be widened considerably. The chief danger will be the possibly unequal settlement of the two portions of the base, but this can be obviated by raising the dam slowly, and by giving it a year in which to settle after completion before the reservoir is filled.

CONSTRUCTION OF THE DAM.¹

General Formation.—Owing to the cheapness of labour, Indian dams are probably more soundly constructed than those elsewhere. The foundation of the dam, having been levelled, is wetted by a hose from a pump, or by “bhisties” (water-carriers employing oxen with leather water-bags placed on their backs). On this is spread the earth, which is conveyed to the site in small quantities, all clods are broken up, and the layer is carefully levelled and finally rolled. On the completion of a layer, the process is similarly repeated for the next one and so on. At the base of the dam crossing the river-bed, the layers, when rolled, should not exceed 3 inches in thickness. When the dam has been raised one-third of its height the thickness may be increased to 4 inches, and for the top third to 5 or even 6 inches.

Material.—In many of the dams constructed in recent years, the chief fear entertained was that water would penetrate them, and, in consequence, they were composed entirely of black “cotton soil” with protective casings. Although this material is very fairly watertight, still, from its greasy and unstable nature, it is not suitable by itself for the formation of high dams, and most of the slips which have occurred must be due, in a great measure, to its use.

When this fear of percolation was seen to be unfounded, more importance was attached to giving greater stability to the earthwork by forming the outer portions of the cross-section of soils, natural or artificial, having a greater frictional resistance to slipping, the hearting being still made of black soil or clay. This may be described as the present general system, and it is a decided advance on the older one. It is, however, open to the objections that in practice it is sometimes difficult to arrange for the simultaneous carrying up of layers having different materials in different parts, and to the more serious one, that by it the dam is composed of three distinct portions having different rates of consolidation and different behaviour under the infiltrating action of water, whereby internal stresses are set up in the mass until it attains its final settlement. With such a material as earthwork it is decidedly better to construct the dam as one homogeneous whole so that it may act as one uniform mass under all conditions.

¹ The standard specifications worked to in Bombay are given in “Specifications, Rates and Notes on Work,” by Captain Marryat, R.E., 4th edition, pp. 47-50.

There is, as a rule, in India, little difficulty in getting argillaceous material, while that necessary to furnish the needful grit is generally the more expensive to obtain. There is, therefore, no economy in limiting the use of clay to the hearting. Where, however, clay is deficient, it should be chiefly used in the upstream two-thirds of the section, a smaller quantity being reserved for mixture with the grit or dry material, forming the downstream one-third, without which the latter would be wanting in cohesive resistance. With careful construction there is no difficulty in consolidating a natural or artificial gritty, but still clayey, soil to a practically watertight mass. It is, therefore, better to make the dam of one consistence throughout, and a good proportion to adopt would be two parts of pure black soil to one part of pure "murum," or other dry material; or, such proportions of the existing soils as would result in an equivalent mixture, which is really an earthen concrete. The admixture of the dry material, besides increasing the frictional resistance of the mass, effects a means of self-drainage. As the vertical height of a dam is only about one-fifth of its width, excess percolation into the dam, at least on the downstream side, would be carried off more rapidly by the base drainage than it is produced by the hearting, and the mass would always be drier and more compact than if it were made of pure clay, which, when it has once admitted water, parts with it extremely slowly.

Such a dam should have protective casings formed with, say, double the amount of grit, and having normal widths varying from about 5 feet at the base to 3 feet at the top, to prevent solution on the reservoir side, and rain-guttering and weathering on the downstream side.

This mixture would, when compacted, be free from voids, but the small amount of clay used would be likely to render the mass permeable and possessed of little cohesive stability.

The layers of earthwork are generally constructed perfectly level, but this method can be improved upon. Mr. G. H. Darwin, M.A., F.R.S., when treating of "The Horizontal Thrust of a Mass of Sand,"¹ mentions the remark of Professor Clerk Maxwell that the "historical element" would probably largely affect the limiting equilibrium of sand, meaning thereby that sand formed in different ways would exercise different thrusts although presenting the same external appearance. The experiments he has recorded go to prove that this is the case. If it is desired that a mass of earthwork should settle tightly against a retaining

¹ Minutes of Proceedings Inst. C.E., vol. lxxi. p. 350.

wall, its constituent layers should slope towards it, and, the steeper the slope the greater would be their pressure. On the other hand, if the wall is to be freed as much as possible from earth pressure, the layers should slope from it. The same thing occurs in nature. "The stability of sedimentary rocks in the side of a cutting is greater when the beds are horizontal, or dip away from the cutting, than when they dip towards it."¹

Applying this principle to the construction of dams, it will be seen that it is advisable to construct the layers sloping inwards so as to counteract the natural tendency to slip outwards. For convenience of working, watering and consolidation, the slope from the downstream edge of the dam should be about 1 in 10. The upstream edge should be kept at about the same level, and the slope from it flattened so that its toe is level with that of the downstream side, and so that the resultant inwardly-slipping tendency of the two opposed masses of different magnitude may be approximately balanced. The central eighth of the layer may be kept level and worked off gradually to meet the outer slopes. Care must be taken when watering that no water runs down the slopes, and that it is uniformly distributed.

During the self-consolidation of the dam, the interior portions being of greater vertical height than the exterior and being subjected to greater pressure, even originally level layers must tend finally to slope towards the centre, but the action is so small that it cannot add appreciably to the frictional stability of the dam.

It has been stated² that the Oued Meurad dam in Algeria, 95 feet high, constructed some thirty years ago, had its earthwork layers deposited normal to the outer slope, and, as the bank was carried up, the water was admitted and allowed to rise to near the temporary crest. As soon as the bank had settled, the earthwork was continued another grade and the same process repeated.

Mixing.—A naturally clayey and gritty soil is the best, but, as such can rarely be found with the constituents in the proper proportion, it is generally necessary to make a mixture. The black soil should be first spread on the dam and should then be covered with a layer of "murum," &c. The best way of mixing them is by hand with a large hoe; but as this is very expensive, native sharp-pointed wooden ploughs and harrows may be employed. The next best method is to use a light metal plough, which inverts the earth and mixes the two layers intimately, thus preventing the formation of a pure soil, greasy plane below

¹ Rankine, "Civil Engineering," p. 318.

² *The Engineer*, vol. lxi. p. 189.

each pair. With the same object in view, in America, grooved rollers are employed, but they have not been used in India, and it is questionable if they are quite so effective as the iron plough in producing a uniform mixture.

Consolidation.—The consolidation of the layers of earthwork is principally effected by iron rollers which are drawn backwards and forwards by buffaloes or oxen until no further compression can be obtained. The dam should be constructed at least 18 inches wider on each side than the designed section, so that the roller can pass over the full final width. After the dam has been raised a few feet this surplus width can be removed and used for the upper layers. With the same object in view no patching on to the dam should be allowed, and all works-roads leading up the slope should be formed outside the designed section and should be removed by the excavator when no longer required.

A light roller should be used at first over the freshly-deposited earth to smoothen it and the consolidation should be completed by a 3-ton iron roller, 4 feet wide, until a loaded cart passing over the dam makes but a faint rut-mark on it. All rollers should be provided with automatic scrapers to prevent their lifting moist earth. At the Nagpur Waterworks a 10-ton steam roller was used; the use of this heavier roller is desirable to ensure that no vacuities are left in the dam. The weight of the dam itself is, however, the best compressor, provided that the earthwork has first been rendered compact artificially, and it is therefore advisable to let the completed section have at least one season in which it can act before the reservoir is allowed to fill, and not to raise the earthwork more than 30 feet in height in one season. The artificial compression by rollers is, however, so good that the allowance made for final settlement is only $\frac{1}{30}$ or $\frac{1}{36}$ of the total height of the embankment. A great part of this occurs during the first year after the work is completed.

Dependence must not, however, be placed entirely upon the self-consolidating powers of earthwork; for, during the settlement of an originally loose mass, a much larger amount of motion will take place, and if this is not absolutely uniform (which it cannot be owing to the varying heights in the longitudinal and cross sections) internal stresses will be set up. Moreover, the loose structure will be subject to great infiltration from rain and from the reservoir, which will keep it green and will still further tend to unequal settlement.

In confined situations, such as the junctions of two lengths of dam, the ordinary roller cannot work, and these places are consolidated by gangs of men working in unison with hand-rammers.

As they cannot compress the earth as much as rollers, these places become sites of unequal settlement, and should be avoided as much as possible. In order to obviate them it would be advisable to use split rollers on a common axle, with the animals working within their paths. At the top of the dam, where the lessened width will not allow animals to work, the consolidation should be effected by lighter rollers, running, say, $\frac{1}{4}$ ton to the foot, worked by men.

Where water is plentiful it is a good plan to water the finished slope with a hose for several days until it becomes so compacted by the washing in of fine particles that the water runs off it. The slopes thus become so hard that they will thereafter resist the guttering action of rainfall. With the same object in view, the top part of the dam should be formed of porous materials to absorb the rainfall as far as possible, and to prevent it running down the slopes in concentrated streamlets. The finished top should be covered with a layer of coarse sand $\frac{1}{2}$ inch thick. Where the top is wide, small side-banks, 1 foot high, might be constructed so as to prevent the water falling on it from guttering the slopes, or the surface may be very slightly inclined to the reservoir, so that the drainage may be harmlessly passed to the pitching. To protect the downstream slope from the weather it should be sown, at the beginning of the monsoon, with chopped "harali," a low grass of spreading habit having deep roots, which will bind the casing.

Watering.—Naturally damp earth, where available, should be used for forming the dam. Where it is not procurable it is a good plan to wet the borrow-pits overnight to produce it artificially. It is essential to secure complete union between the different layers that the finished one should be moistened before the next is put on it, so that the latter may be rolled into the former. Where moist earth is used, the wetting should be slight and done just in advance of the new layer. Where dry earth is used, more water may be given and for a longer time before laying the new layer. The test of the sufficiency of the watering is that the new layer is quickly consolidated, but yields only slightly before the roller. If there is any decided motion, it is an evidence of the formation of slush. The defective part should be at once cut out and re-made with dry material. For the reasons already stated it is imperative that only the minimum amount of water required for consolidation should be used. A dam formed of too wet material will remain green for a long time, and if the reservoir water is admitted to it while it is still wet a very undesirable amount of percolation may be set up.

Minor Precautions.—Cross-sectional junctions should be made as

shown in *Figs. 1*. All the loose surface earth of the old slope should be carefully removed and the earth joggled, as shown in plan, with inclined slip tongues to allow the new embankment to settle tightly on to the old one. Such junctions should not be more than 10 feet in height, and where a greater height is unavoidable, it should be broken up into sections, separated by horizontal breaks of at least 50 feet. They should not be carried up more than 20 feet in one season, and the work of the different seasons should break joint as shown in the sectional elevation.

Longitudinal junctions, or patchings, on to the slopes are most objectionable; but, where they have to be made, they should be carried out in the manner shown in *Fig. 2*, with benchings of irregular width to prevent the formation of a slipping plane, as transverse filtration need not be considered. No more than 20 feet vertically should be executed in one season.

At the gorge, or river-crossing, where the dam abuts on steeply rising ground, this latter should be cut into benches sloping into it, so that the earthwork may have a greater hold on the natural sides and less tendency to slip away from them. Each of the benches in plan should be divided into sections, breaking joint with each other, so as to prevent the formation during settlement of passages for the creep of water to take place. A smooth junction might also produce motion of the whole mass.

To test the nature of the construction at the close of each week, small trial pits, about 2 feet square, should be dug at intervals through the week's work. The earthwork, if properly constructed, should be found only slightly moist, compact and free from distinct stratification.

During the rains, theodolite and level observations of stout pegs, driven 3 feet deep at regular intervals on fixed lines on high parts of the dam, should be maintained, and a continuous record of them kept. These observations should be continued during the year succeeding the completion of the work. Thereafter, if no great settlement or distortion has been observed, it will be sufficient to keep an annual record of the level of bench-mark stones fixed at every chain on the top centre line of the dam.

Pitching.—In all large reservoirs the upstream slope of the dam is protected from wave-wash by drystone pitching. This should be laid on a layer of hard murum, quarry spauls, &c., about 6 inches thick, covering the casing. The pitching stones are usually laid with their broadest ends downwards, and they are hammer-dressed so as to meet from 3 inches to 4 inches all round their bases, and to break bond in all directions. Owing to their irregularity, it requires careful inspection to see that this is done; but, as each stone is more or less irregularly wedge-shaped, such pitching is more stable than the older variety, in which the stones were laid to a smooth surface, with their broadest ends upwards and their points downwards. After the pitching has been inspected, by seeing that the stones are sufficiently solidly fixed to be immovable under a blow from a heavy hammer, the interstices should be filled each with a single well-fitting chip, driven well home. When possible, the pitching should not be constructed until the earthwork has had a year in which to settle.

This form of pitching is the cheapest practicable, but it has not a very sightly appearance. It is liable to have interstices in which the waves will have a blowing-up tendency, and through which water will readily gain access to the earthwork and saturate it. In these interstices plants grow near and above the full-supply level, and tend to disturb the pitching. They also afford a means of entry into the dam for vermin, who may thus be enabled to do a great deal of harm. The irregular tops of the stones offer the maximum resistance to the force of the waves, and are thus subject to their maximum displacing power. The proper inspection of the work is at all times difficult.

All this would be remedied were the pitching packed to a fairly uniform surface with fine concrete or very coarse mortar. This work could be carried out a year or two after the reservoir had filled, and while it was subsiding in level, so that it could be plentifully watered (to permit of proper setting) at a trivial cost. This form of pitching would, of course, be dearer than the ordinary

one, but it would be more durable and more easily inspected and maintained in good order.¹

The pitching should extend from the outlet sill level to about 2 feet above the anticipated maximum wave-wash at high flood level. Its thickness should vary at different levels with the height of the waves it has to resist, which depends upon the fetch of the wind; if taken as half their height, the thickness in feet would be $0.7 \sqrt{\text{fetch of waves in miles}}$. Practically, it would vary from 6 inches at the bottom to 18 inches at the top of the highest dams, the thickness in all cases being represented by the depth of the single stones composing the pitching.

The foundation-course of the pitching should consist of large headers sunk at least 12 inches into the natural ground, and, on soft ground, protected from being undermined by wave-wash by an apron of rubble *débris*, &c., from the waste-weir, &c. The top course should be formed of hammer-dressed headers with thin joints to prevent the upper earth guttering through them, and

should be laid in a continuous level line projecting at least 9 inches from the pitched face so as to act as a wave-breaker course, *Figs. 3 and 4*.

These precautions were taken for the pitching of the flank embankments of the large Dhupdál Weir, Belgaum Collectorate.

CLOSURE OF THE DAM.

This portion of the work gives the Indian engineer the greatest anxiety, as a temporary passage for an immense quantity of water has to be provided until the beginning of the last season, when the last gap has to be completed within seven months, as no con-

¹ The reservoir of the Stratford-on-Avon Waterworks occupies a total area of 7 acres 3 roods 4 perches; its top-water area is $4\frac{1}{2}$ acres, the average depth $18\frac{1}{2}$ feet, and its storage capacity 19,200,000 gallons. All the inside slopes up to water-level are protected by 6 inches of concrete, and above that they are turfed. (*The Engineer*, vol. lx., No. 1561, of 27th November, 1885.)

siderable amount of work can be done during the monsoon, after the commencement of which the reservoir is liable to be filled within a few days. During all this time a very large body of labourers must be kept constantly at work. The fear of an outbreak of cholera, which would effectually stop all progress, is, also, ever before his eyes.

Usual Method of Closure.—The ordinary system of the closure of a dam is shown in *Figs. 5*. The flanks A A are first constructed, leaving the narrowest possible gap in the river-bed for the passage of the monsoon discharge. The central part B has then to be completed during the last season of work. The objections to this method are :

(a) The junction between A and B is too high. A, being made at least a year before B and having been allowed to settle in the open, has, at the time of junction, attained its practically final

consolidation, whereas B is quite green. The two cannot properly unite, and there is always a risk of a leak forming at their junction.

(b) B, while quite green, is at once subjected to the infiltration due to a full reservoir ; the water thus entering

it prevents it ever attaining the density of A.

(c) B having to be carried up the full height in one season cannot be allowed to consolidate gradually by its own weight ; it is, therefore, liable to internal stresses and distortions due to unequal settlement, which will be chiefly caused by the varying effect on the cross-section of infiltration of water from the reservoir during the first few months.

(d) B having to be completed in one season, the work is, to an undesirable extent, in the hands of the labourers, and strikes and higher rates are probable. Moreover, there is the fear of cholera.

New Method of Closure.—The method of closure employed by the Author at the Hubli Waterworks, Dhárwār Collectorate, is shown in *Figs. 5*. Its advantages are :—

(a) The junction between A and B is very much less in height than in the first case. It can, moreover, be greatly reduced, if desirable, at a small further expense by forming the top of A, near

and along the junction, as a temporary dam with reduced section on the upstream side and by removing the boundary part of this at the time of final closure. In this case there would be a step in the longitudinal section of the main dam behind the temporary one.

(b) A is only subject to infiltration from a low reservoir; all the upper part of the dam, with the exception of the comparatively low part closing the temporary waste-weir, can be allowed to consolidate before water touches it.

(c) The bulk of the dam, and, in particular, its highest sections, can be carried up slowly and evenly and allowed to self-consolidate. Only the small portion closing the temporary waste-weir will have to be done in one season.

(d) The work can be executed without fear of strikes, as the final closure of B involves a relatively small quantity of construction.

(e) The construction of A will lead to the formation of a small reservoir which will be most useful for works purposes and will save much in water charges.

(f) The temporary waste-weir will often provide a level site for the location of the outlet away from the gorge embankment and below the general bed of the dam.

In very high dams it may of course be necessary to extend the system by having two or more temporary waste-weirs at higher and higher levels, but the principle of execution will be the same. The final permanent waste-weir should be left open till the last to assist in discharging flood-waters at the lowest level.

Natural sites for these temporary weirs are desiderata in all dam sites, but, if not naturally existing, they can be generally formed by excavation. Sound rock is very desirable for their bed, but, where it does not exist at the proper level, erosion of the area to be eventually covered by the dam can be prevented by constructing a curtain wall at its downstream boundary, and, if necessary, water-cushion walls below this. From this point of view the best site for a dam is one having the gorge, or river section, separated by a natural hill from the flank, so that floods may be most safely diverted from it during construction.

In England the practice is to pass all floods away from the dam during construction by means of by-wash channels, but the largeness of the Indian floods and the lengths to which the flood diversions would have to be carried, put this method of procedure quite out of the question in their case. The system above advocated may be said to be the Indian equivalent of the English practice; but, in the former, the admission of only clear water into the reservoir cannot be arranged for as in the latter. Clear-

water flows would not, however, suffice for replenishment, owing to the sudden diminution of river discharges on the cessation of floods.

In a purely earthen dam the closure of the river gorge should be done by carrying up the full section right across it to the required height above the temporary waste-weir. If a reduced section is first carried up on the waterface and the rear part subsequently added, this latter will have a tendency to slip off during settlement and under the immense pressure of this the highest part of the dam. If, on the other hand, the width of the gorge is first reduced by patching on flank embankments, during settlement there will be a tendency to produce cracks and leakage planes at right angles to the section. By the system of forming the base of the gorge section with massive drystone toes (*post*, p. 156), both these methods of reducing the amount of work involved in the closure may be adopted with perfect confidence as the toes will give a large amount of support and prevent slipping, and their construction will prevent the formation of a direct leak through the dam.

In Figs. 6 and 7, Plate 3, this form of closure is shown for two proposed reservoirs:—the Máládevi (Ahmednagar Collectorate) and Tárálá (Sátará Collectorate). Taking the general cross section, Fig. 8, it will be seen that, in the first season, of the central part, the first 20 feet (vertical) of the whole of the upstream toe and the first 6 feet of the whole downstream toe can be constructed. These will be protected from the monsoon discharge by the concrete walls at their rear, and the central wall, designed for permanently cutting off leakage, will act as a temporary water-cushion. The flank portions of these toes and the central hearting of the dam between them will be carried up with comparatively low steps well set back from each other. This central hearting will have its sides protected from the scour of floods by heavy pitching, which will have to be removed before the rest of the dam is constructed. The temporary water-cushions will serve to moderate the violence of the flood waters.

In the case of Máládevi, only the left bank need be thus treated, the natural spur being left on the right bank. In the second season the closure will be effected by completing the upstream drystone toe, whose rear concrete wall will cut off leakage, and by constructing a reduced section of the dam in its rear to the level required by the temporary waste-weir. In the third season the whole section will be completed to this level, and the rear earthwork will be held up by the completed downstream dry-

stone toe. Subsequently, the whole dam outside the temporary waste-weir will be completed, and the final closure of this latter will be carried out in one season to the full section throughout, or, where this involves a large quantity of earthwork, the top 10 feet may at first be safely raised with a reduced section on the waterface and may be completed during the following season.

For the lower Tārlā reservoir one temporary waste-weir, aided by the excavation of the permanent one being left open, will probably suffice. For Málādevi, two such temporary waste-weirs, also aided by the excavation of the permanent one, will probably be necessary and can be arranged for.

The following Table illustrates the saving in quantities effected by the use of drystone toes as compared with those necessary for ordinary gorge embankment closures in pure earth. To allow for the slower work of constructing the drystone toes, compared with ordinary earthwork, in the comparison the quantities of the former are doubled. The comparison is made with two forms of closure for the purely earthen dams: (a) of the benched gap only as designed for the "compound dam"; and (b) of the whole natural gorge in one operation. The latter is the only safe form for the closure of an earthen dam.

COMPARATIVE STATEMENT OF QUANTITIES REQUIRED FOR THE CLOSURES OF THE GORGE EMBANKMENTS.

Name of Reservoir.	"Compound Dam."			Earthen Dam. (10 feet top width, slopes 3 to 1 and 2 to 1.)			
	Earth-work.	Drystone.	Total, Col. 2 + twice Col. 3.	Benched Gap only.		Whole Gorge.	
				Earthwork.	Per Cent. of Col. 4.	Earthwork.	Per Cent. of Col. 4.
1	2	3	4	5	6	7	8
Málādevi	cub. ft.	2,554,000	1,329,000	5,212,000	11,036,000	13,642,000	262
	cub. yds.	95,000	49,000	193,000	409,000	505,000	
Tārlā	cub. ft.	775,000	815,000	2,405,000	3,788,000	10,956,000	456
	cub. yds.	29,000	30,000	89,000	140,000	406,000	

Seeing that not more than 180 working days are available, and that the working area is comparatively small, it is not safe to count upon much more than a progress of 5 million cubic feet

(185,000 cubic yards) in one season. The closure of the compound dam is thus much more feasible than that of the ordinary earthen one.

The high flood-discharging capacity of the temporary waste-weirs should be made equal to that of the permanent one. As their flow will be uninterrupted by masonry work, their capacity for discharging the flood in its rise, foot by foot, will be greater than that of the permanent one, whose lower portion is restricted to sluice-ways between massive piers. On the other hand, the flood-absorbing power of the reservoir itself, at the lower levels at which they are placed, will be less than it is at the higher ones of the permanent waste-weir.

DESIGN OF LARGE EARTHEN DAMS.

Deficiency of the Theory of Earthwork.—Properly constructed dams are amply sufficient to resist the pressure of the water they hold up. The only way it can and does act prejudicially against them is by infiltration, thus diminishing their frictional resistance and adhesion. The risk of failure lies in the liability of the earthwork itself to slip. There have been many mathematical investigations as to the behaviour of earthwork, but these have naturally been confined to laboratory experiments; and, although they are most useful in indicating the character of the forces at work, they cannot, from the nature of things, be based on actual and comprehensive data, and cannot, therefore, give the actual amounts of those forces in all the varying circumstances which occur in practice. This is borne out by the two most recent Papers on this subject presented to the Institution. Sir Benjamin Baker,¹ Past-President Inst. C.E., has given numerous examples showing that the lateral pressure of earthwork against walls is, at most, only one-half of that pointed out by theory, and he concludes that practical considerations, rather than theoretical ones, should be taken into account when designing them to resist earth pressure. Mr. G. H. Darwin,² M.A., F.R.S., concludes:—"The soundest view seems to be that engineers have no better practical course open to them than, neglecting the elaborate formulas which have been suggested, to work with semi-empirical rules such as those of Coulomb, and to allow a large coefficient of safety."

¹ Minutes of Proceedings Inst. C.E., vol. lxxv. pp. 207, 208.

² *Ibid*, vol. lxxi. p. 378.

Rankine¹ has stated :—"There is a mathematical theory of the combined action of friction and adhesion in earth; but for want of experimental data its practical utility is doubtful."

General Causes affecting the Stability of Earthwork.—Earthwork gives way by the slipping or sliding of its parts on each other. The resistance to this is due, partly to the friction between the particles, and partly to their mutual adhesion or cohesion. The friction is measured by the angle of repose, and constants for it for different soils have been determined; these are coefficients of the weight of the mass. It is greatest for coarse and least for fine soils; on it depends the permanent stability of natural earthwork. The adhesion, or cohesion, may be measured by the depth to which an unsupported face of earthwork will stand; but it is an extremely varying force, depending largely upon the state in which the material is. It is increased by a moderate amount of moisture, but is diminished by excessive wetness. The cohesion of clays is considerable, and is largely increased by a small amount of moisture. A slight addition of moisture also increases the coefficient of friction, but an excess of it acts as an unguent in diminishing it. It is, therefore, evident that any given earthwork, other things being equal, will be most stable when slightly damp, and least stable when charged with water. Its stability, therefore, depends upon the ease and thoroughness with which it can be drained of superfluous and dangerous water. Professor Rankine² sums up the matter thus :—"The properties of earth with respect to adhesion and friction are so variable that the engineer should never trust to tables or to information obtained from books to guide him in designing earthworks, when he has it in his power to obtain the necessary data either by observation of existing earthworks in the same stratum or by experiment."

"Historical Element" of Earthwork.—There is a further cause of variation in the behaviour of soils, and that is what Professor Clerk Maxwell has called the "historical element," which term not only comprises the manner in which the mass was put together, but also includes the different causes at work which have subsequently modified it. The effect of constructing the earthwork so as to give it initially the greatest resistance to slipping outwards has already been noticed. In nearly all earthworks, the practice is to treat the material as homogeneous from top to base, and to adopt a uniform slope throughout. The lower portions in a large dam must, however, be in a very

¹ "Civil Engineering," p. 324.

² *Ibid.*, p. 317.

different condition to the upper ones, as they are much more highly compressed and are moister. Probably the enormous superincumbent weight causes some stratification of the lower parts and diminishes their cohesion, while the increased smoothness, due to the pressure, will lessen their frictional resistance. The amount of increase of frictional stress, according to the depth below the surface, depends upon the viscosity of the earth enabling it to transmit pressure, and this must vary from point to point on the cross section. The increase in moisture at the base will diminish both the frictional resistance and the cohesion. The variation of the materials, their disposition and the methods of construction introduce further elements of change, so that there are numerous entirely hidden forces at work whose magnitude and resultant action can only be determined by the experience of the works themselves.

In Nature it is seen that hills, or even large masses of soil, have not an even slope, but one that varies from steepness at the top to flatness at the base (*e.g.* Fujiyámá in Japan). Although this form is partly due to the effects of denudation, it is also partly due to the natural slopes assumed by the material of the hills. Slips of earthwork show, at first, a similar, but more pronounced, outline. It is known, moreover, that the limit of height of ordinary earthen dams is comparatively low.¹ French engineers have placed it at 60 feet, and, although there are instances of greater heights having been successfully accomplished, engineers, as a rule, view the construction of these higher dams with distrust. Low dams can be constructed with much steeper slopes than high ones. The water-faces of dams require a flatter slope than the rear ones. From these considerations it may be deduced that in an originally homogeneous dam with plane slopes the resistance to slipping decreases with the height from the top, and that the proper section is one having the slopes continually flattened towards the base. An "empirical section" on these principles is shown in dotted lines on Fig. 8, Plate 3. Taking the whole cross section into account, it will be seen from this that a very considerable flattening of the base slopes results in a comparatively small increase of the original area.

¹ Probably the highest earthen dam ever constructed was that of Estrecho de Rientes, near Lorca, Murcia, Spain, which was 150 feet high. It was commenced in 1755 and finished in 1789. The reservoir was filled for the first time in February, 1802, and the work was breached in the following April, destroying part of Lorca and drowning 600 people. The immediate cause of failure is not known. (*Vide* Mr. Gravel's Paper, *The Engineer*, vol. lxiii. p. 208.)

The Use of Berms.—In some large works, instead of flattening the slopes, the increase of base has been obtained by adding berms having the same, or nearly the same, slope as that of the upper part. Assuming the theory of the angle of rest to be correct, the earthwork in these berms is not in so stable a condition as that having the continuous flatter slopes. The total frictional resistance of the dam is a measure of its weight, and is independent of the size of the base, but its cohesive resistance is a measure of its base area. The material in a berm would, therefore, be more effectively distributed with a flatter slope. The chief advantage of a berm is to weight the surface of the dam, and thus to prevent its bulging. Another advantage of a berm is that, by its sudden increase of the section of the dam, it tends to prevent any dislocation at the top from extending to the base.

Fig. 13.

It is advisable to utilize berms for passing off the surface drainage produced by heavy rainfall, which is very considerable on a large slope area. This can be safely done by paved or watertight drains, as shown in *Fig. 13*, discharging at the downstream edge of the berm on to the natural ground. Such drains, if not watertight, would be a source of danger as they would tend to produce a definite line of supersaturation in the heart of the earthwork which might lead to the formation of a slip.

Objections to High Earthen Dams.—The “empirical section” is not recommended as a complete solution of the problem of constructing a high earthen dam. Earthwork being viscous, a small disturbance at one point is likely to extend and to cause in time a large one lower down, and it is, therefore, necessary to guard against this; the higher the dam, the greater the risk of failure. Now the highest sections of dams occur in the worst situations for

stability. The most economical line for the whole dam is generally along ridges which terminate abruptly at the river, forming a gorge. The gorge embankment is, therefore, at neighbouring points on the longitudinal section, of greatly differing height, Figs. 6 and 7, Plate 3, and this causes the formation of internal stresses during settlement. The natural steep side-slopes tend to produce slipping off of the whole mass, and the bed will generally have some fall downstream which will aid this tendency. This part of the dam will therefore be in a condition of more or less unstable equilibrium. The upstream slope will be supported by the water-pressure, or, if this is absent, by its greater mass; the two ends will be supported (or their outward motion resisted) by the natural ground or by the flank embankments, while the downstream slope will be dependent upon itself for support against the resultant stress which will be directed towards it. The tendency will, therefore, be for the dam to slip downstream, and all the slips of large earthen dams in Bombay have thus occurred, no slips of the upstream portion being known. Of course, if the upstream slope be steepened so that, with its reduced coefficients of friction and cohesion produced by water infiltration, it is relatively weaker than the downstream one, it will be the first to give. The result of experience is that the usual 3 to 1 water slope, even charged with water, is more stable than the 2 to 1 downstream one which is never exposed to the direct action of the reservoir. This latter slope is, however, in India subject to the great variations of the climate, being baked by the sun for months, and then sodden by the monsoon deluges during others. It is so wet in this latter season that its condition approximates to that of the water slope, and a less difference in the ratio of the two is necessary to give them the same slip-resisting power. It is for this reason that the "empirical section," given in Fig. 8, Plate 3, provides for a relatively greater increase, beyond the usual section, to the downstream than to the upstream slope.

Typical Sections.—The sections hitherto employed for Bombay dams are given on Fig. 14, Plate 3. The original one was defective in its narrow top width and steep top slopes, which rendered it difficult to make up any large amount of settlement. Appendix I, compiled from official sources, gives details of some of the typical earthen dams constructed according to these sections.

Top Width and Height above High-Flood Level.—The top width advocated is 10 feet throughout. The increase to this dimension will make it more in keeping with the general scale of the work. The variation in height above high-flood level of different parts of

the dam will differentiate them sufficiently without the need for altering their top widths as well; a uniform width will give the work a better appearance. With the crest wall on the upstream face the heights of the dam above high-flood level may be:—

	Feet.
(a) Gorge embankment and flank embankment over 50 feet high	7
(b) Flank embankment, 20 feet to 50 feet high	6
(c) Breaching section	5

The Puddle Wall.—The principal difference in construction between English and Indian dams is that the latter have no puddle wall, being constructed throughout of watertight material which obviates its use. The only plea which can be raised in favour of the puddle wall is that it is economical by limiting the amount of careful construction. Its use implies that reliance cannot be placed on the upstream half of the dam to resist water infiltration. To have so large a mass strongly saturated is very dangerous. The puddle wall is liable to become distorted and fissured during settlement, and the non-homogeneous construction of the dam involved by its use is distinctly adverse to its permanent stability. The following are examples of the dimensions of certain puddle walls:¹ (a) Dale Dyke dam; top width, 4 feet, batters 1 in 16, giving a base width of 16 feet where the dam is 95 feet high, which is very light. (b) Vehár dam for the Bombay waterworks; (in this particular not a typical Indian dam) top width 10 feet, batters 1 in 8. (c) The Bann reservoir and the Harelaw reservoir have both a top width of 8 feet.

Settlement.—The amount of settlement is usually taken as one-thirtieth or one-thirty-sixth of the whole height. It depends greatly upon the rate at which the dam is constructed. If it is raised slowly and uniformly, each season's work will nearly attain its full consolidation before the next is commenced, and the proper allowance for settlement will thus be at a minimum. In such a case one-fiftieth might be allowed. In addition to this the gorge section should be raised one foot higher as a precaution against its ever being topped. For the same reason the lowest and therefore the least important part of the dam should be raised one foot less than the general flank embankment so as to form a "breaching-section," which would be topped before the more important parts. The best location for this breaching-section is at a minor saddle on the longitudinal section where the founda-

¹ *The Engineer*, vol. lxxiii. p. 189.

tion is hard, so that the flood resulting from a breach would be shut off from the main dam and its erosive action would be limited. Where such a saddle does not exist, a flood embankment might be constructed at right angles to the dam and retired some distance from the breaching-section.

The Compound Dam.—If the gorge embankment can have its sides confined by strong toes of some non-viscous material up to the base level of the flanks, the enclosed earthwork will be prevented from moving in any direction, and, when it is thoroughly consolidated, the upper part can be raised on it as an ordinary embankment. This constitutes the leading idea of what is now put forward as a “compound dam.” The toes, if formed of trap-drystone, which has a specific gravity of 2.50 and a coefficient of friction of 0.71, compared with 1.60×0.50 , the relative figures for moist clay, will have a frictional resistance about $2\frac{1}{4}$ times that of an equal bulk of earthwork. To give them cohesive resistance, and to prevent, on the upstream face, the inflow of water, which would lessen the effective weight, the drystone should be packed tight with clayey murum. The stone would, of course, be the roughest of rubble, and probably much of it would be obtained from the waste weir and other excavations. It would be laid with its beds normal to the slope to increase the frictional resistance. The work could be done by unskilled labour, at a cost not exceeding three times that of the earthwork; and, as the material could be stacked near beforehand, at nearly the same pace as the latter, which is a matter of great importance when the closure of the gorge is taken into consideration. To give greater frictional resistance, rubble masonry or concrete toes and core-walls are inserted along the base. The waterface of the upstream toe is covered with concrete to prevent water from entering and buoying it up, and its rear face ends in a battering concrete wall which enables the earth-pressure of the dam to be evenly distributed over it, and is useful in closing the gorge.

It may be urged that the drystone toes might be replaced by masonry retaining walls, but the proper design for these, with so large a surcharge, would be somewhat doubtful, and sufficiently massive ones would exceed the proposed toes both in cost and in time for execution. It would certainly be hazardous to construct drystone retaining walls, and the material saved by their use would not compensate for the loss of the extremely stable form of the toes, which receive the direct normal pressure of the dam and distribute it over a large cohering base.

The downstream drystone toe prevents the exposure of a large

slope area of earthwork to the effects of heavy rainfall, and thus surface drainage of the downstream slope is not necessary. Some engineers consider that earthen dams should not be constructed in extremely rainy localities, but the Máhableshwar dam, about 30 feet high, which withstands an annual fall of 250 to 300 inches of rain (as much as 150 inches have been registered in the single month of July), and the Kás dam, 56 feet high, with an average annual rainfall of 140 inches, are instances to the contrary. Both these dams are in the Sátará Collectorate near the crest of the western Ghauts.

To cut off leakage at the base of the dam, a concrete wall with masonry facings is provided along the centre line, and this serves as a water-cushion during the preliminary closure of the gorge. Just behind it is a continuous parallel drain formed in the usual way, and this leads out of the dam by the "rear drain" of similar construction.

The slopes of the dam are varied in accordance with what has been stated above. On the water-face and for 20 feet below the surface is a $2\frac{1}{2}$ to 1 slope, and below that, to the drystone toe, a 3 to 1 slope. On the downstream side the top, up to full supply level, is at $1\frac{1}{2}$ to 1, and thereafter the slope is at 2 to 1. This reduction of the slope at the top will effect some saving on the whole length of the dam, while it extends for so short a vertical height that any making up of the crest, required by settlement, can be easily effected.

The crest of the dam on the upstream side is formed by a wall, the extra cost of which will be met by the consequent saving of earthwork effected down the whole slope. Compared with the section having a $1\frac{1}{2}$ to 1 slope at the top, at the ordinary rates of the different classes of work, its cost will be the same for a total height of 55 feet; less for greater, and greater for less heights. Similarly, compared with the continuous 3 to 1 slope, the costs will be equal at a total height of 27 feet. It will be a more efficient and permanent form for resisting the action of the waves and for preventing infiltration, and it will protect the dam up to its crest. It should of course be constructed on a wide foundation of concrete, after the dam has attained a practically complete settlement, and this can be easily done by the general plan advocated for the gradual construction of the earthwork. The water-face is protected by stone pitching packed with concrete, or entirely of concrete, constructed after the dam has had time to settle.

The proposed general section for the flank embankment for

total heights up to 60 feet is given in Fig. 9, Plate 1. It is the same as that for the upper part of the compound dam. Where the flank exceeds 60 feet in height, it will be best to construct its base as a compound dam. This form of compound dam is of course only economically feasible where durable stone can be obtained cheaply and abundantly. This is likely to be the case at the sites of gorges, which imply the existence of hard materials, and it is for such sites that the type is best suited.

The ordinary earthen dam is the cheapest form of construction. For heights up to 60 feet it is quite safe, but its closure is difficult, and if this is not carried out in the way described under that head is likely to prove dangerous to stability. It does not require such expensive and solid foundations as are necessary for masonry dams. As all materials for its construction are obtainable close at hand, labour on it can be concentrated and easily supervised. This makes it the best class of work for famine labour, and under the present financial conditions of India, it is likely that such large constructions will be sanctioned only as famine relief works. It has the great advantage that it can be raised from time to time to meet the demands for more water, or to restore the deficiency of storage produced by the silting up of the reservoir. Its construction will generally be the quickest of all, thus enabling the work to be put in operation at the earliest date. For it the bulk of the labour required is unskilled and can thus be most easily obtained. A design for Máládevi reservoir was estimated to cost Rs.1,005,000.¹

The compound dam described above shares all the advantages of the ordinary earthen one, and, in addition, has the further ones that it can be safely raised to a considerably greater height, and that its closure is safe and comparatively easy. It will, however, be somewhat more expensive.

The masonry dam is the most stable form. It however generally requires deep and expensive foundations, and is, therefore, not suitable to all sites. Its construction is expensive and slow. It cannot be raised beyond the originally designed height, and the only way to diminish the tendency of the reservoir to silt up is by a system of undersluices which will keep the water-level low during the early part of the monsoon. It is the best form for deep water-supply schemes where risk of failure must

¹ The value of a rupee varies with currency fluctuations. For such works of a local character it may, however, be taken at its old value of Rs.10 = £1. At this rate the actual cost of labour is probably about one-third of its cost in England.

be avoided at all costs. A design for Máládevi reservoir was estimated to cost Rs.3,011,000.

The composite dam, having a masonry crossing of the river gorge with earthen flanks, shares the advantages and disadvantages of the two forms of structure entering into its composition. The formation of watertight junctions between the parts will involve additional but very necessary expense. A design for Máládevi reservoir was estimated to cost Rs.2,132,000.

EARTHWORK SLIPS AND THEIR REPAIR.

The fact that ordinary high earthen dams are liable to sudden and unforeseen slips, which may cause the breach of the reservoir and consequent damage to life and property, and will certainly involve expensive measures of repair and loss of revenue, renders them a somewhat untrustworthy form of construction. It is far better to prevent the formation of such slips at some extra capital outlay during the progress of the work, than to run any risk for the sake of a comparatively small original economy. The preceding sections have described precautionary measures, both in construction and design, and where these are adopted the chance of failure will practically disappear. A slip is the only form of damage that need be considered here. The overtopping of a dam is due to insufficient waste-weir provision, and the failure of an outlet is due to errors which are pointed out under that head. A slip may be caused in the following ways: by faulty foundations; unequal settlement producing internal stress and subsequent motion; defects in the construction or design of the dam; infiltration of water.

Faulty Foundations.—Foundations may be faulty from two causes: they may be compressible or they may be badly seated. As regards the first of these it may be stated that most dry soils can withstand the weight of a dam. Argillaceous, or partially impervious ones, are likely to give when saturated. A deep clay seat is therefore undesirable for a dam; but, where it exists, it must be rendered as compact and dry as possible on the downstream side, by a series of deep dry rubble drains parallel to the centre line, with cross outfalls as frequently as can be arranged. On both sides the slopes of the dam should be flattened so as to secure a wider base. Berms may also be added at the bases of the slopes to prevent the rise of the subsoil. If the dam is founded on a stratum which is tilted and rests on a lower one with which it is not firmly united, the extra weight on it may cause it to slide and

carry the embankment with it. Careful geological investigation is necessary to avoid this source of danger.

Unequal Settlement.—Wherever the longitudinal section of the dam varies greatly in height, and wherever the construction has not been uniform and slow, and junctions have been formed, there is a risk of the occurrence of unequal settlement, which will cause internal stresses and subsequent motion. The effect would be intensified by the action of the water which might thereby percolate from the reservoir, thus saturating the earthwork and forming a slipping plane. The place where this will most frequently occur is, of course, that where the dam was closed, should this have been done in the usual way at the river-crossing. Slips have occurred in some Bombay dams at this place, and years after their construction, showing that some slow disintegrating force, such as that described, has been at work.

Defects in Construction or Design.—The use of too permeable materials will cause a breach rather than a slip; but with ordinary care in construction, they become too compact to allow of dangerously excessive percolation. Friable materials, too loose to bind and totally wanting in cohesion, may form a slipping plane and lead to failure. Pure clays are dangerous in that their cohesive and frictional resistances become very largely reduced when charged with water, and too liberal use of water during construction is, therefore, to be strongly deprecated. Through a defective design the earthwork may be unable to support its own weight, and will slip so as to assume more suitable slopes. The profile which is only just sufficient for a dry embankment will prove too slight when it is subject to water infiltration.

Infiltration of Water.—This is the principal cause of slips, as it operates in aiding all the others to produce failure. Thorough drainage of the earthwork and of its foundations is, therefore, essential to secure stability.

The practice in dealing with slips of railway cuttings and embankments has been dealt with in the Proceedings.¹

Although Indian dams are carefully constructed, still slips occur. Frequently the initial cause is obscured by the fact that several are at work together. These slips, when extensive, are of the same general form, S-shaped in vertical section, with the concave portion at the top and the convex at the bottom (when looked at from the base), and, in plan, concave to the centre-line

¹ Minutes of Proceedings Inst. C.E., vol. lxii. pp. 272, 280 and 285; vol. lxvi. pp. 256-265.

of the dam, *Figs. 15.* The layers at the base are generally tilted at an angle of about 20° to the horizon, so that the inward thrust there preserves equilibrium with the outward one from the top.

Where a slip occurs in pure black soil, its surface presents a smooth, unctuous appearance, striated by the small particles of contained grit, and parallel planes of similar surface are formed for some feet on both sides of it. It is doubtful if these will ever disappear of themselves; the result is that the fallen mass rests on a series of steeply tilted smooth, lubricated planes, and the slightest additional weight, produced either by adding more material to it or by the soakage of rain-water, will tend to cause further motion. The whole of the slipped earth has also lost all

Figs. 15.

THE SLIP OF THE WÁGHÁD DAM.

the consolidation artificially given to it during construction. It is traversed by minor slipping planes and by fissures, all of which will admit rain-water and cause it to have a greatly reduced frictional and cohesive resistance to motion. No dependence can therefore be placed upon it, and a sound system of repair consists in entirely removing it and in replacing it by trustworthy material.

Where a slip occurs in earthwork having proper proportions of clay and grit, the latter will enable the whole to re-unite gradually, but the junction will, of course, be always a plane of weakness. This property of re-union of gritty soils is a valuable one. The slipped portion will also be fissured like one of pure clay, but the gritty particles will admit of slow self-drainage, so

that after a couple of years the earth-work will attain a fair amount of self-consolidation. The fallen mass when properly drained may, therefore, be utilized in reconstruction, care being taken to weight it very gradually, so as to let each season's work attain a practically final consolidation before the next is raised on it, and to maintain instrumental observations to detect the smallest motion. When this occurs, further additional weight should not be put on until the toe is properly buttressed.

The first thing in all repairs is to drain the slipped earthwork by drains at right angles to the axis of the dam. Of these, one should be at the centre of disturbance, and two should be along the junctions of the slip with the solid embankment; others should be inserted at convenient intermediate distances. They should be taken out, in timbered trenches, from the toe to a little beyond the innermost slipping plane, and should extend vertically throughout the mass. As soon as the excavation of each is completed, a longitudinal base drain with 4-inch breadth and 6-inch depth vent should be laid, and the trench should be filled with drystone having gravel casings at the sides and a 2-foot cover of fine stuff and earth at the top; otherwise it will rapidly choke. Not only do these drains serve their initial purpose of passing out soakage water harmlessly, and thus allowing the fallen mass to consolidate itself, but they also divide it into independent sections. It is unlikely that all these sections will tend to slip at once, and thus each at the time of initial motion is supported by the resistance of a length of the toe works considerably longer than itself. Where practicable, and when the fallen mass has been drained, the whole line of the slip should be followed up and cut out so as to get rid of the slip planes. This may be done in difficult cases by means of a timbered trench. The refilling should consist of gritty clay, with a good base drain communicating with those of the cross drains above mentioned.

The next step is to construct a strong, well-drained drystone wall parallel to the axis of the dam, and with good batters against the slip, to give the new earthwork the needful increased stability, for it will not have, bulk for bulk, the resistance of the original construction. If the fallen earthwork is to be entirely removed, this wall may be placed about the centre of the slip; if that is to be allowed to stay, it should be at its toe. To add to the stability of the repair, a strong earthen berm should be placed just below the original base, and the toe of this should be secured by a second drystone wall. All these drains and walls should, if possible, be founded on rock, but where this is not to be

found at a reasonable depth, they should be carried well into the natural subsoil and beyond the limit of disturbance. Earthwork usually fails at one point, and, as soon as it commences to move, drags the adjacent parts with it. The drystone walls, instead of transmitting the pressure directly behind them, distribute it over a certain increased area, and thus tend to prevent the initial motion. They thus act like the timbering of a trench, which, although incapable of resisting the full lateral pressure of the earthwork, provides sufficient support to prevent the first tendency to slipping.

All excavation should be carefully taken out in sections, with sufficient widths of undisturbed material between them to act as buttresses, and should be filled as quickly as possible. This, of course, results in the filling not being so well compacted as if a large area were dealt with at once, but time will remedy this. It also leads to the formation of numerous junctions, but as the sections will be constructed within a short time of each other, the earthwork on each side will eventually unite in a practically solid way.

The slip of the river-crossing of Wághád Dam, Násik Collectorate, where the designed height was 95 feet, of which 87 feet were completed, was repaired by first digging three drains at right angles to the axis of the dam. As the slip (of black soil) stood fairly well during one monsoon, it was determined to reconstruct the embankment on it, but when only a few feet had been raised, further motion was observed. As the slip was too extensive to be removed entirely, a large trench, about 250 feet long, with base width of 30 feet, side slopes 1 to 1, and maximum central height of 40 feet, was dug about half-way up it down to rock, and was refilled with drystone; a strong earthen berm was also added. The repair has answered, but the reconstruction of the dam has had to be very slowly carried out.

The less extensive slip of the 74-foot high river-crossing of Nehr Dam, Sátará Collectorate, was repaired by excavating three main and two minor drains at right angles to the axis of the dam. In the following season the line of slip (of black soil) was excavated and the fallen earth removed and replaced by good material. In the next season a strong drystone toe-wall, with base drain, was constructed, and a berm carried up in rear. The repair is not yet completed, but it will most likely be successful.

THE WASTE WEIR.

There are two usual kinds of waste weir: Drowned weirs or channels, and clear overfall weirs. Both of these classes are of a simple nature and their selection depends upon the nature of the ground and its levels. The channels have a level up-stream approach, and, down-stream of the weir crest, a fall of 1 in 100 to facilitate the passage of the flood with a small tail depth. The weirs are generally formed by rubble walls, protected from erosion in a few cases by aprons or water-cushions.

Where the natural level and formation permit, it is better to gain increased discharging power by converting (a) into (b). The following Table shows the discharging power per foot run of weir of the two classes:—

DISCHARGE OF WASTE-WEIRS PER LINEAL FOOT.

Total depth of Flood, in Feet . . . }	1	2	3	4	5	6	7	8	9	10
Drowned channel (approximate) cub. feet per sec.	2·38	7·29	13·70	22·32	32·55	43·92	57·04	71·87	87·92	106·05
Clear overfall cub. feet per sec.	3·57	10·08	18·53	28·53	39·87	52·42	66·05	80·72	96·30	112·73

As regards position, waste weirs may be thus classified: (a) Flank weirs, at the immediate flank and in continuation of the embankment; (b) Saddle weirs, separated from the dam by naturally high ground.

The first kind require wing-walls to protect the end of the dam from scour, and, in some cases, a downstream lining, or curtain wall, to prevent the floods from outflanking and washing the downstream toe of the dam, or to divert the flood into a certain course. The junction of the waste weir with the dam is best effected, as shown in *Figs. 16*, by a stepped passage, which permits of easy access, and, at the same time, acts as a staunching fork. It is always desirable to excavate the tail channel with a small cross-sectional fall away from the lining wall in order to assist in diverting the floods.

The second require no such protective works. They discharge either back into the original stream or into an adjacent one.

The most desirable outfall for all waste weirs is one into the original stream as near to the dam as possible without injuring the works or interfering with their drainage. This last is a most

important proviso as the floods, when cutting out a new channel for themselves, bring down a large amount of detritus. Where the outfall is to another stream, unless its channel is ample to pass off the added drainage, damage will be occasioned to the neighbouring lands. The bed, too, of the original stream, being deprived of scour, will silt up, become marshy, covered with bulrushes and reeds, and malarious. The subsoil water-level of the near lands will be raised and perhaps a saline efflorescence will be formed, and they will become uncultivable.

After the tail channel has reached the natural surface, no further protective works, such as cushion walls, are generally required, as the floods scour out for themselves a channel down to rock or other hard material which confines them to limits. "Retrogression of levels," or the scouring away and deepening of the tail channel back to the waste-weir itself, was much feared in the early days of reservoir construction, but this extent of denudation has not occurred as yet, and it may be arrested, when necessary, by building cross walls to serve as JUNCTION OF THE WASTE-WEIR WITH THE DAM. water-cushions.

The amount of excavation of the tail channel, when it is long, may be considerably reduced by gradually diminishing its breadth, care being taken, when doing so, not to increase the tail depth of the floods at the weir crest itself, *Fig. 17*.

The depths of the maximum floods generally allowed on the waste-weirs vary from 4 feet to 6 feet, and the weirs are, therefore,

of great length. This margin of safety between full-supply level and high-flood level involves what may either be taken as a very expensive addition to the cost of the dam, or as a surrendering of a large amount of storage. In a few cases the temporary raising of the reservoir level at the end of the monsoon by a small amount, either by low earthen banks, or by teak shutters fitted into rolled beam uprights, has been attempted. The length of the weirs makes this expensive, and the design of the existing works makes it difficult to arrange for automatic or quick-acting flood discharges without which such temporary raising is attended by an undesirable amount of risk.

Mr. Craig¹ has investigated the causes leading to the "maximum flood discharge from drainage areas, with special reference to India," and has deduced the following formula for it:—

$$D = 440 B (C v i) \text{ hyp. log } \frac{8 L^2}{B}$$

where D is the discharge in cubic feet per second; B , the mean width of the area in miles; C , the coefficient of discharge, varying with the nature of the basin; v , the velocity of the drainage in feet per second; i , the rainfall in inches; L , the length of the catchment in miles, measured from the point of discharge to the centre of the watershed base.

For irregular catchments the perimeter has to be rectified by straight lines, and the whole area divided into triangles with their apices at the point of discharge. The total discharge is the sum of the discharges of the component triangles.

As this formula takes into account the varying width of catchments, their slopes and the amount of rainfall, it is more correct than Dickens' formula, which is:—

$$D = 825 M^{\frac{2}{3}},$$

where D is the discharge per cubic foot per second, and M , the catchment area in square miles.

Scale, 1 inch = 1,000 feet.

PLAN OF ORDINARY WASTE-WEIR.

¹ Minutes of Proceedings Inst. C.E., vol. lxxx. p. 201.

Formulas are, however, not usually employed for calculating the maximum discharges of waste-weirs, partly because the coefficients would have to be worked out with insufficient data, but chiefly because the areas are comparatively so small that the maximum rainfall is fairly constant over them, and its duration is so long that time is given for the maximum flow of the tributaries to arrive at the point of discharge at nearly the same time. The exceptionally heavy rain, which is the only one to be considered in this respect, is usually very widely spread. For instance, all over the Deccán, the maximum floods of 1872 and 1882 occurred on the same days. Moreover, seeing what a disaster would be caused by the overtopping and bursting of a dam, it is advisable to always make very liberal waste-weir provision; the average cost of this is only one-eighth of that of the whole reservoir. The general practice in Bombay is to make the following allowances for average catchments:—

TABLE OF WASTE-WEIR RUNS-OFF.

Catchment Area in Square Miles . .	0-5	5-10	10-25	25-75	75-150	Over 150
Run-off in inches per hour . .	2.00	1.50	1.25	1.00	0.75	0.50

Special circumstances have, of course, to be considered; a purely ghaut catchment would be given a greater, and a purely plain one, a smaller allowance. The general intensity of heavy rainfall in the locality and flood records would also have to be taken into account.

The most noticeable feature of Indian waste-weirs is the extremely large amount of water they may have to discharge. Appendix II gives details of some heavy falls and severe floods.

The discharge of weir channels is calculated by the formulas:—

$$(a) D = a \sqrt{r} \cdot c \sqrt{s}$$

$$(b) D = c_2 b \sqrt{2g d_1} \left(d_2 + \frac{2}{3} d_1 \right), \text{ or } \frac{D}{c b \sqrt{2g}} = \sqrt{d_1} \left(d_2 + \frac{2}{3} d_1 \right),$$

where D is the discharge in cubic feet per second; a, the cross-sectional area of the flood in square feet; r, the hydraulic mean radius = $\frac{\text{area (in square feet)}}{\text{wetted perimeter (in feet)}}$; c, Bazin's coefficient for the tail channel; c_2 , the afflux coefficient; s, the slope of the tail channel = $\frac{\text{fall}}{\text{length}}$; b, the breadth of the weir in feet; d_1 , the height

of the flood afflux in feet; d_2 , the depth of the tail channel discharge in feet; g , the force of gravity. D and s being given, then $a (=b \times d_2)$ is found by trial in the first formula. From the second formula d_1 is ascertained, generally by trial to avoid a cubic equation. The height to which the flood will rise in the reservoir is $d_1 + d_2$ and this has to be provided for.

A Table of discharges of a 200-foot waste-weir cut with a tail channel slope of 1 in 100 and with total flood depths varying foot by foot from 1 foot to 20 feet is given in Appendix III. As the discharges vary with the extent of the flood's wetted perimeter, the flows of weir channels of the same depth are not in exact proportion to their different widths, but, as the wetted perimeters of such floods very nearly vary with their widths, for all practical purposes, the discharges of such floods may be taken as proportionate to their widths, and especially is this the case for the small depths which are generally required. Examples bearing this out are given below:—

Length of channel feet	1,000	1,000	50	50
Total depth of flood "	2	10	2	10
By direct calculation cub. feet per sec.	7,322	106,555	362	5,180
Deduced from Appendix IV "	7,285	106,050	364	5,302

The discharge of clear overfall weirs is given by the formula:—

$$D = 3 \cdot 57 b \sqrt{H^3},$$

where D is the discharge in cubic feet per second; b , the width of the crest overfall in feet; H , the total height of the afflux above the weir-crest in feet.

The existing system of waste-weirs with level crests at full-supply level is best suited for reservoirs whose replenishment is not certain. The level of these has to be kept as high as possible all through the rains, so that no storage may be lost. Such reservoirs are not situated, as regards replenishment, in the most favourable positions. The greatest objections to such weirs are that they keep the reservoirs full during that part of the year when it is most difficult to effect repairs; they prevent the reservoirs being rapidly emptied, when necessary, in the case of accidents to the dams; they impound the earliest monsoon floods, which are always the most heavily charged with silt; and by maintaining the largest reservoir areas, all floods passing through

them have the maximum time in which to deposit their silt. The silting up of reservoirs, even in a comparatively small number of years, is very noticeable; in some cases it has seriously diminished the storage capacity, and, in time, will render all reservoirs too small for their original purpose.

To remedy these defects, the Author advances what may be called a stepped waste-weir, examples of which are given in Figs. 6 and 7, Plate 1, for the proposed Máládevi and Tárlá reservoirs. The first shows the method of dealing with a saddle; while the second, that with sidelong ground, which will be the general ridge profile of most reservoirs. Such a weir may consist of four sections: (*a*) a drowned channel; (*b*) a clear overfall weir; (*c*) an undersluice section; (*d*) an automatic gate section. The last named (*d*), although very desirable, is not an essential feature, as it may be replaced by an extension of (*c*), which would have the advantage of dealing more quickly with the earlier stages of a flood. One of the largest masonry dams in the Presidency, the Bhátgarh dam, has been provided with automatic gates designed by Mr. E. Reinold,¹ and, if they prove perfectly satisfactory in practice, as is anticipated, they will form a most useful means of regulating reservoir floods at the end of the monsoon. It is, of course, not necessary that the different sections of the stepped waste weir should be continuous; they may be located to suit the contour of the ground, and may, if desirable, be situated on both sides of the river valley. Sections (*a*) and (*b*) are built with a masonry crest, preferably 3 feet below full-supply level, to allow them to be more easily closed by quick-acting teak shutters or needles. They give the weir a greater discharging power, should any excess run-off occur, than could otherwise be provided; as for any given increment in depth, the rate of increase of the discharge of a long weir with a small depth of overflow is greater than that of a short weir with a great depth of overflow, having originally the same discharging capacity. The shallow depth of storage over these sections enables the final closure to be more quickly effected; at the same time the extra length thus necessary increases the cost of the footway. Section (*c*) has its masonry crest level with that of (*a*) and (*b*), and similarly closable. The undersluices would be small and numerous so as to be cheaper and more easily worked than larger ones. The sills would be placed as low as possible. The lifting gear would be carried on arches forming part of the footway. Section (*d*) would consist of gates

¹ *The Engineer*, November 3rd, 1893, pp. 430, 431.

automatically opening on the approach of floods, and shutting on their cessation. Their tops would be level with that of the teak temporary crest. Over all sections would be carried a light footway, well out of the reach of floods, so as to permit all parts to be worked at any time. For catchments with a certain replenishment, (c) and (d) should be made large; for those with an uncertain one, they should be made smaller, and (a) and (b) increased proportionately.

Regulating Power of Reservoirs.—The property of flood absorption and regulation possessed by large reservoirs is well known, but practical effect has not yet been given to it in Indian examples. The proposed weir takes advantage of it, and in Appendix IV, Case 1, is a calculation of what may be done in this way. It will there be seen that during thirteen hours a total flood equivalent to a run off of 6.74 inches is dealt with. Of this only 1.75 inches are passed off by the weir, while the balance, 4.99 inches, is absorbed by the reservoir. When the high-flood level is reached, and assuming that the reservoir remains constant at this level, the whole weir will come into action, and its discharge will amount to a run-off of 0.487 inch per hour, giving a total run-off during the day of 11.66 inches. These runs-off are far in excess of what may be expected from the catchment. To obtain the maximum efficiency of the system, it is necessary that the reservoir level should be low before the flood comes. In the calculated example this is therefore assumed, and the waste-weir discharge at the commencement is thus only at the rate of about 0.05 inch per hour, or of 1.20 inch per day, which is, however, more than what any ordinary small flood will produce. The run-off does not reach the reservoir immediately on the occasion of rainfall, nor does it attain its maximum for some time after it has commenced, as the courses of the tributary streams are of largely varying distances from the point of discharge. There is, therefore, sufficient time to lower the reservoir by the sluices to provide for the expected flood.

Even the largest floods are of short duration, and it will be rarely, if ever, that their maximum intensity in a reservoir catchment will last for more than twelve hours, so that the stepped waste weir can pass off the largest flood and regain reservoir flood absorptive capacity before a second one arrives. For this reason the maximum rate of run-off may be safely reduced with it. In the case of Máládevi reservoir the original project provided for a run-off of 1 inch per hour; this was a very liberal allowance for so large a catchment (160 square miles), even although it is largely

a ghaut one; a run-off of 0·75 inch per hour would be more in accordance with general practice. For the "stepped weir," the maximum run-off allowed in the calculations is just under 0·50 inch per hour. The calculations show that the hourly rate of run-off disposed of gradually rises, which would be in accordance with the actual flood, and that, for the last four hours, the average hourly rate dealt with is 0·64 inch per hour.

The same property of flood absorption is shared by the ordinary level weir in proportion to the maximum depth allowed over it. Appendix IV, Case 2, shows the effect of such a weir for Máládevi reservoir. Owing to the restricted nature of the site, a comparatively short weir with a high flood on the crest is alone economically feasible, and therefore the ratio of reservoir flood absorption to the total flood is unusually high. Starting with an initial flood of practically the same intensity as that of the first case, the calculation shows that during eight hours a total flood equivalent to a run-off of 5·82 inches is dealt with; of this 2·62 inches are passed off by the weir, and 3·20 inches are absorbed by the reservoir. The discharge when high-flood level is reached will be 0·72 inch per hour, and, if the reservoir remains at this level, will give a total run-off of 17·32 inches during the day. During the last four hours of the rise of the reservoir, the average rate of run-off will be 0·91 inch per hour. It is therefore likely that the maximum flood depth will never occur, but this is owing to the large depth of flood allowed in this particular instance. In the case of ordinary depths, 5 feet or 6 feet, the flood absorptive capacity of the reservoir would be largely reduced, and the full extent of waste-weir provision would be necessary to deal with an extreme flood lasting only three or four hours.

At high-flood level (reduced level 200·00) and full-supply level (reduced level 190·00) of the 10-foot deep level waste-weir, the contents of the Máládevi reservoir are 5,212 and 3,750 million cubic feet respectively; the storage between the two is 1,462 million cubic feet or 0·28 of the whole full-supply capacity. This quantity is stored by the "stepped weir" without increasing the cost of the dam itself. In order that the storage costs of the two weirs should be the same, the expense of the "stepped weir" should equal that of the level weir plus the value of the extra storage gained by the use of the former; it will never reach anything like this high figure.

The advantages of the "stepped weir" may be thus summarized:—

- (a) The maximum flood down the tail channel is avoided by tapping

the discharge early and allowing the reservoir to absorb the flood and give it out gradually. The action of a short, severe flood on all the works is worse than that of a long, gentle one. (b) It allows the reservoir's high-flood level and full-supply level to be made the same in fair weather, and thus increases its storage capacity at small expense; or, conversely, the height of the dam and its cost may be diminished for the same amount of storage. (c) Protective works along the upper part of the weir, where the flood action will seldom occur and will never be large, can be made much lighter, and, in cases of naturally good foundations, omitted. Hence, when it becomes necessary to raise the dam, the loss in reconstructing the weir works will be comparatively small. (d) It enables the tail flood to be directed along a defined and comparatively narrow channel, and thus avoids the cost of the extended protective works there which may otherwise become necessary. (e) It allows the reservoir to be rapidly lowered when there is any fear of danger to the dam. (f) During the monsoon, when any damage to the dam would be most difficult to deal with, the reservoir would be at its lowest levels, and thus the chance of damage to the works would be the smallest. (g) The first floods, which are most heavily silt-laden, are passed out rapidly and the storage can be effected with the river's clearest flows. (h) Larger catchments with more certain replenishments may be utilized without the fear of excessive silting. (j) It offers a greater variety of sites for the waste weir. The stepped form is generally better suited to the natural contour and requires a shorter length to accommodate it. The longitudinal section of the dam shows if the work is economically feasible; the position and levels of the waste-weir site determine if it is practicable. (k) As the full storage of irrigation reservoirs is not required for some years until irrigation extends, it will be feasible to keep the reservoir low and to allow the dam to consolidate by settlement with a minimum amount of infiltration; while, whenever extra storage may be required (such as during a season of scanty rainfall) it can be obtained without trouble. (l) The footway over the weir enables access to be obtained across it at all times. (m) In reservoirs with a comparatively small utilizable depth of storage an outlet might be economically formed in the deep part of the weir.

Working the Stepped Waste-Weir.—This system is best applicable to reservoirs which have a certain replenishment and which are situated on a stream having a fair flow for some time after the end of the monsoon; it is generally best to select reservoirs at sites where these favourable conditions obtain. In such cases the

sluices would all be kept open until late in the monsoon, and it would thus be only necessary to watch and regulate the few late storms which do not, as a rule, produce on fairly large catchments the excessive run-off of the earlier ones.

As a detailed example, the stepped waste-weir of Máládevi reservoir, Figs. 6, Plate 1, may be considered. During the early part of the monsoon it will store water to reduced level 177, the sill of the lower undersluices, where the storage will amount to 2,203 millions of cubic feet, or to 0.42 of the whole reservoir. During this time it will be perfectly automatic, and the total flood which can be dealt with may exceed that given in Appendix IV, Case 1, by about 4 inches, i.e., while the reservoir is rising from reduced level 177 to reduced level 187. In September, the lower undersluices can be shut, giving a storage at reduced level 187, the sill of the upper ones, of 3,357 millions of cubic feet, or 0.64 of the whole reservoir. Later on, the upper undersluices can be shut, giving a storage at reduced level 196, the masonry crest of the weir, of 4,599 millions of cubic feet, or 0.88 of the whole reservoir. Up till this time it will be easy to render the weir speedily automatic by opening the undersluices. Finally, say early in October, it will be necessary to put down the teak shutters, or needles, on the crest to store the balance, 613 millions of cubic feet, or 0.12 of the full storage, and it will only then be necessary for a short time to be careful in dealing with floods. When the river's flow after the monsoon is fair in amount, this extra storage can be effected with perfect safety after its entire or partial cessation; 613 millions of cubic feet will be given by a flow of 240 cubic feet per second, lasting for one month.

It will always be advisable to maintain a sufficient establishment to attend to the weir until the reservoir has fallen a few feet below its full-supply level after the end of the monsoon, as a cheap and efficient precaution against sudden cyclonic storms. Should these occur thereafter, the reservoir will absorb nearly $\frac{1}{2}$ inch run-off per foot of rise, and the automatic gates, which can easily be made to act, by filling the counterpoise chambers, will discharge more than 2 inches run-off per day. The temporary teak crest will also have been removed, leaving the masonry crest free to discharge. This will give plenty of time to open the undersluices and call the whole weir into play.

As soon as such a flood has fallen to within a foot or so above the masonry crest, it will be easy, by allowing the gates and sluices to remain open, to restore the temporary wooden crest.

Thereafter the gates and sluices can be shut, and the reservoir replenished to full-supply level, if necessary, by the tail of the flood.

A stepped waste-weir for uncertain catchments is shown in *Fig. 18*.

THE OUTLET.

The various forms of reservoir outlets will be dealt with separately.

Culvert Under the Dam.—This form is usually the cheapest, and, when properly constructed, can be made perfectly safe. The objections raised to it are:—(a) It forms a weak point in the dam; (b) being under a large mass of made earth, it cannot afterwards be properly inspected or repaired; (c) it is apt to be disturbed by the spreading out of the dam during settlement; (d) it is liable to

Fig. 18.

Horizontal scale, 1 inch = 800 feet; vertical scale, 1 inch = 40 feet.

STEPPED WASTE-WEIR FOR UNCERTAIN CATCHMENTS.

be fractured where it crosses the puddle trench; (e) a crack is likely to occur, owing to unequal settlement of different heights of masonry, at the junction of the culvert with the headwall or tower; (f) leakage is likely to occur along the outside of the culvert; (g) the valve-tower, if placed in the reservoir and connected with the dam by a bridge, is in an exposed position and is liable to injury by ice, or difficult of access in stormy weather; (h) the valve-tower, if placed in the centre of the dam, is liable to be disturbed by the settlement of the earthwork, causing a leak to form and the lifting rods to be forced out of the vertical; (j) where the reservoir water is admitted freely into the culvert, as in (h), there is danger of its leaking into the dam.

To these objections the following replies can be made:—

- (a) This may be admitted in theory, but the objection can be met by proper precautions in design and by good workmanship.
- (b) The whole of the work being executed in the open, there should

be no difficulty in securing first-rate workmanship, and, provided durable materials, such as stone or brick, are used, there should be no need of repairs. Iron in such a position is not desirable, owing to its tendency to decay. (c) This is rather the fault of the embankment than of the culvert. No such spreading out of the earthwork should occur if it is carefully executed, and it has not occurred in any of the larger modern Indian dams. To meet the objection it is desirable to sink the culvert in a trench some depth below the bed of the dam, and it will then be practically independent of it. Its ends should be well buttressed by the tail and fore bays. (d) This is the most serious objection. The puddle-trench should never go under the culvert; the latter should have throughout its length a solid, unyielding, homogeneous foundation, not liable to be affected by the percolation of water, and this should, in all cases practicable, be of sound rock.

Where rock cannot be met with, the culvert should be carried on a wide concrete foundation. (e) Assuming a leak to occur here, although no instance of it is found in Bombay in the numerous works of the class, it would only involve a loss of water, which would pass harmlessly through the culvert, and would not constitute a danger to the stability of the dam. At the

storage reservoir of the Hubli Waterworks (Dhárwár Collectorate), the Author met the objection as shown in *Fig. 19*. The outlet culvert is overlapped 12 inches by the concentric arch carrying the valve-tower side wall. At their junction, A B, the two arch rings are bevelled as shown, and, being independent of each other, can settle independently. When final settlement has been obtained, which will be before the reservoir fills, the annular wedge space can be cemented watertight. (f) Direct leakage can be shut off by staunching rings. (g) This objection does not apply to Bombay dams where ice does not occur. Damage to the valves by floating logs, &c., can be prevented by cages. The stress of weather is never sufficient there to prevent the valves being attended to. (h) and (j) These objections appear sound, and this form of valve-tower is not employed in Bombay.

This form of culvert outlet under the dam is the form universally

Fig. 19.

adopted in Bombay for large storage reservoirs, and no failures of it have ever occurred there. At the same time the contrary opinion¹ has been expressed:—"Earthen dams rarely fail from any fault in the artificial earthwork, and seldom from any defect in the natural soil; the latter may leak, but not so as to endanger the dam; in nine-tenths of the cases the dam is breached along the line of the water outlet passages." This may be true of works carried out under imperfect supervision or of faulty design; but, as regards modern Indian experience, it is distinctly opposite to the facts in the case of large ones properly supervised and designed.

Tunnel round the Dam.—This form of outlet, being quite independent of the dam, cannot cause damage to it. The objections to it are:—(a) Its great expense, which is not generally necessary, seeing that the culvert form can be made quite safe; (b) the work, being underground, cannot be so carefully supervised as above-ground work; (c) the excavation of the tunnel, which should be in rock, is liable to cause fissures which will lead to loss of water; (d) it is difficult to construct the tunnel so as to make it have a watertight connection with the excavation. In India the scale of the natural features of the country is so large that the cost of the tunnel would, in most cases, be extremely heavy.

Siphon over the Dam.—This form can only be used where the depth to be drawn off is small; probably a depth of 15 feet is the practical limit, but to this can be added the depth below the reservoir surface at which the crest of the siphon can be laid. The culvert containing the pipes should have a wide concrete foundation to secure uniform and small settlement, and should be laid on natural ground, *i.e.*, not in the heart of the embankment. The necessity for having air-tight iron pipes in addition to the culvert adds to the expense of construction, and will, in most cases, exceed the saving, consequent on their use, of a shorter culvert and lower valve-tower. The design involves a loss of head to produce siphonage, and in many projects this would be a disadvantage. This form has been used in England and in America, but not in Bombay.

Headwall in the Centre line of Dam.—This arrangement has been employed for the large Mhaswad reservoir in the Sâtará Collectorate, *Figs. 20*. It consists of interposing in the earthen dam what is virtually a section of a masonry one and of uniting the two by four long wing walls. Great care is necessary to

¹ *The Engineer*, vol. lxiii. p. 189.

prevent the creep of water along the upstream wings and infiltration through them into the dam. The design has the great merit that the work can be most easily inspected and repaired. Rock foundations are necessary. It will be most cheaply constructed in a trench across a narrow saddle, as thereby the length of the wings can be reduced.

Headwall across an open Channel outside the Dam.—This design has been made use of in the small Medleri reservoir in the Dhárwár Collectorate. It is of very simple construction; a channel is dug around the flank of the dam, and across it is built a simple headwall in which are the regulating sluices. It is only adapted for works having a small depth of maximum draw-off. It shares all the advantages of the tunnel form, and in addition has that of being easily inspected. The disadvantage attending it is that a large area is opened out for percolation from the reservoir, and hence it is best adapted to sites where the soil is naturally watertight.

Pipe Outlets.—The dangers attending this form have been often alluded to, and it is therefore sufficient to say here that it should never be adopted for reservoirs of any magnitude or depth. There are, however, numerous small irrigation tanks of native construction where it is the only one economically practicable. For such the pipes should be laid on a hard, unyielding bed, should have staunching collars, and should be covered with the most watertight clay procurable. For these small works well-bedded earthenware pipes can be used; in some cases in Madras concrete pipes have been employed. For larger tanks with a maximum depth of from 10 feet to 15 feet, iron pipes should be laid in a trench and should be embedded in fine concrete, which will serve for the passage of the water after the iron has rusted away.

Regulating Headworks.—The different varieties of these may be classified as: Outlet towers; outlet headwalls; and dam slope gears.

Outlet towers are invariably used for water-supply storages

Figs. 20.

where the supply has to be drawn from different levels to obtain the clear supernatant water continuously as the surface falls. By their means a complete inspection of the valves and their lifting gear can always be had, and the latter is kept out of contact with the reservoir. Where double control of the supply is obtained by exterior valves, they and their lifting-gear cannot be inspected until the water-level falls.

Outlet headwalls are generally used for irrigation storages, and they have the valves placed at the sill level of the culvert. Both the valves and their lifting-gear are under water, and, according to the usual design, the former cannot be inspected until the reservoir runs dry, which, of course, it is undesirable for irrigation should occur. The remedy for this is a simple one, and consists in constructing, just upstream of the headwall, an inspection chamber which can generally be formed by throwing a cross wall between its wing walls or fore bay. The top of this should be raised to a level at which the storage capacity of the reservoir is sufficient to last from the time of inspection (which would be in May) until the monsoon replenishment arrives. At the bottom of the cross wall would be a simple sluice opening, which would be closed either by a plain shutter or by sand-bags when necessary. The same device should be adopted for the examination of the lower exterior valves of outlet towers; that of the upper ones could be effected as the reservoir surface falls. It is most desirable that all under-water sluices should be annually inspected, painted, and repaired, but with the designs now adopted this cannot be done.

In both these forms access from the dam to the valve-gear is gained by means of an approach bank jutting out with steep $1\frac{1}{2}$ to 1 slopes from the dam, and a light iron bridge from it. Any settlement of the main dam would carry the subsidiary one with it, and, whenever there is a natural spur running at right angles to the main dam, the approach bank should be thrown out from it. Where this spur offers good foundations, a masonry foot-bridge can be thrown from it to the outlet headwork with advantage to permanence and appearance.

Dam slope gear.—In this form all masonry walling is avoided and the plan is a very cheap one, but it is only applicable to small reservoirs. An example, designed by the late Mr. W. J. B. Clerke, occurs in the Bhādalwādi reservoir, Poona Collectorate, *Figs. 21*. The ends of the outlet pipes are turned through a quadrant to enable plain circular valves to be used; these are situated in small masonry chambers, and the pipes are led into the culvert through

a concrete stopping-piece. The lifting rods pass through guides fixed to stones supported on the slope of the dam, and are worked by gearing at its top.

The objections to this class of gear are: (a) The settlement of the dam puts the guides and their stone supports out of line with the lifting rods. (b) The valves cannot be inspected till the reservoir is dry. (c) Great force is required to work the long lengths of lifting rods resting on numerous guides and actuating (in the usual plan) an elliptic-shaped gate of increased area. The guide friction could, however, be reduced by using rollers and the gate area, by the device above described.

Valves.—For water-supply purposes, where the quantity of discharge is always small, the commercial pattern of water-valve can be economically used. For irrigation outlets, much larger supplies being required, special valves are made. These consist of three parts—the fixed seating, the fixed guides between which the movable gate works, and the gates themselves. All the surfaces in moving contact should be faced with planed brass or gun-metal to diminish friction and prevent rusting, and so as to make a water-tight joint.

The masonry sill of the sluices should be quite below the seating, and its upper surface should bevel downwards to the reservoir to direct the outflow upwards so as to scour out any silt which might be deposited. To prevent the valve from jamming, it is best to make its bottom line part of a circle, and to slightly bevel it at the centre, which will thus guide the whole over the base of the seating.

In the small native reservoirs the outlet head consists of a small masonry chamber roofed with a slab which is pierced by an inlet hole whose discharge is regulated by a simple wooden plug fixed to a pole. A second hole is made horizontally, in the front wall, at the reservoir-bed level, and is also closed by a plug which is regulated by hand when the water-level falls below the roof of the chamber. This form has been elaborated in iron for the Gulburga

reservoir at Hyderabad, Deccán, and is illustrated in *Figs. 22*. It is simple, can be easily inspected, and enables the bottom of the reservoir to be drawn off with the maximum head. Under a great head of water it would, on account of its form, be difficult to work. By using a number of these "pole and plug" outlets, each in a chamber at a different level from the rest, it is easy to maintain a practically constant discharge by lifting the different plugs as the water-level falls.

Lifting-Gear.—The valve-rods are liable to buckle as an extreme amount of thrust comes on them when the valves jam, or do not work freely from any cause, and it is therefore advisable to make

POLE AND PLUG OUTLET, GULBURGA TANK.

them of mild steel and of somewhat fuller dimensions than theory requires. The joints in particular are apt to give; for rods up to 2 inches in diameter, plain lap joints secured by bolts can be used, but, for larger ones, the lap ends of the rods should be confined in a strong collar with bolts passing through them and it.

The lifting arrangements at the top consist of the screwed end of the lifting-rod actuated by a fixed capstan head. A better design, which, it is believed, is due to the late Mr. J. F. Latrobe-Bateman, has been used on some recent works. In this the lifting-screw works against a bed-step, and is separate from the lifting-rod which is fastened by a long link carried by a movable collar engaging with the screw. Any deviation of the rod from the vertical is thus not communicated to the screw, and grinding action is avoided, *Figs. 23*.

It is desirable that the travel of all lifting-rods should be visible at the capstan-pillar so that the positions of all valves in their

Scale, $\frac{1}{4}$ inch = 1 foot.

seats may at once be known. Where this cannot be done directly, "tell-tales" should be fixed to indicate them.

No attempts have been made in India to work the valves from the downstream end of the outlet culvert by bevel gearing and rods passing through it horizontally, but as this design would save all the expense of an outlet headwall and permit of easy inspection at all times, it might be adopted in the case of irrigation reservoirs. In this case the valve could be given either horizontal or vertical motion; the end of the valve-rod would be stepped into the valve-seating and would have a pinion engaging with rackwork fixed to the valve.

Discharge of Valves.—The discharge of the valves is usually regulated so that, with a small head of say 1 foot, the full supply may be given. Besides furnishing the supply to be utilized, the valves should, however, be sufficiently large to be of use in lowering the reservoir, when this has to be quickly done, either for their own examination or in case of accident to the dam; to steady the rise of the reservoir and save the permanent or temporary waste-weirs; to diminish silting up of the bed of the reservoir; and to aid in the closure of the dam. Taking the case of Máládevi reservoir, the outlet would have to discharge:—

	Cubic Feet per Second.
(a) To lower the reservoir 1 foot in a day below reduced level 177, the sill of the lower under-slucies of the "stepped weir"	1,260
(b) To run off $\frac{1}{100}$ inch per day from the catchment	1,033
(c) To pass 15 inches run off from the catchment in four months of the monsoon	538

Here a discharge of say 1,000 cubic feet per second would probably be advisable. In water-supply reservoirs independent valves should be constructed with these objects in view.

To illustrate these remarks, drawings of the Hubli waterworks

outlet, designed by the Author, are given in Figs. 24 and 25, Plate 1, and *Figs. 26*. This work was modified in construction by certain changes in the valves and by the replacement of the masonry footbridge by an ordinary approach bank and iron foot-bridge. As stone could only be obtained at great cost, the tower was built of block-in-course facings with a hearting of very fine lime concrete (really a coarse mortar) gauged with Portland cement. The supply-valves and lifting-gear are designed inside the tower, so as to be quite protected, and double control is given to all by an extra valve placed downstream of the central stand-pipe. An inspection-chamber was built between the wings of the tower, two large unwatering valves were placed at its base, and its junction with the culvert was made as explained on p. 181.

Figs. 26.

General Remarks on Outlet Culverts.—In Western India the form of outlet almost universally adopted for large works is the culvert under the dam, and this alone will be considered now. The position for the outlet should be very carefully selected; it should never be placed near the river gorge, as leakage from it would tend to lubricate its sides and cause the slipping of the highest part of the dam. For the same reason it is not advisable to locate it near the surface of steep sidelong ground. It should, as far as possible, be buried in a deep trench so that the friction of the filling against the sides will make it more independent of any possible movement of the dam, and so as to shorten its length and diminish its cost. It should be placed below the bed of the puddle-trench so as not to be underlain by it, but where this cannot be done, a concrete

trench should be substituted for the puddle one so as to give the culvert solid support. There will, however, in this case, be still a slight danger of unequal settlement taking place at this point. Slip-joints over the puddle-trench are not therefore required, and their use even with a puddle-trench is generally condemned in English practice.¹

The trench excavated for the culvert should be considerably wider than the masonry and should be taken out with slightly sloping sides to give space for a good thickness of puddle so as to ensure that during settlement no leaks are formed along it. In some cases a concrete casing has been interposed between the ashlar arching and the puddle, or has been allowed to entirely supersede it. Every junction of dissimilar materials is liable to produce a leakage plane; this will be the case with concrete and any natural soil, and still more with the smooth surface of the concrete casing and the puddle round it. Puddle will fit much tighter between the rough back of the arching and the side of the excavation, and as a greater thickness of it can be used at the same cost as a thinner casing of concrete, it is better to employ it alone for surrounding the culvert.

To prevent the creep of water along the line of the culvert, staunching rings should be placed around it at intervals from the upstream side up to the line of the puddle trench. The one most upstream should be situated where it is not liable to be passed by any large amount of infiltration through the dam. The rings should be of different projections beyond the culvert so as to offer the greatest resistance to leakage along a definite straight line. They should slope in cross and longitudinal section so that the earthwork may settle tight on them. Beyond the puddle trench there should be no staunches, and the culvert should then be cased by a drystone ring surrounded by gravel to prevent the inflow of earth.

Rankine states² that the proper form for the line of pressure is the elliptic linear arch in which the ratio of the half span to the rise shall not be less than the square root of the ratio of the horizontal to the vertical pressure of the earth. He adds that the entire ellipse may be used as the figure of the arch, or, if necessary, the bottom may consist of a circular segmental inverted arch having a depression of one-eighth of the span. In the Wághád (Násik Collectorate) and Hubli (Dhárwár Collectorate) reservoirs, an ovoid

¹ Minutes of Proceedings Inst. C.E., vol. lix., Wood on "Reservoir Outlets."

² *Ibid*, vol. lxxvi., Burke on "The Ashti Dam," pp. 23, 24.

form was used to give a better discharging power, and the masonry invert was, for facility of construction, replaced by a flat concrete foundation. In the former the sill is 60 feet below the top of the dam and the modification has answered well. In this case a central drain should be constructed at the base to pass off any leakage that may occur. Careful attention should be paid to breaking joint in pavements and to keying the side stones below the arch ring to prevent any displacement by a large rush of water. The culvert should have a small longitudinal fall to facilitate drainage and the flow of the discharge.

CONCLUSION.

The Author has now dealt with all the leading features of large earthen reservoirs in Western India, and has described the usual practice and the modifications of it which appear desirable to him.

The principal feature of the works is their large scale; for, owing to climatic reasons, very large storage has to be effected and excessively large floods passed off. The remarks made have especial reference to large works, for with those of smaller size many of the precautions described are not so necessary and may be omitted. To some engineers it may appear that too much stress has been laid on these, but, as for the most part they involve more careful supervision rather than greatly increased cost of construction; and, as their adoption will greatly minimise the risk of failure, they are well worth all the attention that can be given to them. It is true that many large dams have been successfully constructed without them, but on the other hand others have given trouble which might have been avoided had the precautions been adopted. True economy and increased soundness of construction will be obtained by observing them.

For all earthwork careful selection of material and its consolidation are necessary, but the most important matter is the proper drainage of every part of the work. Up to the centre-line every precaution should be taken to prevent infiltration, while beyond this point, every facility should be given to the harmless escape of such water as has penetrated so far. Slow construction, vertically, of the earthwork, raising the highest parts of the dam first, and the avoidance of everything likely to cause infiltration or unequal settlement must be insisted upon. To suit the conditions of gorge embankments and of their closure, a new form, the "compound dam," is proposed. The closure of dams by level stages is strongly advocated. As regards waste-weirs, a new

form, "the stepped" waste-weir, is put forward, so that advantage may be taken of the flood-absorbing capabilities of the reservoir. It is best adapted to cases where the replenishment is certain, but it may be employed in others. For outlets, the type recommended as generally the most suitable is the culvert under the dam. Its size and discharging-power should be adjusted so as to make it of assistance to the waste-weir in regulating all ordinary replenishments.

The Author believes that his recommendations will not in most cases increase the cost of storage as compared with general practice, and that the works will be much safer if they are adopted.

The Paper is accompanied by four tracings, from which Plate 3 and the *Figs.* in the text have been prepared.

COMPARATIVE STATEMENT OF CERTAIN STORAGE RESERVOIRS

1	2	3	4	5	6	7	8	9	10
Consecutive Number.	Name of Reservoir.	Collectorate in which Situated.	Data.			Dam.			
			Area of Catchment.	Average Annual Rainfall and Estimated Proportion of Run-off to Rainfall.	Fall of River above Dam.	Length of Dam.	Maximum Height of Dam.	Depth from Full-Supply Level to Sill of Outlet.	Width of Dam at Top.
			Square Miles.		Feet per Mile.	Feet.	Feet.	Feet.	Feet.
1	Āshti .	Sholāpur .	92·00	$\frac{24}{4}$ ⁽¹⁾	12·00	12,700	58·00	22·00	6·00
2	Ekruk .	..	159·00	$\frac{31·57}{4}$	8·50	6,940	75·66	38·25	6·00
3	Kās .	Sátará .	1·97	$\frac{139·67}{3}$	57·85	718	56·41	17·80	10·00
4	Maini .	..	54·00	$\frac{24·24}{4}$	29·25	3,370	57·33	31·20	5·00
5	Medleri.	Dhārwar .	11·00	$\frac{23·40}{3}$	33·50	2,250	41·00	15·00	6·00
6	Mhaswad	Sholāpur .	508·00	$\frac{22·83}{10}$	12·00	7,950	79·79	24·00	8·00
7	Mukti .	Khāndesh.	34·22	$\frac{20·92}{4}$	21·30	3,000	65·00	41·00	10·00
8	Nehr .	Sátará .	59·50	$\frac{28·37}{4}$	25·26	4,820	74·00	31·00	8·00
9	Pārsul .	Nāsik .	17·33	$\frac{28·00}{4}$	42·70	2,770	62·27	35·00	6 to 8
10	Wāghād	..	29·00	$\frac{54·30}{4}$	61·00	4,162	95·00	48·00	6·00
11	Mālādevi	Ahmednagar	160·00	$\frac{55·00}{4}$	5·00	4,445	114·00	63·00	10·00
12	Tārlā .	Sátará .	60·00	44·84	{ not available }	3,120	94·00	60·00	10·00

¹ In col. 5 the denominator represents the fractional part the run-off bears² In col. 6 the fall is taken within the limits of the full-supply contour, the³ The figures for these works are those given in the official projects; they⁴ With the exceptions of works Nos. 5 and 6, the outlets of all these reser-

DIX I.

WITH EARTHEN DAMS IN THE DECCÁN, BOMBAY PRESIDENCY.

11	12	13	14	15	16	17	18	19	20	21
Waste Weir.						Reservoir.				
Length of Waste Weir.	Height of Calculated Maximum Flood over Weir Crest.	Height of Top of Dam over Weir Crest.	Estimated Run-off per Hour.	Estimated Discharging Power of Waste Weir.	Description of Waste Weir.	Areas of Contours.		Total Capacity.	Available Capacity over Outlet Sill.	Annual Depth Allowed for Evaporation and all other Losses.
						At Full-Supply Level.	At Outlet Level.			
Feet.	Feet.	Feet.	Ins.	Cubic Feet per Second.		Million Square Feet.	Million Square Feet.	Million Cubic Feet.	Million Cubic Feet.	Feet.
structed.										
800	7·00	12·00	0·80	48,000	Excavated channel	123·296	23·000	1,550·000	1,348·000	4·00
750	10·00	17·00	0·42	43,763	{ Two channels in excavation . . }	198·232	12·000	3,330·000	3,310·000	7·00
60	5·00	15·30	3·00	3,820	{ Masonry wall and excavated channel . . . }	3·373	0·333	..	56·567	4·00
{ 600 300 }	6·00	13·00	1·11	38,668	{ Masonry weir wall and excavated channel. . . }	16·570	1·200	195·270	188·590	5·00
700	2·00	7·00	1·00	6,453	{ Masonry wall and excavated channel . . . }	7·360	1·120	62·380	57·600	4·00
3,000	6·00	13·00	0·73	235,545	Concrete weir wall	174·840	48·500	3,072·130	2,632·770	4·00
1,590	{ 5·40 2·40 }	13·00	1·00	32,265	{ Two masonry weir walls . . . }	22·177	nil	342·429	342·300	7·00
700	6·30	14·00	1·00	38,720	{ Masonry wall and channel . . }	29·490	3·400	522·640	489·770	4·00
500	4·00	10·00	1·00	12,800	Masonry wall .	6·620	1·011	124·500	118·700	4·00
650	5·00	12·00	1·00	18,069	Excavated channel	33·900	1·657	624·670	605·550	4·00
posed. ³										
1,575	9·00	16·00	1·00	103,254	Masonry wall .	153·331	18·730	5,140·370	4,921·844	4·00
600	7·00	14·00	1·00	38,000	Excavated channel	35·640	2·830	854·710	823·400	4·00

to the whole rainfall: thus 4 represents $\frac{1}{2}$ the whole rainfall.
distance being measured along the bed of the river.

differ in some instances from those mentioned in the Paper.

voirs consist of culverts under the dams with head-walls or towers at the upstream ends.

[THE INST. C.E. VOL. CXXXII.]

0

APPENDIX II.

I. RAINFALL.

The following are instances of heavy falls of rain.

On the Lower Ganges Canal, North West Provinces, the rainfall in 1884 was:—

	Inches.
September 13th	16
October 1st	22
October 2nd	22½
October 3rd	18
October 4th	17½
Total October 1st–4th	80

Sometimes the rate was as high as 5 inches per hour. Probably this is the greatest storm on record. ("Manual of Irrigation Engineering," by H. M. Wilson, 1st edition, 1893.) It was most likely due to a cyclone.

At Jalgaon, in the Akola district, Central Provinces, on June 17th, 1888, 7·75 inches fell in six hours, from 11 A.M. to 5 P.M. (*Bombay Gazette*.)

At Saugor Island, in the Hughli, near Calcutta, 14·28 inches were registered in one day, on the 23rd (?) of August, 1888, and the wind attained an average velocity of 72 miles an hour. (*Bombay Gazette*.)

At Broach, on the West Coast, Bombay Presidency, on the 21st of June, 1893, 8 inches fell in two hours. (*Bombay Gazette*.)

At Mount Abu, in Rajputáná, in September, 1893, there was an extraordinary fall of 42 (44 ?) inches; 15 inches fell in one day. (*Bombay Gazette*.)

In Madras (town) 1 inch fell in sixteen minutes on the 11th of October, 1893. (*Bombay Gazette*.)

In Bombay (town), on the 7th of September, 1895, the rainfall at different stations was:—Colaba, 6·82 inches; Byculla, 9·50 inches; Esplanade, 7·13 inches; and Fort, 9·12 inches. (*Times of India*.) This shows how the intensity of heavy rain varies at near stations.

At Sholapur, in Bombay Presidency, on the 6th of September, 1895, 17 inches fell in twenty-four hours; at one time 10 inches being registered in seven hours. (*Times of India*.)

II. FLOODS.

The following are records of large floods in Khándesh, Bombay Presidency—

At Máhilla, near Dhulia, the Pánjhra river, on the 15th of September, 1872, had a flood discharge of 276,000 cubic feet per second, equal to a run-off of 0·54 inch per hour on a catchment of 788 square miles. The river rises in the western Ghauts; at its source the catchment has its maximum width of 21 miles, and is elevated and bounded by steep uncultivated hills. Uncultivated trap-hills bound the whole valley, but lower down it is itself flat and cultivated. The rainfall gauged was:—

	Sept. 11th.	Sept. 12th.	Sept. 13th.	Sept. 14th.	Sept. 15th.	Total.
	Inches.	Inches.		Inches.	Inches.	Inches.
Pimpalner (45 miles from gauge-station)	2·13	0·20	..	9·90	0·60	12·83
Dhulia (1 mile from gauge-station)	..	0·34	..	5·69	0·36	6·39

The flood commenced to rise at 8 P.M. on the 14th, attained its maximum at 6·30 A.M. on the 15th, and returned to its original dimensions on the morning of the 16th.

At the Jámá weir, Girná river, on the 15th of September, 1872, the flood rose to 16·45 feet on the weir crest, and was calculated to amount to 373,000 cubic feet per second. The catchment area is about 2,050 square miles, extending from the Ghauts, where it is 30 miles wide, hilly and uncultivated, to the weir site where it is flat and cultivated. This gives a run-off of 0·28 inch per hour.

At the same place, on the 11th of September, 1882, there was another severe flood rising to 15·90 feet on the weir crest, but, as it outflanked the work and broke into a tributary valley, damaging the canal, and could not be gauged at the weir site, it was probably as large as the previous one. The rainfall gauged on this latter occasion, on the 9th, 10th, and 11th of September, was :—

Rain-Gauge Stations.	Ghauts.		Upper Basin.		Lower Basin.			
	Háigad.	Allábad.	Chankápur.	Káilvan.	Nándgaon.	Málegaon.	Saigaon.	Jámá.
Miles above weir	97	82	81	71	38	34	16	—2
Inches of rainfall	22·80	56·59	12·21	14·42	9·35	8·15	5·83	3·35

The Upper Pánjhrá river has, at the site of the Dáturti weir, a catchment of 265 square miles. Its average width is 8 miles; on the north, south and west it is bounded by trap hills with steep, uncultivated slopes, the valley between being flat and cultivated. The rainfall gauged was :—

Date.	Rain-Gauge Stations.				
	Ámli.	Dáhiwad.	Pimpalner.	Sákri.	Lákhálá.
September 7th, 1882	9·71	2·03	0·12	0·29	1·35
" 8th, "		0·29	..	..	
" 9th, "		1·31	1·92	1·54	2·30
" 10th, "		4·03	4·02	2·67	
" 11th, "	5·31	4·31	4·11	3·33	2·30
" 12th, "		..	..	..	
" 13th, "		..	..	..	..
Totals	15·02	11·97	10·17	7·83	5·95

At the stations where two or more days' falls are bracketed, daily observations were not made.

The flood, as calculated from the high flood marks, amounted to 49,700 cubic feet per second, or to a run-off of 0·299 inch per hour.

During the same time, the neighbouring Burai river at Ranmálá, with a catchment of 65 square miles, which is practically uncultivated, and is elevated

with hills on the north, south and west, had a flood, similarly calculated, of 37,800 cubic feet per second, equal to a run-off of 0.90 inch per hour. There were no rain-gauge stations in this area.

Although heavy rainfall and floods are usually limited to the monsoon, they very occasionally happen during cyclones at other times of the year. A noticeable instance of this was on the 15th of January, 1871, when 15 inches of rain fell at Ratnagiri, on the coast, and 8 inches at Sâtará, to the east of, and 30 miles from, the Ghaut watershed (Bombay Presidency). A heavy flood was caused in the Krishná river.

APPENDIX III.

TABLE OF THE DISCHARGES OF A WASTE-WEIR CHANNEL HAVING A BED WIDTH OF 200 FEET AND A BED SLOPE OF 1 IN 100.

Total Depth.	Afflux Height, d_1 .	Tail Depth, d_2 .	Afflux Coefficient, c_1 .	Channel Coefficient, c_2 .	$\frac{\eta}{c w \sqrt{2g}}$.	$\sqrt{d_1} \left(d_2 + \frac{2}{3} d_1 \right)$.	Mean Velocity of Tail Channel per Second.	Discharge per Second, D.
Feet.	Feet.	Feet.					Feet.	Cubic Feet.
1	0.30	0.70	0.60	41.00	0.495	0.495	3.40	476
2	0.74	1.26	0.60	52.10	1.510	1.505	5.78	1,457
3	1.24	1.76	0.60	59.00	2.85	2.87	7.78	2,741
4	1.70	2.30	0.62	64.4	4.47	4.46	9.66	4,444
5	2.15	2.85	0.64	68.8	6.34	6.29	11.42	6,510
6	2.63	3.37	0.66	72.0	8.29	8.29	13.03	8,784
7	3.08	3.92	0.68	75.0	10.46	10.45	14.55	11,407
8	3.52	4.48	0.70	77.5	12.80	12.84	16.04	14,734
9	3.95	5.05	0.72	79.5	15.23	15.28	17.41	17,585
10	4.36	5.64	0.74	81.4	17.87	17.87	18.80	21,210
11	4.77	6.23	0.76	83.1	20.56	20.51	20.11	25,057
12	5.17	6.83	0.78	84.5	23.34	23.34	21.38	29,203
13	5.54	7.46	0.80	85.8	26.24	26.20	22.57	33,668
14	6.00	8.00	0.80	86.8	29.44	29.40	23.61	37,775
15	6.47	8.53	0.80	87.7	32.65	32.61	24.56	41,893
16	6.94	9.06	0.80	88.6	36.03	36.00	25.51	46,236
17	7.42	9.58	0.80	89.3	39.47	39.52	26.43	50,645
18	7.86	10.14	0.80	90.0	43.10	43.06	27.28	55,304
19	8.33	10.67	0.80	90.7	46.88	46.81	28.19	60,157
20	8.80	11.20	0.80	91.3	50.67	50.63	29.03	65,035

In the Table the afflux coefficient c_1 has been taken approximately. Rankine¹ gives Poncelet and Lebos' coefficients, which were determined from experiments with orifices only about 8 inches wide; and it is believed none on a large scale have ever been made. The values of c_1 are increased up to a total flood depth of 13 feet, to allow for the more efficient discharging power of a deep channel. No further increase is thereafter made, as large waves, and consequently more friction, will be caused. Any errors made by these assumed values will be

¹ *Civil Engineering*, 11th edition, art. 448, p. 680.

minimized in the calculations given in Appendix V, in the proportion the discharges of the waste-weir cut bear to the total flood, and this will always be small.

APPENDIX IV.

WASTE-WEIR DISCHARGES AND RESERVOIR FLOOD ABSORPTIONS.

Case I.—The “Stepped Waste Weir.”

The “Stepped Waste Weir,” proposed for Máládevi reservoir consists of the following sections:—

Section of “Stepped Waste Weir.”	Total Length.	Net Length exclusive of Footway Piers.	Maximum Depth of Flood over Sill.	High-Flood Discharge.
	Feet.	Feet.	Feet.	Cubic Feet per Second.
(a) Drowned channel	625	500	4	11,110
(b) Clear overfall weir . . .	575	450	4	12,840
(c) Undersluices	200	$\left\{ \begin{array}{l} 80 \\ 80 \end{array} \right.$	$\left\{ \begin{array}{l} 23 \\ 13 \end{array} \right.$	14,208
(d) Automatic gates	200	150	8	12,108
Totals. . . .	1,600	1,260	..	50,266

For (a) and (c) the effect, in reducing the discharge, of the depth of the tail channel flood is taken into account. The other discharges are not thus affected, as, with the total high-flood discharge, the water surface of the tail channel is level with the sills of the upper sluices.

The grand total discharge is equivalent to a run-off of 0·487 inch per hour from the catchment of 160 square miles.

TABLE OF WASTE-WEIR DISCHARGES AND RESERVOIR FLOOD ABSORPTIONS.

Data.—The reservoir to rise one foot per hour, all sluices being fully open and the weir crest free and unobstructed. The flood to commence when the reservoir is at the level of the sills of the upper undersluices, reduced level 187, when the lower ones will be discharging 5,500 cubic feet per second, or at the rate of about $\frac{1}{20}$ inch per hour, which is equal to a fair small flood.

1	2	3	4	5	6	7	8
Number of Hours from Commencement of Flood.	At End of each Hour.		During the Hour.				
	Reduced Level of Reservoir Surface.	Height of Reservoir Surface above Bed of Waste-Weir Tail Channel.	Mean Discharge of Under-Sluices.	Mean Discharge of Waste-Weir Crest.	Increment of Reservoir Storage (or Flood Absorption).	Total Flood dealt with.	Equivalent Run-off (of col. 7) from Catchment.
		Feet.	Million Cubic Feet.	Million Cubic Feet.	Million Cubic Feet.	Million Cubic Feet.	Inches.
1	188	11	20·700	..	128·440	149·140	0·40
2	189	12	23·580	..	130·888	154·468	0·42
3	190	13	27·380	..	133·359	160·739	0·43
4	191	14	31·680	..	135·748	167·428	0·45
5	192	15	35·640	..	138·030	173·670	0·47
6	193	16	38·880	..	140·330	179·210	0·48
7	194	17	41·940	..	142·650	184·590	0·50
8	195	18	44·280	..	144·988	189·268	0·51
9	196 ¹	19	46·440	..	147·358	193·798	0·52
10	197	20	48·600	5·040	149·734	203·374	0·55
11	198	21	50·220	19·620	152·130	221·970	0·60
12	199	22	51·120	41·940	154·557	247·617	0·66
13	200 ²	23	52·200	70·380	157·003	279·583	0·75
Totals			512·660	136·980	1,855·215	2,504·855	6·74
Add col. 4 total			512·660				
Total waste-weir discharge .			649·640				
Percentage quantities . .			25·94	74·06	100·00		
Add total waste-weir high flood discharge for eleven hours . .							5·35
Total run-off in twenty-four hours							12·09

Case II.—The Level Waste Weir.

The level waste weir proposed for Máládevi reservoir consists wholly of a drowned weir 700 feet long with its sill 10 feet below high flood level. Its high flood discharge will be 74,000 cubic feet per second, which is equal to a run-off of 0·72 inch per hour from the catchment of 160 square miles.

¹ Masonry crest of waste-weir.

² At reduced level 200 the automatic gates come into action and the total waste-weir discharge becomes 50,266 cubic feet per second, or at the rate of 0·487 inch per hour.

TABLE OF WASTE-WEIR DISCHARGE AND RESERVOIR FLOOD ABSORPTIONS.

Data.—The reservoir to rise one foot per hour. The flood to commence when the reservoir is at reduced level 192, when the weir will be discharging 5,100 cubic feet per second, or at the rate of about $\frac{1}{20}$ inch per hour, which is equal to a fair small flood.

1	2	3	4	5	6	7
Number of Hours from Commencement of Flood.	At End of each Hour.		During the Hour.			
	Reduced Level of Reservoir Surface.	Height of Reservoir Surface above Waste-Weir Crest.	Mean Discharge of Waste Weir.	Increment of Reservoir Storage (or Flood Absorption).	Total Flood dealt with.	Equivalent Run-off (of col. 6) from Catchment.
		Feet.	Million Cubic Feet.	Million Cubic Feet.	Million Cubic Feet.	Inches.
1	193	3	26·460	140·330	166·790	0·45
2	194	4	45·360	142·650	188·010	0·51
3	195	5	69·120	144·988	214·108	0·58
4	196	6	96·300	147·358	243·658	0·65
5	197	7	127·080	149·734	276·814	0·74
6	198	8	162·360	152·130	314·490	0·85
7	199	9	201·240	154·557	355·797	0·96
8	200 ¹	10	244·260	157·003	401·263	1·08
Totals			972·180	1,188·750	2,160·930	5·82
Percentage quantities			44·99	55·01	100·00	
Add total waste-weir high flood discharge for sixteen hours .						11·50
Total run-off in twenty-four hours						17·32

¹ High flood level.

Figs: 6.

Figs: 24.

Scale for Figs: 8, 12 & 14, 50 Feet = 1 Inch.
Scale for Figs: 24 & 25, 32 Feet = 1 Inch.

Fig: 14.

Scale for Figs: 6 & 7, Horizontal 1000 Feet = 1 Inch.
Vertical 10 Feet = 1 Inch.

Fig: 8.