



High Performance Bio-based Functional Coatings for Wood and Decorative Applications



PERFE COAT

Functional Nanomaterials

Brian Wabende, Bioenvision Technology AS

Bio-based Industries
Consortium



Horizon 2020
European Union Funding
for Research & Innovation

This project receives funding from the Bio-based Industries Joint Undertaking (JU) under the European Union's Horizon 2020 research and innovation programme under grant agreement No 101022370. The JU receives support from the European Union's Horizon 2020 research and innovation programme and the Bio-based Industries Consortium.

Polyhedral Oligomeric Silsesquioxanes (POSS)

- Introduction
- Progress
- Conclusion


Purpose of POSS

- Hydrophobicity
- UV curing to improve the mechanical strength of coating

What is POSS?

Polyhedral Oligomer SilSesquioxsanes (POSS)

- POSS is a hybrid organic-inorganic branched polymer with organic substituents attached to an inorganic silica core.
 - Mix of cage structures.
 - The inorganic silica core gives stability.
 - Organic modifications of the R-groups can be tailored to desired functionalities.
- POSS improves performance without compromising mechanical properties and is used in various applications.
 - ✓ High performance / high efficiency
 - ✓ Low dosage => does not affect mechanical properties
 - ✓ Thermostability and UV-stability (Si-O-bonds)



POSS means

Polyhedral – three dimensions with flat polygonal faces, straight edges and sharp corners or vertices

Oligo – the existence of a small number of units

Sil – silicon

Sesqui – each Si atom is bonded to 1.5 oxygen

ane – Si atom bonds to one hydrocarbon group


Introduction

POSS

- **Polyhedral Oligomer SilSesquioxanes (POSS)**
- POSS is made of the inorganic Si-O-Si cage and R groups (arms) which are organic in nature
- R groups can either be reactive or non-reactive
- Reactive R = aminopropyl, vinyl, 3-chloropropyl, methacrylate, acrylate etc.
- Non-reactive R = methyl, propyl, isobutyl etc


Advantages & Benefits

- Cost-efficient Sol-Gel process
- A versatile technology platform
- Solids – Solutions – Emulsions – Dispersions
- High-performing nanotechnology



POSS synthesis


- Alkoxysilanes
- Water
- Catalyst
- Solvent



Introduction

Where POSS is born

Small scale equipment



2L reactor




Pilot-scale reactor – 30L



Physical state of POSS


Viscous liquid



Solid




Powder



Introduction

Located at Herøya Industrial Park - Porsgrunn, Norway




Facts:

- 80 businesses
- 2.500 employees
- A range of sectors – industrial/maintenance/start-ups


Introduction

Main areas of POSS application in Bioenvision



Flame retardants

- D-PYRE® portfolio



Water-repellent/
Gas and Moisture Barriers

- Funzionano® portfolio

Confirmed (✓) and opportunities (•) for D-PYRE® technology

Based on Base Material

- ✓ **Polyvinyl Chloride**
- ✓ **Polypropylene**
- ✓ **Polyurethane**
- ✓ **Adhesives**

- Polycarbonate
- Polyethylene
- Polyethylene Terephthalate
- Polystyrene
- Polyesters Unsaturated

D-PYRE® in PU FOAM

Without FR additives



With standard FR additives



With 1.5% D-PYRE® and standard FR additives



* 5 sec Sequence of pictures from video


Introduction

Performance of D-PYRE® in high-plasticised PVC

PVC *without* D-PYRE®



PVC *with 1 PHR* D-PYRE®



* 10 sec sequence of pictures from videos

Progress

Synergism hydrophilic POSS with micro fibrillated nano cellulose (MFC)


- MFC is used as a rheology modifier
- The MFC used here is Exilva, which is 100% bio-based. (From Borregaard AS)
- In this case we see the homogeneous dispersion of hydrophilic POSS and MFC



Progress

Synergism with micro fibrillated nanocellulose (MFC)

- Viscosity tests were performed at Sintef.
- The dispersion's viscosity is unchanging over one month.




Anton Paar GmbH


Progress

Viscosity of MFC compared to MFC+POSS with time.

MFC+POSS




MFC



Progress


Synergism hydrophobic POSS with micro fibrillated nano cellulose (MFC)

- In this case we see the homogeneous emulsion of hydrophobic POSS and MFC when a defoamer is used.
- Green are with defoamer
- Orange are without defoamer



Synergism with alginate

- Two different hydrophilic POSS formed a homogenous mixture with alginate.



Hydrophobicity

- We see no improvement in the hydrophobicity of the coating

Formulation	No POSS	POSS	POSS in emulsion	No POSS	CaCO ₃ coated POSS
WCA before watering / °	81-73	97-85	93-82	107 - 96	105 - 100
WCA after watering / °	99-94	101-96	101-88	90 - 78	99 - 95

Martindale anti-scratch test of UV POSS done at Evonik

Without filler



7.5% benchmark filler



7.5% UV POSS



Martindale anti-scratch test UV POSS done at Evonik

7.5% benchmark filler +
7.5% UV POSS



15% benchmark filler



15% UV POSS



- Hydrophobicity was not significantly improved after POSS inclusion.
- Good synergy between POSS and MFC in both the hydrophilic POSS and hydrophobic POSS (with the help of a defoamer)
- Good synergy between POSS and alginate.
- Low amounts of POSS (5-7.5%) have a significant effect on the mechanical strength of the coating.



Thank you. 😊