Testing and Correlation of 8mm Pitch Honeycomb & Plate Type Module Performance in a 20 Litres SCR Test Facility

D. Eswaraiah, G. Karthik, U. Harish Kumar

Abstract: The main aim of this experiment is to reduce the concentration of NO_x in the exhaust gas below 100ppm with the most effective technique named selective catalytic reduction (SCR) with ammonia over to evaluate the performance of honeycomb and plate type catalyst in NO_x reduction by varying the performance parameters such as flue gas temperature, space velocity, NH₃/NO molar ratio, etc., and to find the optimum values of the above parameters under which we get the maximum efficiency of NO_x conversion at which air is not polluted and we have the sustained and eco-friendly environment. The effect of various performance parameters on the SCR process is also evaluated and the optimum values of performance parameters are also found to get the maximum efficiency of NO_x conversion. SCR performance is substantially under the effects of reactant (ammonia) concentration and operating temperature, so that the concentration of untreated ammonia emitted from reactor discharge (ammonia slip) increases significantly at NH₃/NO ratios of more than 1.14 and operating temperatures less than 360 °C and 300 °C, respectively, in the catalytic filter medium and honeycomb reactor. low level of ammonia slip can be achieved at the NH₂/NO ratio of 1 and temperature range of 300–350 °C in both reactors. The temperature of SCR is varied between $300^{\circ}C$ to $350^{\circ}C$, with a fixed space velocity of exhaust gas and a fixed value of NH3/NO ratio of 1.

Keywords: SCR, honeycomb, plate, catalyst, NO_x reduction, space velocity, pressure drop, ammonia slip.

I. INTRODUCTION

The concentration of poisonous gases and toxic pollutants in the atmospheric air is drastically increasing due to the combustion of fossil fuels and atmospheric cycles. If the same situation is continued for few more decades then the human survival on the earth shall become a big challenge and the human species are going to extinct on earth. In recent years the problem of air pollution caused by the toxic pollutants such as NO_x , SO_x and particulate matter has become very severe that the india has decided take stringent action against it. In view of the toxic pollutants, The ministry of environment and forest (MOEF), GOI issued notification for implementation of emission norms for particulate matter (PM), sulphur di-oxide (SO₂), oxides of nitrogen (NO_x) and

Revised Manuscript Received on February 05, 2020.

* Correspondence Author

D. Eswaraiah *, Mechanical Engineering Department, GRIET, Hyderabad, India. Email: <u>d.eswaraiah@gmail.com</u>

G.Karthik, Mechanical Engineering Department, GRIET, Hyderabad, India. Email: <u>karthikchowdary351@gmail.com</u>.

U. Harish Kumar: Mechanical Engineering Department, GRIET, Hyderabad, India. Email: <u>harishrockz6@gmail.com</u>

Table 1. TPPs regulatory norms installed from 1st Ja	ın,
promulgated in february 1998, are shown in table below	1.
mercury (Hg). The final emission limits under title	١٧,

2017			
Industry	Parameter	Standards	
	Particulate Matter	- 30 mg/Nm ³	
	(SO ₂)	- 100 mg/Nm ³	
rower riant	(NO _x)	- 100 mg/Nm ³	
	(Hg)	- 0.03 mg/Nm ³	
	Industry Thermal Power Plant	IndustryParameterThermalParticulate MatterPower Plant(SO2)(NOx)(NOx)	

Oxides of nitrogen (NO_x) are a group of air pollutants, including nitrogen oxide, nitrogen dioxide and nitrous oxide, considered as very dangerous, since they contribute to the greenhouse effect and participate in photochemical reactions that lead to acid rain, troposphere ozone and respiratory problems in humans. So, the reduction of NO_x from stationary and mobile sources has become an important concern of industrialized countries, due to an increased attention to environmental pollution and to the demand for sustainable energy development.

Hence, the elimination of gaseous pollutants and particles from high temperature gases is often required in waste incineration and thermal power plants. There are two sources of NO_x. One of them occurs in nature (nitrogen fixation by lightning, volcanic activity, oxidation of ammonia in the troposphere, inflow of NO from the stratosphere). The other is the combustion of fossil fuels (especially in vehicles) that is the main cause of emissions. So the emission of NO_x caused by the combustion of fossil fuel has to be reduced by scientific methods. The control of NO_x emissions from stationary sources includes techniques of modification of the combustion stage (primary measures) and treatment of the effluent gases (secondary measures).

SCR method, which was established in the 1970s, has been used mainly for stationary sources and still is the major strategy for the reduction of NO, industrially, due to its high efficiency and the ability of ammonia to react selectively with NO_x to form nitrogen (N₂) and water (H₂O), together with the resistance to poisoning and aging of the applied catalysts.

II. OVERVIEW OF SCR

A. Selective Catalytic Reduction (Scr)

SCR is a process, where ammonia (NH₃) is injected into flue gas stream, allowing the ammonia (NH₃) to selectively react



Retrieval Number: C6258029320/2020©BEIESP DOI: 10.35940/ijeat.C6258.029320

3540

Published By: Blue Eyes Intelligence Engineering & Sciences Publication

Testing and Correlation of 8mm Pitch Honeycomb & Plate Type Module Performance in a 20 Litres SCR Test Facility

with oxides of nitrogen (NOx) mainly nitrous oxide (NO) & nitrogen di-oxide (NO₂) and decompose them into water (H₂O) and nitrogen (N₂) in presence of catalyst. Aammonia is injected into exhaust gases containing NOx. The gases mix thoroughly in a turbulent zone, and then pass through the catalyst where the NOx is reduced. The technique is known as "selective" because the reducing agent will preferentially react with NOx instead of O₂ at the proper temperature. The term "reduction" is used because the nitrogen is chemically reduced from an oxidized form to molecular nitrogen.

SCR Advantages

- Low consumption of ammonia
- Emission levels below 100 mg/Nm³ can easily be achieved
- Side effect dioxin reduction

SCR Disadvantages

- High cost of investment dependent on NOx reduction level,
- High operational cost_,
- Risk of ammonia slip,
- Catalyst life time,
 - Storage of used catalysts.

B. Chemical Reactions

The NH₃-SCR reduction of NO over a V2O5/TiO2 catalyst can be described by a reaction network that involves two parallel reactions. The desired reaction is the conversion of NO to N_2 according to Equation (1), while NH₃ oxidation with O_2 , based on Equation (2) is an undesired reaction which leads to lower NO conversion and becomes more significant at higher temperatures. The reduction of NOx is considered to be faster compared to NO, so that NOx typically consists of up to 95% NO, especially at high temperatures.

 $4NO + 4NH_3 + O_2 \square 4N_2 + 6H_20$ (1) $4NH_3 + 3O_2 \square 2N_2 + 6H_2O$ (2)

III. EXPERIMENTAL SYSTEM DESCRIPTION

The experiments were conducted in 20 litres capacity selective catalytic reduction (SCR) test facility with 8mm pitch honeycomb and plate type catalyst. The 8mm pitch honeycomb and plate installed in 20 litres capacity selective catalytic reduction (SCR) test facility to evaluate the De-NO_x efficiency at various space velocities and various SCR inlet temperatures. The existing 200mm APFBG pilot plant was operated in a combustion mode and generated flue gas for testing of 20 litres capacity honeycomb and plate catalyst for NO_x reduction. The Process and Instrumentation Diagram (P&ID) and Pictorial View of SCR test facility for De-NO_x process is shown in Figure 1(a) & 1(b) respectively. The performance of honeycomb and Plate catalyst was tested with dust concentration of 30-52 grams/Nm³ in flue gas. The following experimental setup comprises of the systems/sub-systems and are explained subsequently,




Figure 1. Process & Instrumentation Diagram of 20 litres capacity SCR test facility

s.no	Sub System
1	APFBG test facility
2	Flue Gas Cooler-I & II
3	On-line Dust Monitoring system
4	NOx Measurement System
5	Ammonia Injection system
6	Static Mixture
7	SCR Reactor Housing
8	SCR Catalyst
9	Venturi Flow Meter
10	Ammonia Slip measurement System

APFBG TEST FACILITY

Advanced Pressurized Fluidized Bed Gasification (APFBG) pilot plant was to use generated flue gases for testing the SCR reactor.

FLUE GAS COOLER-I & II

The purpose of the flue gas coolers are used to cool the flue gas from 400 Deg. C to 300 Deg. C. Since the testing of



catalyst was proposed between 300-350 Deg.C, the flue gas coolers cool and maintain the required temperature at inlet of SCR reactor. Thermocouples are also installed to measure the flue gas temperature at inlet, outlet and between the cooler.

DUST MEASUREMENT SYSTEM

The main objective of the present project is to evaluate the performance of SCR honeycomb and plate catalyst with higher dust concentration of about 30 to 52 grams/Nm³ in flue gas. To achieve the above objective, the generated flue gas from APFBG test facility is admitted in to dust measurement system and measured the dust concentration in flue gas. The following are the specifications of the on-line dust monitoring system

NO_x MEASUREMENT SYSTEM



Figure 2(a) Flue Gas analyser.

1 NOx Ch 0-1000	79 ppm
2 SO2 Ch 0-3000	178 ppm
3 CO2 Ch 0-20,00	9.64
4 CO Ch 0-200.0	55.8 🔎
5 02 Ch 0-25.00	8.79

Figure 2(b). Flue Gas Composition.

AMMONIA INJECTION SYSTEM

Anhydrous ammonia is used as reducing agent for $De-NO_x$ system in SCR technology. In this system, A 0.5mm nozzle is used for injecting the ammonia in to flue gas pipe line with the help of ammonia mass flow controller. The specifications of the ammonia mass flow controller are shown in below Table.

Description		
Scope of Supply:	Mass Flow Controller suitable for controlling, measuring and display of ammonia gas	
Medium	Anhydrous ammonia gas	
Ammonia flow range (LPM)	0.4 LPM to 2 LPM	
Inlet Pressure range (kg/cm ²)	0.5 to 3	
Medium temperature range	10°C to 50°C	
Maximum allowable pressure drop	0.05 kg/ sq.cm	

Flow selectionVolumetric flow/Mass flowThe mixed (ammonia and oxides of nitrogen) gas sent to SCRreactor to absorb the oxides of nitrogen in presence ofcatalyst. The anhydrous ammonia injection nozzle and massflow controller is shown in figure.3(a),(b).



Figure 3(a) Ammonia Injection Nozzle &. (b) Ammonia Mass flow Controller.

Ammonia is a gas at normal atmospheric temperature, therefore, it must be transported and stored under pressure. Anhydrous ammonia often requires special permission for transportation and storage. It is a colourless gas with a pungent odour that is noticeable at concentrations above 50 ppm. It is poisonous if inhaled in great quantities and is irritating to the eyes, nose, and throat in lesser amounts. The danger associated with ammonia is that it is explosive when mixed with air in certain proportions, approximately one volume of ammonia to two volumes of air, and is much more so when mixed with oxygen. The properties of anhydrous ammonia is shown in Table.

Property	Anhydrous Ammonia
Liquid or gas at normal air	
temperature	Liquid
Ratio of ammonia to solution	99.5% (by weight of NH ₃)
Density of liquid at 60 ⁰ F	5.1 lb/gal
Vapor pressure @ 80 ⁰ F	153 psia
Flammability limits in air	16-25 % NH ₃ (by volume)
Short-term exposure limit	35 ppm
Odor	Pungent odor @ 5 ppm or more
	Steel, rated for at least 250 psig
	pressure (no copper or
Acceptable materials for storage	copper-based alloys, etc.,)

ADVANTAGES OF ANHYDROUS AMMONIA

- Lowest regent cost
- Lowest capital cost
- Lowest operating cost
- Simplistic Design
- Fewest product deliveries
- Easily available

DIS-ADVANTAGES OF ANHYDROUS AMMONIA

- It must be stored and handled under high pressure
- Highest permitting costs
- Largest number of regulatory issues

IMPORTANT SAFETY POINTS

- Always have an ample water supply close by;
- Always wear personal protective equipment;
- Never fill a tank over 85 percent of its capacity;
- Inspect hoses and valves regularly;
- Replace hoses at least every five years;
- Bleed off pressure in the hose before disconnecting it;
- Stay clear of hose and valve openings;

Blue Eyes Intelligence Engineering

Published By:

& Sciences Publication



Testing and Correlation of 8mm Pitch Honeycomb & Plate Type Module Performance in a 20 Litres SCR Test Facility

- Follow step-by-step procedures when using the equipment;
- Never try to repair the tank yourself seek a qualified technician;

STATIC MIXTURE

Static mixture is an equipment which is used to mix thoroughly the oxides of Nitrogen (NO_x) available in flue gas with anhydrous ammonia. The performance of the catalyst is totally depends upon the quality of mixing in the static mixture.

SCR REACTOR HOUSING

The honeycomb catalyst is enclosed in a fabricated stainless steel housing called SCR reactor. The size of the SCR reactor is 94mm X 94mm X 750 mm of 3 modules. As the same way 86mm X 86mm X 730 mm plate type is also mounted.

SCR CATALYST

Catalyst is the heart of De-NO_x process. There are two types of catalysts are available; honeycomb & plate type catalyst. The honeycomb and plate type catalyst with 8mm pitch has been used for reduction of oxides of nitrogen (NO_x) from flue gas. Anhydrous gaseous ammonia reacts with NO_x in flue gas to form nitrogen (N₂) and water vapour (H₂O) in presence of honeycomb catalyst. The primary base material of catalyst is titanium dioxide (TiO₂), with smaller amounts of other metal oxides including tungsten oxide (WO₂) for thermal support and vanadium pentoxide (V₂O₅), which is the primary active material.

The size of honeycomb is offered with 94mm X 94mm X 750mm of 3 Modules with 8mm pitch and 1mm wall thickness. The total volume of the catalyst is 0.0198 m^3 (0.094*0.094*0.75*3). And plate catalyst o86mm X 86mm X 730mm of 3 modules. The pictorial view of 8mm pitch honeycomb and plate catalyst has been shown in figure. To provide a large gas contact area with a minimum pressure loss, the honeycomb catalyst is provided as 64 elements containing a large number of parallel channels.



Figure 4.Pictorial View of 8mm (a) Honeycomb and (b) plate Catalyst along with casing

SCR PERFORMANCE PARAMETERS

The rate of the reduction reaction determines the amount of NO_x removed from the flue gas. The major design and operational factors that affect the NO_x removal performance of SCR are:

- Reaction temperature range
- Residence time available in the optimum temperature range
- Degree of mixing of anhydrous ammonia and flue gas composition

• Molar ratio of anhydrous ammonia to inlet NOx

VENTURI FLOW METER

A venturi flow meter has been installed at the exit of SCR reactor, to measure the flue gas flow rate. The installed capacity of the venture flow meter is $150 \text{ Nm}^3/\text{hr}$



IV. EXPERIMENTAL PROCEDURE

The existing 200mm advanced pressurized Fluidized Bed gasification (APFBG) pilot plant was operated in a combustion mode and generated flue gas for testing of 8mm pitch honeycomb and plate catalyst performance. The Process and Instrumentation diagram (P&ID) and pictorial view of SCR test facility for De-NO_x process is shown in Figure 1.The performances of honeycomb and plate catalysts were tested with high dust (30-52 grams/Nm³) concentration in flue gas.

For testing of honeycomb and plate catalysts with dust, flue gas generated from the gasifier and sent directly to dust measurement system where the dust concentration was measured with help of on-line dust monitoring system. Once the dust measured using on-line dust measurement system, the flue gas was sent to immersion heating coil to heat the flue gas to a required SCR inlet temperature (300 to 350 Deg.C) and is shown in figure 8(a). Then the inlet NO_x concentration was measured using flue gas analyser and is shown in figure 2.

Subsequently the required quantity of Anhydrous Ammonia was admitted with help of ammonia mass flow controller in to flue gas pipe line through ammonia injection nozzle. The pictorial view of ammonia mass flow controller and ammonia flow nozzle is shown in figure 3 (a) & 3 (b). The quantity of anhydrous ammonia is calculated based on the flue gas flow rate and NO_x concentration in the flue gas. Once the anhydrous ammonia injected in to flue gas, the mixture of ammonia (NH₃) and Oxides of Nitrogen (NO_x) gas was sent to static mixture for better mixing of ammonia and oxides of nitrogen in the flue gas. Then the mixture sent in to SCR reactor to reduce the oxides of nitrogen (NO_x) in presence of honeycomb and plate catalyst for NO_x reduction at required SCR inlet temperature. The temperature, pressure and differential pressures are measured across the SCR



3543

Published By: Blue Eyes Intelligence Engineering & Sciences Publication reactor using E-type thermocouples, pressure transmitters and differential transmitters respectively. Once the reaction completed in SCR reactor, the flue gas passes through gas venturi flow meter to measure the flue gas flow rate for calculating the space velocity. The outlet NOx concentration and ammonia slip also measured before vent off to the atmosphere using flue gas analyzer and ammonia gas analyzer respectively.

The NO_x conversion rate was calculated based on the inlet and outlet NO_x concentration of the SCR reactor.

V. EXPERIMENTAL RESULTS

The experiments were conducted to evaluate performance of 8mm honeycomb and plate catalysts in 20 liters capacity SCR test facility. The flue gas was generated from APFBG pilot plant by operating in combustion mode. to generate the flue gas for testing of in-house developed catalyst. Feed particle size has been maintained more or less same for all the experiments and which was + 0.5 to -4.0 mm.

The fluidized bed gasifier generates the flue gas by operating in combustion mode. The flue gas composition consists of carbon di-oxide (CO₂), water (H₂O), oxygen (O₂), nitrogen (N₂), nitrous oxide (NO), nitrogen di-oxide (NO₂), sulphur di-oxide (SO₂), and Argon (Ar). The generated flue gas composition in volume percentage wise is shown in table

Flue Gas Composition (Vol %)		
Carbon di-oxide (CO ₂)	12	
Water (H ₂ O)	8.5	
Oxygen (O ₂)	6.24	
Nitrogen (N ₂)	71.9755	
Oxides of Nitrogen (NOx)	0.04	
Oxides of Sulphur (SOx)	0.03	
Argon (Ar)	1.2	
Average Molecular Weight	29.46952	

The generated flue gas was sent to honeycomb and plate type catalysts to evaluate the NO_x removal efficiency and ammonia slip by varying the space velocities and flue gas temperatures with and without dust concentration in flue gas respectively. The following parameters are measured continuously while testing of Honeycomb and plate type catalysts respectively

- 1. Inlet & outlet NO_x concentration at SCR reactor
- 2. Anhydrous ammonia flow rate
- 3. Flue gas flow rate
- 4. Ammonia slip.
- 5. Reaction temperature range;
- 6. Differential pressure across the SCR reactor
- 7. Pressure at inlet and outlet of SCR reactor

VI. RESULTS AND DISCUSSION

The NO_x reduction reaction takes place in presence of SCR catalyst. The SCR reactor contains a honeycomb and plate type catalysts of 94mm X 94mm X 750 mm size of 3 modules with 8mm pitch of 64 numbers and plate type catalyst is 86mm X 86mm X 730 mm long to get about 20 liter catalyst volume. When the mixture (Flue gas and ammonia) is admitted in to SCR reactor, the available NO_x in the flue gas is reacted with ammonia in presence of catalyst and converted in to nitrogen (N₂) and water (H₂O). The catalytic reduction process consists of primary and secondary reactions and those are shown below:

Primary reactions

 $\begin{array}{l} 4\mathrm{NO}+4\mathrm{NH}_3+\mathrm{O}_2\rightarrow 4\mathrm{N}_2+6\mathrm{H}_2\mathrm{O}\\ 2\mathrm{NO}_2+4\mathrm{NH}_3+\mathrm{O}_2\rightarrow 3\mathrm{N}_2+6\mathrm{H}_2\mathrm{O}\\ \mathrm{NO}+\mathrm{NO}_2+2\mathrm{NH}_3\rightarrow 2\mathrm{N}_2+3\mathrm{H}_2\mathrm{O}\\ \hline \textbf{Secondary reactions}\\ 2\mathrm{SO}_2+\mathrm{O}_2\rightarrow 2\mathrm{SO}_3\\ 2\mathrm{NH}_3+\mathrm{SO}_3+\mathrm{H}_2\mathrm{O}\rightarrow (\mathrm{NH4})_2\mathrm{SO}_4\\ \mathrm{NH}_3+\mathrm{SO}_3+\mathrm{H}_2\mathrm{O}\rightarrow \mathrm{NH}_4\mathrm{HSO}_4 \end{array}$

NOX REMOVAL EFFICIENCY

The NO_x removal efficiency, represented as η_{NOx} , is determined from the inlet and outlet NO_x concentration of SCR. The equation for the NO_x removal efficiency is given by:

NOx Removal Efficiency
$$\eta_{NOx}$$
 : $\frac{NOxin - NOxout}{NOxin}$

Where:

$$\begin{split} \eta_{NOx} &= NO_x \text{ removal efficiency, fraction} \\ NO_{xin} &= Inlet \ NO_x \text{ rate to the SCR,} \end{split}$$

 $NO_{xout} = outlet NO_x$ rate from the SCR.

SPACE VELOCITY (1/hr)

The space velocity is defined as the ratio of volumetric flow rate of flue gas and the catalyst volume. It is commonly regarded as the reciprocal of the residence time. The units are per hour

VII. SCR HONEYCOMB CATALYST WITH DUST CONCENTRATION

1. Flue Gas Flow Rate Vs De-Nox Efficiency

Figure 6. Shows the De-NO_x efficiency as a function of Flue gas flow rate. To generate the Flue gas flow rate Vs De-NO_x efficiency performance curve, this experiment was conducted in a 20 litre capacity SCR test facility by varying the flow rate of 31.80, $41.75 \& 51.70 \text{ Nm}^3$ /hr which is an equivalent to the space velocity of 1000, 1500 & 2000




Figure 6.NO_x Reduction Efficiency Vs Flue gas flow rate at 300, 325 & 350 Deg.C

 Nm^3/hr . Also the SCR inlet temperature varied in the range of 300 to 350 Deg.C and the molar ratio of ammonia (NH₃) to oxides of nitrogen (NO_x) varied in the range of 0.9 to 1.0 but reported only 0.9 (NH₃: NO_x=0.9) due to avoid more ammonia slip.



Retrieval Number: C6258029320/2020©BEIESP DOI: 10.35940/ijeat.C6258.029320

3544

Testing and Correlation of 8mm Pitch Honeycomb & Plate Type Module Performance in a 20 Litres SCR Test Facility

The results show that the De-NO_x efficiency increases with decrease in flue gas flow rate which could be attributed due to less residence time. The residence time is the major parameter which greatly affects the De-NO_x efficiency in SCR catalyst. When the flue gas flow rate increases, the residence time decreases which means the flue gas spent very less time in SCR reactor which leads to reduction in reaction rate between NOx and NH₃. When the flue gas flow rate increases from flue gas flow rate is 31.80 to 51.70 Nm³/hr, the De-NO_x efficiency decreased from 86.75 to 81.89% at different temperatures (300 -350 Deg.C).

FLUE GAS FLOW RATE VS PRESSURE DROP ACROSS SCR REACTOR




Figure 7.Flue gas flow rate Vs pressure drop across SCR reactor

Figure .7. Shows the pressure drop across SCR reactor as a function of flue gas flow rate to generate the flue gas flow rate Vs pressure drop across SCR reactor performance graph, this experiment was conducted in a 20 liter capacity SCR test facility by varying the flue gas flow rate at 31.80, 41.75 & 51.70 Nm³/hr which is an equivalent to the space velocity of 1000, 1500 & 2000 /hr respectively.

The results show that the pressure drop across SCR catalyst increases with increase in flue gas flow rate. The pressure drop across SCR catalyst is a function of the length of the catalyst, catalyst configuration and deposition of fly ash over the catalyst. The measured dust concentration at a flow rate of 51.70, 41.75 & 31.80 Nm³/hr was 30-32, 45-47 and 50-52 grams/nm³ respectively.

It also been observed that the pressure drop across SCR reactor is varying from 20mmWc to 38 mmWc over a 2250mm catalyst length.

AMMONIA SLIP VS FLUE GAS FLOW RATE




Figure 8. Ammonia slip Vs gas flow rate

Figure .8. Shows the ammonia slip as a function Flue gas flow rate. To generate the Ammonia slip Vs Flue gas flow rate performance curve, this experiment was conducted in a 20 litre capacity SCR test facility by varying the flue gas flow rate of 31.80, 41.75 & 51.70 Nm³/hr. Also varied the SCR inlet temperature in the range of 300-350 deg. C and the molar ratio of ammonia (NH₃) to oxides of nitrogen (NO_x) in the range of 0.9 to 1.0 but reported only 0.9 (NH₃: NO_x=0.9) due to avoid more ammonia slip.

The results show that the Ammonia slip increases as the flue gas flow rate increases which could be attributed due lower residence time. When the flue gas flow rate increases from 1000 to 2000 Nm³/hr, the ammonia slip increases from 1.3 to 1.9ppm at the molar ratio of ammonia (NH₃) to oxides of nitrogen (NO_x) in the range of 0.9. When the flue gas flow increases, the residence time decreases when the residence time decreases the reactivity also decreases. When the reactivity decreases as the catalyst activity decreases. The allowable ammonia slip approximately less than 2 ppm [3]. SCR PLATE TYPE CATALYST PERFORMANCE CURVES

FLUE GAS FLOW RATE VS DE-NO_X EFFICIENCY

Figure 9: Shows the De-NO_X efficiency as a function of space velocity. To generate the space velocity Vs De-No_x efficiency performance curve, this experiment was conducted in a 20 litre capacity SCR test facility by varying the flow rate of 24.30, 32.40 & 40.50 Nm³/hr at a space velocity of 1000 to 2100 /hr. Also the SCR inlet temperature varied in the range of 300 to 350 Deg.C and the molar ratio of ammonia (NH₃) to oxides of nitrogen (NO_X) varied in the range of 0.9 to 1.0 but reported only 0.9 (NH₃: NO_X=0.9) due to avoid more ammonia slip. The results show that the $De-NO_X$ efficiency increases with decrease in flue gas flow rate which could be attributed due to less residence time. The residence time is the major parameter which greatly affects the De-NO_x efficiency in SCR catalyst .When the flue gas flow rate increases, the residence time decreases which means the flue gas spent very less time in SCR reactor which leads to reduction in reaction rate between NO_X and NH₃.



Published By

& Sciences Publication

Blue Eyes Intelligence Engineering




Figure 9. Flue gas Flow rate Vs De-NOx efficiency

When the flue gas flow rate increases from flue gas flow rate is 31.80 to 51.70 Nm^3/hr , the De-NO_X efficiency decreased from 86.09 to 79.45% and the NO_X reduction efficiency increases with increase in temperature up to 350 Deg C. NO_X reduction efficiency increased from 82.91 to 85.88 % at different temperatures (300 -350 Deg.C).

FLUE GAS FLOW RATE VS PRESSURE DROP ACROSS SCR REACTOR.




Figure 10. Flue gas flow rate Vs pressure drop across SCR reactor

Figure 10. Shows the Pressure drop across SCR reactor as a function of flue gas flow rate. To generate the flue gas flow rate Vs pressure drop across SCR reactor performance graph, this experiment was conducted in a 20 litre capacity SCR test facility by varying the flue gas flow rate at 24.30, 32.40 & 40.50 Nm³/hr and space velocity of 1000, 1500 & 2000 /hr respectively. The results show that the pressure drop across SCR catalyst increases with increase in flue gas flow rate. The pressure drop across SCR catalyst is a function of the length of the catalyst, catalyst configuration and deposition of fly ash over the catalyst. The measured dust concentration at a flow rate of 51.70, 41.75 & 31.80 Nm³/hr was 30-32, 45-47 and 50-52 grams/nm³ respectively.

It also been observed that the pressure drop across SCR reactor is varying from 10.46 mmWc to 15.50 mmWc over a 2190mm catalyst length.

AMMONIA SLIP VS FLUE GAS FLOW RATE.




Figure 11. Ammonia slip Vs Flue gas flow rate

Figure 11. Shows the ammonia slip as a function of Flue gas flow rate. To generate the ammonia slip vs flue gas flow rate performance curve, this experiment was conducted in a 20 litre capacity SCR test facility by varying the flue gas flow rate of 24.30, 32.40 & 40.50 Nm³/hr. Also varied the SCR inlet temperature in the range of 300-350 deg. C and the molar ratio of ammonia (NH₃) to oxides of nitrogen (NO_x) in the range of 0.9 to 1.0 but reported only 0.9 (NH₃: NO_x = 0.9) due to avoid more ammonia slip. The results show that the Ammonia slip increases as the flue gas flow rate increases which could be attributed due lower residence time. When the space velocity increases from 1000 to 2000 Nm³/hr, the ammonia slip increases from 1.6 to 1.8ppm at the molar ratio of ammonia (NH₃) to oxides of nitrogen (NOx) in the range of 0.9. When the flue gas flow increases, the residence time decreases when the residence time decreases the reactivity also decreases. When the reactivity decreases the ammonia slip increases. Ammonia slip also increases as the catalyst decreases. The allowable ammonia activity slip approximately less than 2 ppm [3].

COMPARISSION

Efficiency's for honeycomb and Plate type catalyst's at different space velocity's and different temperatur's.

	HONEYCOMB		
Flow rate vs Avg Temp	300	325	350
31.80 Nm ³ /hr	84.50%	85.84%	86.75%
41.75 Nm ³ /hr	83.15%	84.25%	85.72%
51.70 Nm ³ /hr	81.92%	83.24%	84.07%
	PLATE TYPE		
Flow rate vs Avg Temp	300	325	350
24.30 Nm ³ /hr	82.90%	84.51%	85.62%
32.40 Nm ³ /hr	81.01%	83.01%	84.14%
40.50 Nm ³ /hr	79.50%	82.01%	84.01%

1. Ammonia slip measured was in the range of 1.4 to 3.8 ppm for honeycomb catalyst and with plate type was 1.6-4.7 ppm at 0.9 & 1.0 for ammonia to oxides of nitrogen.

2. The total differential Pressure (DP) across honeycomb SCR catalyst was 25-38 mmWc over a 2250mm length



and for plate type SCR catalyst was 9-18 mmWc over a 2100mm length.

- 3. Surface area is high in honeycomb and quite less in plate type.
- 4. Back pressure is high in honeycomb and less in plate type.
- 5. Ash struck in the chamber is observed in honeycomb and while coming to plate it is too less.
- 6. We have achieved max NO_x efficiency at gas flow rate of 31.80 Nm³/hr, 41.75 Nm³/hr, 51.70 Nm³/hr for honeycomb and 24.30 Nm³/hr, 32.40 Nm³/hr, 40.50 Nm³/hr for plate type.

VIII. SUMMARY

The existing 200mm advanced pressurized fluidized bed gasification (APFBG) pilot plant was operated in a combustion mode and generated flue gas for testing of 8mm Honeycomb and plate type catalyst to evaluate the catalyst efficiency. To evaluate the honeycomb and plate type catalyst, three modules of each in-house developed honeycomb and plate type SCR catalysts were tested in a 20 liter capacity SCR pilot plant. The size of the each honeycomb is 94mm X 94mm X 750 mm long and plate type catalyst volume. The process and instrumentation diagram (P&ID) of 20 liters SCR test Facility for De-NO_x system is shown in Figure 1. The performance of honeycomb and plate type

catalysts were evaluated by varying the dust concentration from 30-52 g/Nm³ in flue gas. Also varied the flue gas flow rate of 31.80, 41.75 & 51.70 Nm³/hr which is an equivalent to the space velocity of 1000, 1500 & 2000 Nm³/hr and 1600, 2102 & 2600 /hr respectively. Also the SCR inlet temperature is varied in the range of 300 to 350 Deg.C and the molar ratio of ammonia (NH₃) to oxides of nitrogen (NO_x) is varied in the range of 0.9 to 1.0 for all experiments. Also measured the inlet NO_x, outlet NO_x, Inlet dust concentration, pressures, differential pressures across static mixture & SCR reactor and ammonia slip at out let of the SCR reactor. The following performance curves were generated to evaluate the honeycomb and plate type catalysts.

IX. CONCLUSIONS

Experiments were carried out to generate the performance curves on in-house developed 8mm Pitch Honeycomb and Plate type catalysts in a 20 litre volume capacity SCR test facility. The flue gas was generated from 200mm Advanced Pressurized Fluidized Bed Gasification (APFBG) pilot plant by operating in combustion mode. The NO_x removal efficiency and ammonia slip was investigated with dust concentration of 38-50 grams/Nm³ in flue gas by varying the space velocities (2500-1500 per hr.) and flue gas temperatures (300–350^oC) using anhydrous ammonia as reducing agent.

• In-house developed 8mm pitch honeycomb and plate type SCR catalysts were tested in a 20-liter capacity SCR test facility with dust concentration in the range of 38-50 grams/nm³ by varying the space velocities (2500-1500 per hr.) and flue gas temperatures in the range of 300–350^o C using anhydrous ammonia as reducing agent.

- NOx reduction efficiency achieved with honeycomb was 81.89 86.75% and with plate type was 79.50 85.62% at 2500-1500 per hr. space velocities and the ratio of ammonia (NH₃) to oxides of nitrogen (NO_x) was maintained at 0.9.
- NO_x reduction efficiency achieved with honeycomb was 82.72–88.23% and with plate type was 80.43 87.41% at 2500-1500 per hr. space velocities and the ratio of ammonia (NH₃) to oxides of nitrogen (NO_x) was maintained at 1.0.
- Ammonia slip measured was in the range of 1.4 to 3.8 ppm for honeycomb catalyst and with plate type was 1.6-4.7 ppm at 0.9 & 1.0 for ammonia to oxides of nitrogen.
- The total Differential Pressure (DP) across Honeycomb SCR catalyst was 25-38 mmWc over a 2250mm length and for plate type SCR catalyst was 9-18 mmWc over a 2100mm length.

Finally, it can be concluded that, the 8mm pitch honeycomb and plate type SCR catalysts are very much suitable for reduction of Oxides of Nitrogen (NOx) in the range of 80-90% in flue gas with dust concentration of 30-52grams/Nm³ which are meeting the power plant requirements

REFERENCES

- Institute of Clean Air Companies (ICAC). Selective Catalytic Reduction (SCR) Control of NOx Emissions, Prepared by the ICAC SCR Committee, November 1997.
- 2. Selective Catalytic Reduction of NOx controls section 4, EPA/452/B-02-001.
- International Energy Outlook 2016, report no. DOE/EIA-0484(2016) I May 2016.
- 4. Latest Selective Catalytic Reduction (SCR) Technologies for DeNOx Plants, Christoph M. Heinisch, Experts September 2013.
- Christoph M. Heinisch, Air Economics Group, Chapter 2 of Selective Catalytic Reduction, June 2015.

AUTHORS PROFILE



D. Eswaraiah, Currently his working as a asst.Prof in Gokaraju Rangaraju Institute of engineering and technology, HYDERABAD and is done his M.Tech (Thermal Engineering) in JNTU-Hyderabad, B.Tech. (Mechanical Engineering), Acharya Nagarjuna University, Guntur. And He published three international journals, His area of interests are heat transfer, refrigeration and air conditioning, thermodynamics, CFD,EDTS.



Karthik Gudipudi, M. Tech (Thermal Engineering) from Gokaraju Rangaraju Institute of engineering and technology -Hyderabad, B.Tech, (Mechanical Engineering) from Khammam institute of technology and sciences (KITS), khammam. His areas of interest are heat transfer applications, thermodynamics and strength of materials.



U.Harish kumar, M. Tech (Thermal Engineering) from Gokaraju Rangaraju Institute of engineering and technology -Hyderabad,B.E(Mechanical Engineering) from Sri handrasekharendra Saraswathi Viswa Maha Vidhyalaya (SCSVMV) university Kancheepuram, Tamil Nadu (631561).His areas of interest are heat transfer,strength of materials.



3547

Published By: Blue Eyes Intelligence Engineering & Sciences Publication