


Spectro-astrometry with Photonic Lanterns



Yoo Jung Kim¹, Stephanie Sallum², Jonathan Lin¹, Yinzi Xin³, Barnaby Norris⁴, Christopher Betters⁴, Sergio Leon-Saval⁴, Julien Lozi⁵, Sebastien Vievard⁵, Pradip Gatkine³, Olivier Guyon⁵, Nemanja Jovanovic³, Dimitri Mawet³, and **Michael P. Fitzgerald¹**

¹University of California, Los Angeles, ²University of California, Irvine,

³California Institute of Technology, ⁴The University of Sydney, ⁵Subaru Telescope

Overview

1. Spectro-astrometry and artifacts
2. Photonic lanterns
3. Spectro-astrometry with photonic lanterns
4. Application & mock observation: Binary model

Spectro-astrometry measures light centroid as a function of wavelength, a technique for studying angular scales smaller than the PSF size

Binary stars






Image at focal plane :




Spectro-astrometric signal
= wavelength-dependent
centroid shift

A method for studying scales
smaller than the PSF size,
where morphology changes
with wavelength


Examples: young binaries, stellar outflows, broad-line region of quasars

Slit-based spectro-astrometry suffers from artifacts due to asymmetry in PSF

Most spectro-astrometric studies used long-slit spectroscopy or image slicer-based IFU spectroscopy.




Asymmetries in the dispersion axis introduce spectro-astrometric **artifacts**



We measure center of light shift in the spatial axis (spectro-astrometric signal)

At least two observations of different position angles needed to obtain 2D spectro-astrometric signals

180° rotated spectra must be obtained to correct for the artifacts





Spatial filtering of unwanted aberrations is crucial!

Photonic Lantern (PL)

❖ Photonic lantern:



- A waveguide that gradually transitions from few-mode fiber geometry to a bundle of single-mode fiber geometry.
- High throughput, high stability (spatial filtering)
- Considered for future fiber-fed spectrograph
- Uses: OH line suppression, Focal-plane wavefront sensing, high contrast imaging with vortex fiber nuller



Photonic Lantern (PL) for spectro-astrometry

❖ Photonic lantern:




- A waveguide that gradually transitions from few-mode fiber geometry to a bundle of single-mode fiber geometry.
- High throughput, high stability (spatial filtering)
- Considered for future fiber-fed spectrograph
- Uses: OH line suppression, Focal-plane wavefront sensing, high contrast imaging with vortex fiber nuller



For spectro-astrometry:
Relative intensities in each single mode fiber can be used to determine the light centroid precisely!

Linearity of the PL response makes it ideal for spectro-astrometry

- » Photonic lanterns respond linearly to low-order aberrations.




- » The linear relation can be inverted to recover phase aberrations ($\vec{\phi} \approx B^{-1}(\vec{I} - \vec{I}_0)$) – tip/tilt, defocus, astigmatism.


- » In the linear regime, random errors are averaged out (example: AO-residual tip-tilt jitter)

PLs can measure 2D spectro-astrometric signals, do not suffer from artifacts, and are insensitive to random errors.

Summary: PL spectro-astrometry




Application: Binary Model




Can we recover binary parameters with PL spectro-astrometry?

Mock observation:
Accreting planets show strong hydrogen emission lines




Artist's impression of PDS70 system. W. M. Keck Observatory/Adam Makarenko




Aoyama et al. 2021

Linearly reconstructed aberration amplitudes (tip, tilt, defocus, astig) can be used to constrain binary parameters (cont., sep., PA)



Measure: \vec{I} , calculate: $\vec{\phi}_{(\text{tip, tilt, defocus, astig})}$


Example case for zero position angle,
Contrast = 0.001




In the linear regime, the **tip-tilt** = center of light

At large separations, the reconstructed **tip-tilt** deviates from the center of light

Linearly reconstructed aberration amplitudes (tip, tilt, defocus, astig) can be used to constrain binary parameters (cont., sep., PA)



Example case for zero position angle,
Contrast = 0.001



In the linear regime, the **tip-tilt** = center of light


At large separations, the reconstructed **tip-tilt** deviates from the center of light

At large separations, **astigmatism** & **defocus** signals can be used to constrain the separation

➔ contrast & separation degeneracy breaks!


Mock observations

1 hour observation
 $R \sim 4000$
 Tip-tilt jitter 0.2 mas



Small
 separation

Distance = 40pc, separation ~ 0.1 AU, PA=60 deg, Accretion rate = $10^{-8} M_{\odot}/\text{yr}$




Large
 separation

Distance = 140pc, separation ~ 3 AU, PA=60 deg, Accretion rate = $10^{-8.5} M_{\odot}/\text{yr}$

Next steps

- Experiments and on-sky verification
- SMF outputs can be interferometrically combined for spectro-interferometry and coherent imaging



Lin et al. in prep

Summary

- ❖ Spectro-astrometry is a useful technique for studying scales smaller than the PSF size, but care is needed due to artifacts.
- ❖ A photonic lantern, with its spatial filtering property and its linearity, is ideal for a stable measurement of spectro-astrometry.
- ❖ We explored the application on the binary model, in particular on observing accreting planets with hydrogen emission lines. The spectro-astrometry with photonic lantern can constrain binary parameters.