


Date: 20250310 Vacuum pre-experiment: 10-1
Experiment: TNA_Venezia_2
LABVIEW FILE NAME: Venezia_2

- FAN ON ☒ (TIME:) OFF ☐ (TIME:)
- RH% FAN MUST BE ON
RH%_start % RH% REACHED: % [PM₁₀] after RH% max: µg/m³
- PRESSURE P_{int}: P_{ext}: ΔP (P_{int}-P_{ext}):
- TEMPERATURE T_{int}:

PETRI IN: (TIME) ----->
UV LAMP FOR STERILIZATION START TIME: STOP TIME:



Instruments – particles counters:

- OPS ☐ FILE NAME:
SMPS ☐ FILE NAME:
WIBS ☐ FILE NAME:

INJECTION:

NEBULIZER:

Back_Pressure: bar -- Air Flow MFC: lpm -- Injection Feed Rate: ml/min / Injection time: min
[Pre-conditioning ml:]

- Injected in ChAMBRé Start Injection: Stop Injection: ml:
OPS: [PM₁₀] max: µg/m³
WIBS: [# /cm³]_{tot} max: [# /cm³]_{fluor} max:

GASES:	Concentration – t1:	Concentration – t2:	Concentration – t3:	Concentration – t4:	Concentration – t5:
[CO] ppm					
[CO2] ppm					
[NO] ppb					
[NO2] ppb					
[SO2] ppb					
BTEX µg/m ³					
[O ₃] ppb					

TIME:	NOTE:
	B7 dark - 1 sec inj (partial valve)
13:30	NOx - SOx - O ₃ - VOC - PAXs - SMPS
	Riscaldamento motogeneratore 15 min
13:42	PAXs out
14:58	paxs in
14:58:30	SoSi ON 85%
15:00	SoSi 105%
15:03	PAXs out
15:39	SoSi off
16:00	lamp O ₃ on
16:05	lamp off
16:11	vacuum

PETRI OUT: (TIME) Vacuum: